

PARTS BOOK

E-Series Dual-small

E-UH1504D-45

PME-110422

Notice

1. 본 책자는Parts Book으로 제작되었으므로 매뉴얼로 사용 불가합니다.
2. 조에 속한 파트는 개별 조립 시 제품의 파손 또는 자수 불량일 수 있어 해당 파트에 대한 주문 시에는 조 품목으로만 구입이 가능합니다.
3. 당사의 Part Book은 다음과 같은 순서로 분류되어 있으니 제품을 구입한 소비자께서는 다음과 같은 순서로 제품을 검색하여 주십시오.

- 1) Machine Layout
- 2) Section
- 3) Part List

※소모성 부품은 자수 기계의 보증 기간과 상관 없음.

1. This is a parts book. It cannot be used as a manual.
2. The parts classified as ass'y items may cause damage to the machine or bad embroidery when they are separately assembled.
Hence, when they are ordered, they can be purchased as ass'y items only.
3. The Part Book is classified as below and users could search products in the following order.


- 1) Machine Layout
- 2) Section
- 3) Part List

※Consumable parts shall not be guaranteed even in warranty period.

Information

A. Structure of Part Book

1. Machine Layout




Information

A. Structure of Part Book

2. Section

- ① : Index Number
- ② : Index Group
- ③ : Related Parts
Ex) A-1, A-2, A-3...



Information

A. Structure of Part Book

3. Part List

①

A-1

Note

③ Ref No	④ Part No	⑤ Part Name	⑥ Applied Period	⑦ Interchangeability	⑧ Hardware	⑨ Qty	⑩ Remark
A-1-1	0101SCM-T900	Twice-up Lever Driving Cam	Oct-08-07 ~ Oct-08-07			1	
A-1-2	0101SCM-T900	Twice-up Lever Driving Cam	Oct-08-07 ~	X		1	
A-1-3	0101SCM-T121	Cam Screw (8/32x28L=17)				1	
A-1-4	0101SCM-T121	Screw (1/8x28L=7.5)			O	1	
A-1-5	0101SCM-T121	Hex. Socket Set Screw (1/4" 3x40 L=4.5)				1	
A-1-6	0102PWR-A001	Washer				2	
A-1-7	0102PWR-A001	Washer				1	
A-1-8	0102PWR-T900	Needle Bar Crank				1	
A-1-9	0101SCM-T121	Upper Shaft Bushing (H)				1	
A-1-10	0101SCM-T121	Screw (1/8x28 L=14)			O	3	
A-1-11	0101SCM-T121	Felt				1	
A-1-12	0101SCM-T121	Presser Foot Driving Cam				1	
A-1-13	0401ZAP-A001	Screw (1/8x28)			O	3	
A-1-14	0102PWR-A001	Screw (M4xL20)			O	1	
A-1-15	0102PWR-A001	Rearizer (600422)				1	
A-1-16	0102PWR-A001	Rearizer Collar				2	
A-1-17	0401ZAP-A001	Screw (1/8x28)			O	3	
A-1-18	WS-0001BR-00	Washer				1	
A-1-19	CL-000097-00	Code Wheel				1	
A-1-20	CL-000097-00	Collar				1	
A-1-21	0101SCM-T121	Needle Plate				1	
A-1-22	0101SCM-T121	C-Ridge (H47)			O	1	
A-1-23	0101SCM-T121	Rearizer (600422)				1	

(Note) * : Checks the timing of application.

① Index Number
Ex) A-1, A-2...

② Part View

Information

A. Structure of Part Book

③ Ref. No

④ Part No

Ex)

Category	CODE	Remark
Old part	16009SC-4113	
New part	AS -000000-00	Set parts (Set 구성품)
	GP -000000-00	Instrumental parts (기구적 파트)
	EP -000000-00	Electrical parts (전기적 파트)

⑤ Parts Name : 파트들의 고유 품명을 표기 : Refers to unique names of parts

⑥ Applied Period

Ex1) 2007년2월10일 적용, 2008년7월10일 폐기
-> Feb.10.07 ~ Jul.10.08

Ex1) Applied from Feb. 10, 2007, To on July 10, 2008
-> Feb.10.07 ~ Jul.10.08

Ex2) 2007년 2월 10일 부터 파트북 발행일 까지 적용
-> Feb.10.07 ~

Ex2) Applied from Feb. 10, 2007
-> Feb.10.07 ~

Information

A. Structure of Part Book

⑦ Interchangeability

O : 구 부품을 신 부품으로 교환 가능

신 부품을 구 부품으로 교환 가능

: It is interchangeable between old and new part.

X : 구 부품을 신 부품으로 교환 불가능

신 부품을 구 부품으로 교환 불가능

: It is not interchangeable between old and new part.

△ : 구 부품을 신 부품으로 교환 가능

신 부품을 구 부품으로 교환 불가능

: It is interchangeable by new part only.

Interchangeability		
O	X	△
Old -> New: OK New -> Old : OK	Old -> New: NO New -> Old : No	Old -> New: OK New -> Old : No

⑧ Hardware : 시중에서 구매 할 수 있는 부품

: Parts that can be purchased in the market


⑨ Q'ty : 사용 파트의 수량을 표기

: Quantity of part

⑩ Remark

⑪ Index Number

Machine Layout



- A Machine Body Ass'y
- B Arm 1
- C Arm 2
- D Thread Cutting Set
- E Main Drive System I
- E1 Main Drive System II
- F Head & Color Change Set
- G Thread Tension Unit
- H1 XY-Axis Drive System(UH1504D)
- H2 XY-Axis Drive System(UH1506D)
- H3 XY-Axis Drive System(UH1208D)
- H4 XY-Axis Drive System(UH1512D)
- I Settingt I
- I1 Setting II
- J Spool
- K Table
- L Cable
- M Control Box & O/P Box
- N LAMP & SWITCH
- O Bobbin Winder
- P Cover
- Q1 Frame(UH1504D)
- Q2 Frame(UH1506D)
- Q3 Frame(UH1508D)
- Q4 Frame(UH1512D)




CONTENT

A	Beam Body & Bed	10
B	Arm 1	13
C	Arm 2	20
D	Thread Cutting Set	26
E	Main Drive System 1	32
E1	Main Drive System 2	38
F	Head & Color Change	44
G	Thread Tension Unit	51
H1	X-Y Drive (UH1504D-45)	55
H2	X-Y Drive (UH1506D-45)	63
H3	X-Y Drive (UH1508D-45)	71
H4	X-Y Drive (UH1512D-45)	80
I	Setting 1	89
I1	Setting 2	95

J	Spool	100
K	Table	103
L	Cable	112
M	Con Box & O/P Box	119
N	Lamp & Switch	124
O	Bobbin Winder	129
P	Cover	132
Q1	Frame (UH1504D)	135
Q2	Frame (UH1506D)	139
Q3	Frame (UH1208D)	143
Q4	Frame (UH1512D)	147
R	Index	151

Beam Body & Bed



A-1

A-1-1

Note

A

A-2


This exploded view diagram illustrates the assembly of the A-2 component. The main body, labeled A-2-1, is shown with various mounting points and internal features. Key components and their assembly sequence are indicated by callouts and dashed lines:

- A-2-2**: A small screw or pin, shown at the bottom left and bottom right of the main body.
- A-2-3**: A large gear or pulley, shown at the top right.
- A-2-4**: A small washer or spacer, shown near the gear.
- A-2-5**: A small screw or pin, shown near the gear.
- A-2-6**: A small screw or pin, shown near the bottom left of the main body.
- A-2-7**: A small screw or pin, shown near the bottom left of the main body.
- A-2-8**: A small screw or pin, shown near the bottom left of the main body.
- A-2-9**: A small screw or pin, shown near the bottom left of the main body.
- A-2-10**: A small screw or pin, shown near the bottom left of the main body.
- A-2-11**: A small screw or pin, shown near the bottom left of the main body.
- A-2-12**: A small screw or pin, shown near the bottom left of the main body.
- A-2-13**: A small screw or pin, shown near the bottom left of the main body.
- A-2-14**: A small screw or pin, shown near the bottom left of the main body.
- A-2-15**: A small screw or pin, shown near the bottom left of the main body.
- A-2-16**: A small screw or pin, shown near the bottom left of the main body.
- A-2-17**: A small screw or pin, shown near the bottom left of the main body.
- A-2-18**: A small screw or pin, shown near the bottom left of the main body.
- A-2-19**: A small screw or pin, shown near the bottom left of the main body.
- A-2-20**: A small screw or pin, shown near the bottom left of the main body.
- A-2-21**: A small screw or pin, shown near the bottom left of the main body.
- A-2-22**: A small screw or pin, shown near the bottom left of the main body.
- A-2-23**: A large screw or pin, shown at the bottom right of the main body.
- A-2-24**: A small washer or spacer, shown near the large screw.
- A-2-25**: A small washer or spacer, shown near the large screw.
- A-2-26**: A small washer or spacer, shown near the large screw.
- A-2-27**: A small washer or spacer, shown near the large screw.

Note

A

Arm 1



This diagram shows the exploded view of the B-1-1 unit assembly. The main unit, labeled B-1-1, is a rectangular box with a handle on the right side. It is shown with various components being installed or removed. The components are labeled as follows:

- B-1-2**: A small rectangular component on top of the unit.
- B-1-3**: A small rectangular component on the side of the unit.
- B-1-4**: A long, thin rectangular component, likely a cable or hose, connected to the side of the unit.
- B-1-5**: A small rectangular component on the top of the unit.
- B-1-6**: A small rectangular component on the side of the unit.
- B-1-7**: A small rectangular component on the side of the unit.
- B-1-8**: A small rectangular component on the side of the unit.

The diagram also shows the internal structure of the unit, including the handle and various mounting points. The unit is shown in a disassembled state, with the components being installed or removed. The diagram is a technical drawing with dashed lines indicating the assembly path.

Note

[illegible]

14

B-2

The diagram illustrates the assembly of the B-2 component. It shows a main assembly area at the bottom and a detailed inset at the top right. The main assembly shows a large bracket-like structure with various mounting points. The inset shows a detailed view of a specific assembly step, likely the installation of the B-2-16 component. The components are labeled as follows:

- B-2-16: A long, thin rod or pin.
- B-2-15: A small cylindrical component.
- B-2-18: A small cylindrical component.
- B-2-7: A small cylindrical component.
- B-2-9: A small cylindrical component.
- B-2-8: A small cylindrical component.
- B-2-14: A small cylindrical component.
- B-2-13: A small cylindrical component.
- B-2-17: A small cylindrical component.
- B-2-10: A small cylindrical component.
- B-2-12: A small cylindrical component.
- B-2-11: A small cylindrical component.
- B-2-6: A small cylindrical component.
- B-2-5: A small cylindrical component.
- B-2-4: A small cylindrical component.
- B-2-1: A small cylindrical component.
- B-2-2: A small cylindrical component.
- B-2-3: A small cylindrical component.

Note



Note



B-4

Exploded view diagram of the B-4 assembly, showing various components and their assembly sequence. The diagram includes the following labeled parts:

- B-4-1: Main vertical support plate.
- B-4-2: Bolt for B-4-1.
- B-4-3: Lever arm.
- B-4-4: Pin for B-4-3.
- B-4-5: Pin for B-4-3.
- B-4-6: Bolt for B-4-1.
- B-4-7: Main vertical support plate (alternative view).
- B-4-8: Washer for B-4-7.
- B-4-9: Washer for B-4-7.
- B-4-10: Bolt for B-4-7.
- B-4-11: Bolt for B-4-7.
- B-4-12: Bolt for B-4-7.
- B-4-13: Bolt for B-4-7.
- B-4-14: Bolt for B-4-7.
- B-4-15: Bolt for B-4-7.
- B-4-16: Bolt for B-4-7.
- B-4-17: Bolt for B-4-7.
- B-4-18: Bolt for B-4-7.
- B-4-19: Bolt for B-4-7.
- B-4-20: Bolt for B-4-7.
- B-4-21: Bolt for B-4-3.
- B-4-22: Washer for B-4-21.
- B-4-23: Washer for B-4-21.
- B-4-24: Washer for B-4-21.

Note



Note


B

This diagram shows the exploded view of the B-6 assembly. The main component is the B-6-1 frame. To its left is the B-6-5 plate, which is secured by screws B-6-6 and B-6-7. To the right of the frame is another plate, which is secured by screws B-6-2, B-6-3, and B-6-4. A small rectangular component is also shown near the right plate. The diagram illustrates the relative positions and assembly sequence of these parts.

Note

B

Arm 2



C-1

Exploded view diagram of the C-1 assembly. The diagram shows the following components and their assembly sequence:

- C-1-1**: The main base plate, which is a large rectangular plate with various mounting holes and a central cutout.
- C-1-2**: A long, narrow plate that fits into a slot on the front of C-1-1. It is secured by a screw (C-1-4) and a pin (C-1-3).
- C-1-3**: A long pin that passes through the front plate (C-1-2) and the base plate (C-1-1) to secure them together.
- C-1-4**: A screw that secures the front plate (C-1-2) to the base plate (C-1-1).
- C-1-5**: A small rectangular plate that fits into a slot on the top of the base plate (C-1-1).
- C-1-6**: A screw that secures the top plate (C-1-5) to the base plate (C-1-1).

Note



C-2

The diagram illustrates the assembly of the C-2 unit. The components and their assembly sequence are as follows:

- C-2-1**: The main vertical plate, which is the first part to be installed.
- C-2-2**: A small rectangular component that is attached to the top of the main plate (C-2-1).
- C-2-3**: A screw used to secure the top of the main plate (C-2-1).
- C-2-4**: A dashed box indicating the sub-assembly of components C-2-5 through C-2-14.
- C-2-5**: A vertical plate that is attached to the main plate (C-2-1) using screw **C-2-14**.
- C-2-6**: A horizontal plate that is attached to the bottom of the main plate (C-2-1) using screw **C-2-3**.
- C-2-7**: A small component that is attached to the bottom of the main plate (C-2-1) using screw **C-2-14**.
- C-2-8**: A small component that is attached to the bottom of the main plate (C-2-1) using screw **C-2-14**.
- C-2-9**: A small component that is attached to the bottom of the main plate (C-2-1) using screw **C-2-14**.
- C-2-10**: A small component that is attached to the bottom of the main plate (C-2-1) using screw **C-2-14**.
- C-2-11**: A small component that is attached to the bottom of the main plate (C-2-1) using screw **C-2-14**.
- C-2-12**: A small component that is attached to the bottom of the main plate (C-2-1) using screw **C-2-14**.
- C-2-13**: A small component that is attached to the bottom of the main plate (C-2-1) using screw **C-2-14**.
- C-2-14**: A screw used to secure the bottom of the main plate (C-2-1).

Note



This exploded view diagram illustrates the assembly of the C-3-1 component. The main body, C-3-1, is a rectangular block with a central circular feature. Various parts are shown being attached to it, including a bracket (C-3-3) and a flange (C-3-2). The diagram uses dashed lines to show the alignment and assembly sequence of the parts. Key components include:

- C-3-1**: Main rectangular body.
- C-3-2**: Flange with a central hole.
- C-3-3**: Bracket with a circular opening.
- C-3-4**: Bolt.
- C-3-5**: Washer.
- C-3-6**: Nut.
- C-3-7**: Bolt.
- C-3-8**: Washer.
- C-3-9**: Bolt.
- C-3-10**: Bolt.
- C-3-11**: Bolt.
- C-3-12**: Bolt.
- C-3-13**: Bolt.
- C-3-14**: Bolt.
- C-3-15**: Bolt.
- C-3-16**: Bolt.
- C-3-17**: Bolt.
- C-3-18**: Bolt.
- C-3-19**: Bolt.
- C-3-20**: Bolt.
- C-3-21**: Bolt.
- C-3-22**: Bolt.
- C-3-23**: Bolt.
- C-3-24**: Bolt.
- C-3-25**: Bolt.
- C-3-26**: Bolt.
- C-3-27**: Bolt.



This exploded view diagram illustrates the assembly of the C-4-10 LED light fixture. The components are labeled as follows:

- C-4-10**: The main LED light fixture tube.
- C-4-9**: The main housing or base of the fixture.
- C-4-11**: Two screws used to secure the housing (C-4-9).
- C-4-12**: A cap or plug for the top of the housing.
- C-4-5**: A mounting bracket or arm that connects the housing to the wall plate.
- C-4-6**: A screw used to secure the mounting bracket.
- C-4-7**: A wall plate or mounting plate.
- C-4-8**: A screw used to secure the wall plate.
- C-4-1**: A circular component, likely a lens or diffuser, which is shown in a dashed box indicating it is part of the internal assembly.
- C-4-2**: A screw used to secure the circular component.
- C-4-3**: A small component, possibly a switch or sensor, located near the circular component.
- C-4-4**: A small component, possibly a switch or sensor, located near the circular component.
- C-4-13**: A cable or wire connected to the circular component.

[illegible]


This diagram illustrates the exploded view of the C-5-1 component assembly. The main component, C-5-1, is a square block with a central circular opening. The assembly includes the following parts:

- C-5-1**: The main square component with a central circular opening.
- C-5-2**: A small cylindrical pin.
- C-5-3**: A small cylindrical pin.
- C-5-4**: A small cylindrical pin.
- C-5-5**: A large cylindrical ring.
- C-5-6**: A small cylindrical pin.
- C-5-7**: A small cylindrical pin.
- C-5-8**: A small cylindrical pin.
- C-5-9**: A small cylindrical pin.
- C-5-10**: A small cylindrical pin.
- C-5-11**: A small cylindrical pin.

The diagram shows the relative positions and assembly sequence of these components, with dashed lines indicating the alignment and fit of the parts.

[illegible]

Thread Cutting Set



D-1

This exploded view diagram illustrates the assembly of a car stereo unit. The main components shown are:

- D-1-1**: The main stereo chassis, shown from both front and rear perspectives.
- D-1-2**: A mounting bracket that fits into the rear of the chassis.
- D-1-3**: A screw used to secure the mounting bracket.
- D-1-4**: A long vertical screw for the main chassis.
- D-1-5**: A set of four screws used to secure the mounting bracket to the chassis.
- D-1-6**: A mounting bracket for the antenna.
- D-1-7**: A screw for the antenna bracket.
- D-1-8**: A small plastic component, likely a grommet or spacer.
- D-1-9**: A small screw for the antenna bracket.
- D-1-10**: A small screw for the antenna bracket.
- D-1-11**: A long horizontal screw for the antenna bracket.
- D-1-12**: A small screw for the antenna bracket.
- D-1-13**: A small screw for the antenna bracket.
- D-1-14**: A small screw for the antenna bracket.
- D-1-15**: A long horizontal screw for the antenna bracket.
- D-1-16**: A small screw for the antenna bracket.
- D-1-17**: A small screw for the antenna bracket.
- D-1-18**: A small screw for the antenna bracket.
- D-1-19**: A small screw for the antenna bracket.
- D-1-20**: A small screw for the antenna bracket.
- D-1-21**: A small screw for the antenna bracket.
- D-1-22**: A small screw for the antenna bracket.
- D-1-23**: A small screw for the antenna bracket.
- D-1-24**: A small screw for the antenna bracket.

The diagram uses dashed lines to indicate the assembly path and the location of each component within the unit.

Note

D

D-2

This exploded view diagram illustrates the assembly of the D-2 engine. The main component is the engine block, which features two large circular openings on the front. Various parts are shown being assembled onto this block, with dashed lines indicating their relative positions and assembly paths. The components are labeled as follows:

- D-2-1**: A large cylindrical component, likely a cylinder head or a similar major assembly, shown being attached to the top of the engine block.
- D-2-2**: A small pin or clip used to secure the D-2-1 component.
- D-2-3**: A small circular component, possibly a gasket or a seal, located between the D-2-1 and the engine block.
- D-2-4**: A small pin or clip used to secure the D-2-3 component.
- D-2-5**: A small circular component, possibly a gasket or a seal, located between the D-2-1 and the engine block.
- D-2-6**: A small circular component, possibly a gasket or a seal, located between the D-2-1 and the engine block.
- D-2-7**: A small circular component, possibly a gasket or a seal, located between the D-2-1 and the engine block.
- D-2-8**: A long, thin cylindrical component, possibly a shaft or a rod, shown being inserted into the engine block.
- D-2-9**: A small circular component, possibly a gasket or a seal, located between the D-2-8 and the engine block.
- D-2-10**: A small circular component, possibly a gasket or a seal, located between the D-2-8 and the engine block.
- D-2-11**: A small circular component, possibly a gasket or a seal, located between the D-2-8 and the engine block.
- D-2-12**: A small circular component, possibly a gasket or a seal, located between the D-2-8 and the engine block.
- D-2-13**: A small circular component, possibly a gasket or a seal, located between the D-2-8 and the engine block.
- D-2-14**: A long, thin cylindrical component, possibly a shaft or a rod, shown being inserted into the engine block.
- D-2-15**: A small circular component, possibly a gasket or a seal, located between the D-2-14 and the engine block.
- D-2-16**: A small circular component, possibly a gasket or a seal, located between the D-2-14 and the engine block.
- D-2-17**: A small circular component, possibly a gasket or a seal, located between the D-2-14 and the engine block.
- D-2-18**: A small circular component, possibly a gasket or a seal, located between the D-2-14 and the engine block.

Note



D-3


The diagram illustrates the assembly of the D-3 unit. Key components and their connections are as follows:

- to joint b/d <cn7>**: Cable assembly **D-3-17** connects to the top of the main assembly.
- to joint b/d <cn3>**: Cable assembly **D-3-18** connects to the side of the main assembly.
- Left Sub-assembly**: Includes a threaded rod, a gear (D-3-12), a bracket (D-3-13), and a pin (D-3-14). The bracket is secured with a screw (D-3-15) and a washer (D-3-16).
- Right Sub-assembly**: Includes a motor (D-3-5), a circular plate (D-3-1), and a bracket (D-3-7). The motor is secured with a screw (D-3-2) and a washer (D-3-3). The bracket is secured with a screw (D-3-4) and a washer (D-3-11). The bracket is also secured with a screw (D-3-10) and a washer (D-3-9). The bracket is also secured with a screw (D-3-8).
- Other Components**: A gear (D-3-12) is shown at the bottom left. A screw (D-3-6) is shown on the right side of the main assembly.

Note

D

D-4



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
D-4-1	07021MP-T121	Lever Shaft Bush				12	
D-4-2	07023CW-T121	Lever Pin "A"				6	
D-4-3	02029SN-9311	Hex. Nut (M4-No2)			O	6	
D-4-4	03001100U000	Mes Driving Lever Shaft "A"				6	
D-4-5	02100400U000	Mes Driving Lever				6	
D-4-6	02015SC-7113	Hex.Socket Bolt(M4*L10)			O	6	
D-4-7	07006LA-UK01	Mes Connecting Link				6	
D-4-8	GP-006638-00	Moving Mes Shaft				6	
D-4-9	07028PR-T121	Moving Mes				6	
D-4-10	07032CL-T121	Fixed Mes				6	
D-4-11	07033PR-T121	Under Thread Presser				6	
D-4-12	07018SC-8118	Plus Screw (M3*L8)			O	12	
D-4-13	03050SC-4517	Hex. Socket Set Screw (M3*L3)			O	6	
D-4-14	08014SC-A001	Plus Screw (M3*L8)			O	6	
D-4-15	08122CW-A001	MES PIN				6	
D-4-16	08123CW-T121	MOVING MES CONNECTING LINK PIN				6	
D-4-17	13003000T000	Mes Shaft Collar				6	
D-4-18	03022SC-4517	Hex. Socket Set Screw (M4*L5)			O	12	
D-4-19	04026BR-A001	Ball Bearing 6003Z				6	
D-4-20	01102000B000	Bearing Bushing				6	
D-4-21	04016AF-A001	Cam Collar Screw			O	12	
D-4-22	GP-005357-00	Needle Plate Bracket	Nov,01,04 ~ Jun,12,05	X		6	
	GP-005357-01		Jun,13,05 ~ Dec,03,08	△		6	
	GP-005357-02		Dec,04,08 ~	△		6	
D-4-23	02009PI-T121	Spring Pin				12	
D-4-24	04026SC-T121	Needle Plate Pin				6	
D-4-25	GP-012800-00	Needle Plate Guide(L)				6	
D-4-26	GP-012801-00	Needle Plate Guide(R)				6	
D-4-27	04037SC-A001	Picker Bracket Screw(R)				12	
D-4-28	32047RB-T121	Oil Rubber Cap				6	
D-4-29	02019BM-T121	Needle Plate Set(Cap)				6	
D-4-30	02019PR-T121	Needle Plate(Cap)				6	
D-4-31	04007SC-A001	Cushion Cover Screw (M3*L2.3)				12	
D-4-32	GP-010385-00	NEEDLE GUIDE PLATE(FLAT)				6	
D-4-33	04004AF-A001	Needle Plate Screw				12	

D-5

(UH1208D,UH1512D)


D-5-11
D-5-13
D-5-12

D-5-2
D-5-3
D-5-4
D-5-5
D-5-6
D-5-7
D-5-8
D-5-9
D-5-10
D-5-7

Note

[illegible]

Main Drive System



E-1

This exploded view diagram illustrates the assembly of a mechanical component, likely a motor or actuator. The main assembly plate, E-1-1, is a rectangular plate with two circular cutouts. It is shown with various fasteners and sub-assemblies. E-1-19 is a bracket that fits into the top of E-1-1. E-1-2, E-1-3, and E-1-4 are a bolt, washer, and nut assembly that secures E-1-19. E-1-20, E-1-21, and E-1-22 are a bolt, washer, and nut assembly that secures E-1-1. E-1-7 is a screw that secures E-1-1. E-1-5 and E-1-6 are a bolt and nut assembly that secures E-1-1. E-1-15, E-1-16, and E-1-17 are a bolt, washer, and nut assembly that secures E-1-1. E-1-18 is a circular plate that fits into the bottom of E-1-1. E-1-14 is a circular plate that fits into the bottom of E-1-1. E-1-13 is a circular plate that fits into the bottom of E-1-1. E-1-12 is a screw that secures E-1-1. E-1-11 is a screw that secures E-1-1. E-1-10 is a screw that secures E-1-1. E-1-9 is a gear that fits into the bottom of E-1-1. E-1-8 is a U-shaped bracket that fits into the bottom of E-1-1. E-1-2 is a bolt that secures E-1-1. E-1-3 is a washer that secures E-1-1. E-1-4 is a nut that secures E-1-1. E-1-20 is a bolt that secures E-1-1. E-1-21 is a washer that secures E-1-1. E-1-22 is a nut that secures E-1-1. E-1-7 is a screw that secures E-1-1. E-1-5 is a bolt that secures E-1-1. E-1-6 is a nut that secures E-1-1. E-1-15 is a bolt that secures E-1-1. E-1-16 is a washer that secures E-1-1. E-1-17 is a nut that secures E-1-1. E-1-18 is a circular plate that fits into the bottom of E-1-1. E-1-14 is a circular plate that fits into the bottom of E-1-1. E-1-13 is a circular plate that fits into the bottom of E-1-1. E-1-12 is a screw that secures E-1-1. E-1-11 is a screw that secures E-1-1. E-1-10 is a screw that secures E-1-1. E-1-9 is a gear that fits into the bottom of E-1-1. E-1-8 is a U-shaped bracket that fits into the bottom of E-1-1.

Note

E

E-2

This exploded view diagram illustrates the assembly of the E-2 unit. The main components are shown in their relative positions, with dashed lines indicating the assembly path. The components are labeled as follows:

- E-2-1: Main housing or base unit.
- E-2-2: Gear or pulley component.
- E-2-3: Small pin or screw.
- E-2-4: Small pin or screw.
- E-2-5: Gear or pulley component.
- E-2-6: Small pin or screw.
- E-2-7: Flange or mounting plate.
- E-2-8: Small pin or screw.
- E-2-9: Long shaft or rod.
- E-2-10: Small pin or screw.
- E-2-11: Small pin or screw.
- E-2-12: Washer or spacer.
- E-2-13: Washer or spacer.
- E-2-14: Washer or spacer.
- E-2-15: Gear or pulley component.
- E-2-16: Small pin or screw.
- E-2-17: Long shaft or rod.
- E-2-18: Small pin or screw.
- E-2-19: Small pin or screw.
- E-2-20: Small pin or screw.
- E-2-21: Small pin or screw.
- E-2-22: Small pin or screw.
- E-2-23: Gear or pulley component.
- E-2-24: Small pin or screw.
- E-2-25: Small pin or screw.
- E-2-26: Small pin or screw.

Note

E

E-3

This exploded view diagram illustrates the assembly of a mechanical component, likely a door handle or latch. The components are labeled as follows:

- E-3-1**: Main mounting bracket.
- E-3-2**: Small pin or screw.
- E-3-3**: Small washer or spacer.
- E-3-4**: Small pin or screw.
- E-3-5**: Small pin or screw.
- E-3-6**: Small pin or screw.
- E-3-7**: Small pin or screw.
- E-3-8**: Small pin or screw.
- E-3-9**: Small pin or screw.
- E-3-10**: Small pin or screw.
- E-3-11**: Small pin or screw.
- E-3-12**: Small pin or screw.
- E-3-13**: Small pin or screw.
- E-3-14**: Large circular component, possibly a cam or wheel.
- E-3-15**: Small pin or screw.
- E-3-16**: Small pin or screw.
- E-3-17**: Small pin or screw.
- E-3-18**: Large, curved component, likely the handle or lever.
- E-3-19**: Small pin or screw.
- E-3-20**: Small pin or screw.
- E-3-21**: Small pin or screw.
- E-3-22**: Small pin or screw.

The diagram shows the assembly sequence from the main bracket (E-3-1) to the handle (E-3-18) and the internal mechanism (E-3-19, E-3-20, E-3-21, E-3-22). Dashed lines indicate the alignment and assembly path for each part.

Note

E

E-4

This exploded view diagram illustrates the assembly of the E-4 component. The parts are labeled as follows:

- E-4-1**: A large U-shaped bracket.
- E-4-2**: A long screw with a washer.
- E-4-3**: A small washer.
- E-4-4**: A small screw.
- E-4-5**: A vertical plate with two slots.
- E-4-6**: A small screw.
- E-4-7**: A small washer.
- E-4-8**: A small screw.
- E-4-9**: A small screw.
- E-4-10**: A small screw.
- E-4-11**: A pulley with a central shaft.
- E-4-12**: A long screw with a washer.
- E-4-13**: A small washer.
- E-4-14**: A small screw.


The diagram shows the following assembly steps:

- Attach **E-4-2** to the bottom of **E-4-1** using **E-4-3** and **E-4-4**.
- Attach **E-4-5** to the side of **E-4-1** using **E-4-6**, **E-4-7**, and **E-4-8**.
- Attach **E-4-9** to the side of **E-4-1**.
- Attach **E-4-10** to the side of **E-4-1**.
- Attach **E-4-11** to the top of **E-4-1** using **E-4-12** and **E-4-13**.
- Attach **E-4-14** to the top of **E-4-1**.


Note



E



Main Drive System 1




This exploded view diagram illustrates the assembly of a mechanical component, likely a door or panel. The main assembly is shown on the left, with various parts labeled with callouts. The components are as follows:

- E1-1-1**: A large, L-shaped metal bracket or frame.
- E1-1-2**: A small screw or bolt.
- E1-1-3**: A small screw or bolt.
- E1-1-4**: A small screw or bolt.
- E1-1-5**: A small screw or bolt.
- E1-1-6**: A small screw or bolt.
- E1-1-7**: A small screw or bolt.
- E1-1-8**: A long, curved metal strip or handle.
- E1-1-9**: A small screw or bolt.
- E1-1-10**: A small screw or bolt.
- E1-1-11**: A small screw or bolt.
- E1-1-12**: A small screw or bolt.
- E1-1-13**: A small screw or bolt.
- E1-1-14**: A small screw or bolt.
- E1-1-15**: A small screw or bolt.
- E1-1-16**: A small screw or bolt.
- E1-1-17**: A small screw or bolt.
- E1-1-18**: A small screw or bolt.
- E1-1-19**: A small screw or bolt.
- E1-1-20**: A small screw or bolt.
- E1-1-21**: A small screw or bolt.
- E1-1-22**: A small screw or bolt.

The diagram shows the assembly of the main bracket (E1-1-1) with various screws (E1-1-2 through E1-1-22) and a curved strip (E1-1-8). The assembly is shown in an exploded view, indicating the relative positions of the components.

[illegible]

E1-2



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
E1-2-1	03700300UH60	Mes Cam Driving Box C				1	
E1-2-2	13032GA-UK06	INDEX SHAFT GEAR UK06				1	
E1-2-3	04012AF-A001	HOOK SHAFT BUSH SCREW (15/64)			O	2	
E1-2-4	04026BR-A001	BALL BEARING 6003Z			O	1	
E1-2-5	01102000B000	COLLAR"B"				1	
E1-2-6	14060AF-4517	HEX.SOCKET SCREW(M6*L6)			O	2	
E1-2-7	04039PR-A001	BEARING COVER				1	
E1-2-8	13061SC-8119	PLUS SCREW (M3*L10)			O	3	
E1-2-9	03100710UH60	INDEX SHAFT B[551mm]				1	
E1-2-10	03704900A000	CAM SHAFT COLLAR				2	
E1-2-11	04016AF-A001	CAM COLLAR SCREW				4	
E1-2-12	08027BR-A001	THRUST BEARING (NTB 1528)			O	2	
E1-2-13	08028BR-A001	THRUST WASHER (AS 1528)				4	
E1-2-14	04027BR-A001	NEEDLE BEARING (HMK1515)			O	1	
E1-2-15	13032GA-UK06	INDEX SHAFT GEAR UK06				1	
E1-2-16	04012AF-A001	HOOK SHAFT BUSH SCREW (15/64)			O	2	
E1-2-17	GP-004942-00	LOW SHAFT B [902.5mm] UH1504D				1	
	03000410UH60	LOW SHAFT B [1302.5mm] UH1506D					
	GP-004154-00	LOW SHAFT B [1702.5mm] UH1208D					
	GP-005077-00	LOW SHAFT B [1302.5mm] UH1512D					
E1-2-18	13041SH-UK01	MIDDLE SHAFT				1	
E1-2-19	08053PR-A001	LEVER WASHER				4	
E1-2-20	02023SC-7113	HEX.SOCKET BOLT(M4*L8)			O	2	
E1-2-21	18014SW-3115	SPRING WASHER (@4-NO2)			O	2	
E1-2-22	18015SW-3111	WASHER (4@)			O	2	
E1-2-23	13034GA-UK06	MIDDLE SHAFT GEAR UK06				1	
	13036BR-UK01	MIDDLE SHAFT GEAR NEEDLE BEARING (@10-@19)NNB				4	
E1-2-24	12019BR-T121	FIBER WASHER R-TW1020			O	4	
E1-2-25	13038CW-UK01	COLLAR				2	
E1-2-26	03022SC-4517	HEX. SOCKET SET SCREW(M4*L5)				4	

Note

E

E1-4

This exploded view diagram illustrates the assembly of the E1-4 component. The main structure is a rectangular frame with a central opening. The assembly process is indicated by numbered callouts and dashed lines showing the placement of parts:

- E1-4-1**: A vertical plate that fits into the left side of the frame.
- E1-4-2**, **E1-4-3**, and **E1-4-4**: Screws used to secure the left side plate.
- E1-4-5**: A large U-shaped bracket that fits into the bottom of the frame.
- E1-4-6**, **E1-4-7**, and **E1-4-8**: Screws used to secure the bottom bracket.
- E1-4-9**: A long screw used to secure the bottom bracket to the frame.
- E1-4-10**: A small plate that fits into the bottom of the frame.
- E1-4-11**: A circular component that fits into the right side of the frame.
- E1-4-12**: A long screw used to secure the circular component.
- E1-4-13**: A small plate that fits into the right side of the frame.
- E1-4-14**: A small plate that fits into the right side of the frame.

Note	
-------------	--



E1-5

This diagram illustrates the assembly of the E1-5 unit. The components are labeled as follows:


- E1-5-1**: Main unit housing.
- E1-5-2**, **E1-5-3**, **E1-5-4**: Screws for the top cover.
- E1-5-5**: Mounting plate.
- E1-5-6**, **E1-5-7**, **E1-5-8**: Screws for the mounting plate.
- E1-5-9**: Cable connector.
- E1-5-10**: Cable connector.
- E1-5-11**: Cable connector.
- E1-5-12**, **E1-5-13**, **E1-5-14**: Screws for the mounting plate.
- E1-5-15**: Mounting bracket.
- E1-5-16**, **E1-5-17**, **E1-5-18**: Screws for the mounting bracket.
- E1-5-19**: Cable for the control box.
- E1-5-20**: Cable for the control box.

Labels for the control box are shown as "to con. box".


Note



Head & Color Change



F-1



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
F-1-1	GP-007360-00	Head (9C)	Jan,28,05 ~ Nov,12,06	X		6	
	GP-007360-01		Nov,13,06 ~ Mar,25,07	△			
	GP-007360-02		Mar,26,07 ~ Dec,13,07	△			
	GP-007360-03		Dec,14,07 ~	△			
	GP-007361-00	Head (12C)	Jan,28,05 ~ Nov,12,06	X			
	GP-007361-01		Nov,13,06 ~ Mar,25,07	△			
	GP-007361-02		Mar,26,07 ~ Dec,13,07	△			
	GP-007361-03		Dec,14,07 ~	△			
	GP-007362-00	Head (15C)	Jan,28,05 ~ Nov,12,06	X			
	GP-007362-01		Nov,13,06 ~ Mar,25,07	△			
	GP-007362-02		Mar,26,07 ~ Dec,13,07	△			
	GP-007362-03		Dec,14,07 ~	△			
F-1-2	05008SC-4113	Hex.Socket Bolt (M4*L16)			O	24	
F-1-3	06003SW-2111	Washer (@4)			O	24	
F-1-4	08201303I000	Head Rail 9C				6	
F-1-5	04023MC-4113	Hex. Socket Bolt (M4*L23)			O	24	
F-1-6	05015CW-A001	Head Base Pin(@5*L15)				12	
F-1-7	03022SC-4517	Hex. Socket Set Screw(M4*L5)			O	12	
F-1-8	05018CW-A001	Needle Bar				54	
F-1-9	05019SC-A001	Needle Bar Cover Screw (M5*L6)			O	54	
F-1-10	08200700H000	Needle Bar Felt				36	
F-1-11	05023RB-A001	Needle Bar Cushion Rubber "A"				36	
F-1-12	05024RB-A001	Needle Bar Cushion Rubber "B"				54	
F-1-13	11101200T000	Upper Dead Point Stopper				54	
F-1-14	05026SC-4113	Stopper Screw (9/64-11.5)			O	54	
F-1-15	08201400H000	Needle Bar Holder				54	
F-1-16	05028SC-4113	Holder Screw (9/64-L8)			O	54	
F-1-17	05021PM-H001	Presser Foot Spring Guide				108	
F-1-18	08201000I000	Needle Bar Return Spring				54	
F-1-19	08200500I000	PRESSER FOOT				54	
	GP-006119-00	PRESSER FOOT (L)				54	
F-1-20	08200900I000	Presser Foot Holder A'ssy				54	
F-1-21	05026SC-H001	Presser Foot Bolt				54	
F-1-22	05027PR-H001	PRESSER FOOT HOLDER WASHER				54	
F-1-23	GP-007216-00	Needle Bar Return Spring	Jan,28,05 ~ Nov,12,06	X		54	
	GP-007216-01		Nov,13,06 ~	△			
F-1-24	05022SW-A001	Spring Shoe Washer				54	
F-1-25	08201200H000	Presser Foot Cushion Rubber A				54	


This exploded view diagram illustrates the assembly of the front panel for a washing machine. The components are labeled with part numbers and their assembly sequence:

- Top Section:**
 - F-1-9:** A long vertical rod at the top.
 - F-1-8:** A small component below F-1-9.
 - F-1-18:** A small circular component below F-1-8.
 - F-1-24:** A small circular component below F-1-18.
- Panel Frame and Mounting:**
 - F-1-10:** A horizontal mounting rail.
 - F-1-11:** Two horizontal mounting rails.
 - F-1-12:** A horizontal mounting rail.
 - F-1-3:** A small circular component.
 - F-1-14:** A small circular component.
 - F-1-15:** A small circular component.
 - F-1-16:** A small circular component.
 - F-1-17:** A small circular component.
 - F-1-23:** A small circular component.
 - F-1-17:** A small circular component.
 - F-1-20:** A small circular component.
 - F-1-22:** A small circular component.
 - F-1-21:** A small circular component.
 - F-1-10:** A horizontal mounting rail.
- Internal Components and Fasteners:**
 - F-1-6:** A vertical component.
 - F-1-1:** The main panel frame.
 - F-1-31:** A vertical component.
 - F-1-7:** A small circular component.
 - F-1-2:** A small circular component.
 - F-1-3:** A small circular component.
 - F-1-30:** A small circular component.
 - F-1-4:** A horizontal component.
 - F-1-25:** A small circular component.
 - F-1-26:** A small circular component.
 - F-1-5:** A small circular component.
 - F-1-27:** A small circular component.
 - F-1-28:** A small circular component.
- Bottom Section:**
 - F-1-19:** Two L-shaped components.
 - F-1-29:** A small circular component.
 - F-1-19:** Two L-shaped components.

[illegible]

46

F-2



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
F-2-1	10200103B000	Head Face Plate (U) 9C				6	
F-2-2	10200100H000	Thread Guide Bush "A-1"				54	
F-2-3	05070SC-3123	Head Face Plate (U) Screw			O	24	
F-2-4	10300003A000	Thread Guide (M) Set (9C)				6	
	10300004A000	Thread Guide (M) Set (12C)					
	10300005A000	Thread Guide (M) Set (15C)					
F-2-5	GP-033547-00	Thread Guide (M)				6	
	GP-033548-00	Thread Guide (M) (12C)					
	GP-033549-00	Thread Guide (M) (15C)					
F-2-6	05452CM-A001	Eyelet "A"				54	
F-2-7	05483CM-A001	Eyelet "B" (9C)				36	
	10110000A000	Eyelet "B" (12C)				54	
F-2-7	05483CM-A001	Eyelet "B"				72	
F-2-8	05062SC-A001	Thread Guide (M) Screw (9/64 n=40)				6	
F-2-9	12001703I000	Head Face Plate(L) (9C)				6	
	12001704I000	Head Face Plate(L) (12C)					
F-2-10	11012PR-B001	Thread Guide				54	
F-2-11	09005SC-3123	Truss Bolt (M3*L5)			O	54	
F-2-12	05070SC-3123	Head Face Plate (U) Screw			O	12	
F-2-13	10900003I000	Thread Holding Device A'ssy				6	
F-2-14	05070SC-3123	Truss Bolt 9/64 n=40			O	12	
F-2-15	GP-008540-00	Needle Bar Guide Rail (9C)				6	
	GP-008541-00	Needle Bar Guide Rail (12C)					
	GP-008542-00	Needle Bar Guide Rail (15C)					
F-2-16	05041SC-A001	Bolt (9/64 n=40)				30	
F-2-17	08200503A000	Take-Up Lever Shaft (9C)				6	
F-2-18	02015SC-7113	Hex.Socket Bolt(M4*L8)			O	24	
F-2-19	08004900A000	Color Change Bracket "B"				5	
F-2-20	GP-004943-00	Head Transportation Shaft UH1504D				2	
	06000114UH60	Head Transportation Shaft UH1506D					
	GP-005043-00	UPPER THREAD HOOK DRIVING SHAF UH1208D					
	GP-005089-00	UPPER THREAD DRIVING SHAFT UH912D	Oct,06,04 ~ Jan,26,05	X			
	GP-005089-01		Jan,26,05 ~	△			
F-2-20	06000105UH60	UPPER THREAD DRIVING SHAFT A UH1512D					
F-2-21	07005BM-B002	Take-Up Lever Set				54	
F-2-22	08203000A000	Take-Up Lever Shaft Bush(L)				6	
F-2-23	08200800A000	Take-Up Lever Shaft Bush(R)				6	
F-2-24	11047PR-A002	Cable Support "B"				6	

F-2

This exploded view diagram illustrates the assembly of the F-2 antenna. The components are labeled as follows:

- F-2-1**: Main antenna housing with vertical slots.
- F-2-2**: Small mounting pin.
- F-2-3**: Small mounting pin.
- F-2-4**: Mounting bracket for the main housing.
- F-2-5**: Mounting bracket for the main housing.
- F-2-6**: Mounting bracket for the main housing.
- F-2-7**: Mounting bracket for the main housing.
- F-2-8**: Mounting bracket for the main housing.
- F-2-9**: Mounting bracket for the main housing.
- F-2-10**: Mounting bracket for the main housing.
- F-2-11**: Mounting bracket for the main housing.
- F-2-12**: Mounting bracket for the main housing.
- F-2-13**: Mounting bracket for the main housing.
- F-2-14**: Mounting bracket for the main housing.
- F-2-15**: Mounting bracket for the main housing.
- F-2-16**: Mounting bracket for the main housing.
- F-2-17**: Mounting bracket for the main housing.
- F-2-18**: Mounting bracket for the main housing.
- F-2-19**: Mounting bracket for the main housing.
- F-2-20**: Mounting bracket for the main housing.
- F-2-21**: Mounting bracket for the main housing.
- F-2-22**: Mounting bracket for the main housing.
- F-2-23**: Mounting bracket for the main housing.
- F-2-24**: Mounting bracket for the main housing.
- F-2-25**: Mounting bracket for the main housing.

Note

F

F-3

The diagram illustrates the assembly of the F-3 component. Key parts and their assembly sequence are as follows:

- F-3-1**: Main housing or frame.
- F-3-2, F-3-3, F-3-4**: Screws used to secure the main housing.
- F-3-5, F-3-6, F-3-7, F-3-8, F-3-9**: Components of the internal assembly, including a flange and a shaft.
- F-3-10, F-3-11, F-3-12, F-3-13, F-3-14**: Components of the internal assembly, including a flange and a shaft.
- F-3-15, F-3-16**: A cylindrical component, likely a motor or actuator, which is the final assembly.
- F-3-17, F-3-18, F-3-19**: Components of the internal assembly, including a flange and a shaft.
- F-3-20, F-3-21, F-3-22, F-3-23, F-3-24, F-3-25**: Components of the internal assembly, including a flange and a shaft.

The diagram also includes a note: "To Joint B/D <CN5>" pointing to the F-3-19 component.

Note



F-4


The diagram illustrates the assembly of the F-4 unit. It shows three main components: a motor assembly (top left), a control box (top right), and a main unit (bottom). The motor assembly includes a motor (F-4-14) connected to a cable (F-4-13) which is labeled "To Joint B/D <CN1>". The control box (F-4-16) has two screws (F-4-17) and a cable (F-4-15) labeled "To Joint b/d <CN2>". The main unit (F-4-1) is shown in a dashed outline, indicating its internal structure. It includes a motor (F-4-8) connected to a cable (F-4-7) which is labeled "To Joint B/D <CN1>". The main unit also has a cable (F-4-26) labeled "To Joint b/d <CN2>". Various other components are labeled, including F-4-10, F-4-11, F-4-12, F-4-13, F-4-14, F-4-15, F-4-16, F-4-17, F-4-18, F-4-19, F-4-20, F-4-21, F-4-22, F-4-23, F-4-24, F-4-25, F-4-26, F-4-27, F-4-28, F-4-29, F-4-30, F-4-31, F-4-32, F-4-33, F-4-34, F-4-35, F-4-36, F-4-37, F-4-38, F-4-39, F-4-40, F-4-41, F-4-42, F-4-43, F-4-44, F-4-45, F-4-46, F-4-47, F-4-48, F-4-49, F-4-50, F-4-51, F-4-52, F-4-53, F-4-54, F-4-55, F-4-56, F-4-57, F-4-58, F-4-59, F-4-60, F-4-61, F-4-62, F-4-63, F-4-64, F-4-65, F-4-66, F-4-67, F-4-68, F-4-69, F-4-70, F-4-71, F-4-72, F-4-73, F-4-74, F-4-75, F-4-76, F-4-77, F-4-78, F-4-79, F-4-80, F-4-81, F-4-82, F-4-83, F-4-84, F-4-85, F-4-86, F-4-87, F-4-88, F-4-89, F-4-90, F-4-91, F-4-92, F-4-93, F-4-94, F-4-95, F-4-96, F-4-97, F-4-98, F-4-99, F-4-100.

Note	
-------------	--

F

Thread Tension Unit

G-2




G

G-2

This exploded view diagram illustrates the assembly of the G-2 unit. The components are labeled as follows:


- G-2-1:** A large circular component, likely a lens or filter, shown being inserted into the front panel.
- G-2-2:** The front panel, which features a grid of circular openings.
- G-2-3:** A long, narrow component, possibly a filter or a support structure, shown being inserted into the front panel.
- G-2-4:** A small circular component, likely a screw or cap, shown being inserted into the front panel.
- G-2-5:** A small circular component, likely a screw or cap, shown being inserted into the front panel.
- G-2-6:** A small circular component, likely a screw or cap, shown being inserted into the front panel.
- G-2-7:** A small component, likely a screw or cap, shown being inserted into the front panel.
- G-2-8:** A small component, likely a screw or cap, shown being inserted into the front panel.
- G-2-9:** A small component, likely a screw or cap, shown being inserted into the front panel.
- G-2-10:** A small component, likely a screw or cap, shown being inserted into the front panel.
- G-2-11:** A small component, likely a screw or cap, shown being inserted into the front panel.
- G-2-12:** A small component, likely a screw or cap, shown being inserted into the front panel.
- G-2-13:** A small component, likely a screw or cap, shown being inserted into the front panel.
- G-2-14:** A small component, likely a screw or cap, shown being inserted into the front panel.
- G-2-15:** A small component, likely a screw or cap, shown being inserted into the front panel.
- G-2-16:** A small component, likely a screw or cap, shown being inserted into the front panel.
- G-2-17:** A small component, likely a screw or cap, shown being inserted into the front panel.

Note


[illegible]

G

X-Y Drive (UH1504D-45)



H1-1



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
H1-1-1	GP-004930-00	Y-LM Guide Frame L620	Sep,25,04 ~ Mar,12,06	X		4	
	GP-004930-01		Mar,13,06 ~	△			
H1-1-2	04016MC-4113	CAM ROLLER GUIDE FIXED SCREW				56	
H1-1-3	02033SC-4113	Hex. Socket Bolt			O	16	
H1-1-4	03003SC-4113	Hex. Socket Bolt "B" (M8*L35)			O	12	
H1-1-5	15095SW-3115	Spring Washer (@8)			O	28	
H1-1-6	16074PR-UK06	Y-Lm Support Fixing Plate				2	
H1-1-7	14002SC-7113	Hex.Socket Bolt (M6*L15)			O	8	
H1-1-8	16014SW-4115	Spring Washer (@6)			O	8	
H1-1-9	08057SW-1111	Washer (@6)			O	8	
H1-1-10	03016SC-4113	Hex. Socket Bolt (M5*L15)			O	8	
H1-1-11	18048SW-3115	Spring Washer (@5)			O	8	
H1-1-12	16018SW-1111	Washer (@5)			O	8	
H1-1-13	03101300UH00	Sensor Bracket				1	
H1-1-14	03101300UH00	Sensor Bracket				1	
H1-1-15	02015SC-7113	Hex.Socket Bolt(M4*L10)			O	4	
H1-1-16	02028SW-9115	Spring Washer (@4)			O	4	
H1-1-17	05009SW-1111	Washer (@4-L)			O	4	
H1-1-18	02107300UH80	Cable (Sh-73)				2	
H1-1-19	06010SC-8118	Plus Screw (M3*L4)			O	4	
H1-1-20	03100600UH00	Tension Adjusting Plate				4	
H1-1-21	07016SC-7113	Hex.Socket Bolt (M4*L12)			O	8	
H1-1-22	18014SW-3115	Spring Washer (@4-No2)			O	8	
H1-1-23	18015SW-3111	Washer (4@)			O	16	
H1-1-24	03100700UH00	Fixed Block				4	
H1-1-25	11029SC-4113	Hex. Socket Bolt (M4*L20)			O	4	
H1-1-26	18014SW-3115	Spring Washer (@4-No2)			O	4	
H1-1-27	18015SW-3111	Washer (4@)			O	4	
H1-1-28	15030SC-7113	Hex. Socket Bolt (M5*L30)			O	4	
H1-1-29	18048SW-3115	Spring Washer (@5)			O	4	
H1-1-30	16018SW-1111	Washer (@5)			O	4	
H1-1-31	03100500UH00	Y-Tension Adjusting Bracket			O	4	
H1-1-32	08007SC-4517	Hex. Socket Set Screw (M3*L5)				8	
H1-1-33	04500100U000	Y-Drive Timing Pulley			O	4	
H1-1-34	12018BR-T121	Needle Bearing Hk1010(Ina)				8	
H1-1-35	12019BR-T121	Fiber Washer R-Tw1020				8	
H1-1-36	16100CW-UK06	Timing Pulley Shaft (Y)				4	
H1-1-37	08062SC-7113	Hex. Socket Bolt (M5*L20)				8	



H1-2

The diagram illustrates the assembly of the H1-2 unit. The main components and their assembly sequence are as follows:

- H1-2-1**: The central motor or actuator unit.
- H1-2-2**, **H1-2-3**, and **H1-2-4**: Screws used to secure the front plate (**H1-2-1**) to the motor.
- H1-2-5**: A mounting bracket that is attached to the side of the motor.
- H1-2-6**, **H1-2-7**, and **H1-2-8**: Screws used to secure the mounting bracket to the wall or structure.
- H1-2-9**: A cable or hose that connects the motor to the control unit.
- H1-2-10**: A connector or plug that fits into the end of the cable/hose.
- H1-2-11**: A long, thin rod or shaft that passes through the motor and the mounting bracket.
- H1-2-12**: A nut or washer that secures the rod to the mounting bracket.
- H1-2-13**: A small screw or pin that secures the rod to the motor.
- H1-2-14**: A long, thin rod or shaft that passes through the motor and the mounting bracket.
- H1-2-15**: A cable or hose that connects the motor to the control unit.

Note




Exploded view diagram of the H1-3 assembly, showing the following components and their assembly order:

- H1-3-9, H1-3-10, H1-3-11 (Screws for the top plate)
- H1-3-8 (Top plate)
- H1-3-5, H1-3-6, H1-3-7 (Screws for the side plate)
- H1-3-4 (Side plate)
- H1-3-14, H1-3-15, H1-3-17 (Screws for the bottom plate)
- H1-3-12 (Bottom plate)
- H1-3-11, H1-3-13, H1-3-18, H1-3-16 (Screws for the bottom plate)
- H1-3-2 (Screw for the side plate)
- H1-3-1 (Side plate)
- H1-3-3 (Bottom plate)



H1-4



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
H1-4-1	14045AD-UK01	Belt Bracket (B)				2	
H1-4-2	14049AD-UK01	Belt Bracket (C)				2	
H1-4-3	15034SC-4113	Hex. Socket Bolt (M4*L45)			O	2	
H1-4-4	18015SW-3111	Washer (@4)			O	4	
H1-4-5	12048BT-T121	X-Axis Timing Belt				2	
H1-4-6	14051PR-UK01	Fixing Plate				8	
H1-4-7	14052PR-UK01	Fixing Plate Holder				8	
H1-4-8	03071SC-7113	HEX. SOCKET BOLT (M3*L10)			O	16	
H1-4-9	11019SW-9115	Spring Washer (3@)			O	16	
H1-4-10	08011SW-1111	Spring Washer (@3-S)			O	16	
H1-4-11	12017PU-T121	Timing Pulley "A"				4	
	12018BR-T121	Needle Bearing Hk1010(Ina)			O	8	
H1-4-12	12019BR-T121	Fiber Washer R-Tw1020				8	
H1-4-13	03106000U000	Timing Pulley Driving Pin				4	
H1-4-14	15048SC-4119	Plus Screw (M5*L12)			O	4	
H1-4-15	08044SR-4013	E-Ring (@8)			O	4	
H1-4-16	05100100T000	X-Motor (103H7126-2851)				4	
H1-4-17	08076SC-7113	Hex. Socket Bolt (M5*L12)			O	16	
H1-4-18	18048SW-3115	Spring Washer (@5)			O	16	
H1-4-19	16018SW-1111	Washer (@5)			O	16	
H1-4-20	15059PR-UK02	X-Motor Space				16	
H1-4-21	15061PR-UK02	X-Motor Base(R)				2	
H1-4-22	15060PR-UK02	X-Motor Base(L)				2	
H1-4-23	15053SC-4119	Plus Screw (M5*L30)			O	8	
H1-4-24	14067AD-UK01	Motor Fixing Shaft (B)				4	
H1-4-25	15055SC-4119	Plus Screw (M5*L35)			O	4	
H1-4-26	14063PU-UK01	Timing Pulley "B"				4	
H1-4-27	04014SC-4517	Hex.Socket Set Screw(M5*L5)			O	8	
H1-4-28	14065AD-UK01	Motor Fixing Shaft (A)				8	
H1-4-29	03000100U020	X-Motor Fixing Block				4	
H1-4-30	08076SC-7113	Hex. Socket Bolt (M5*L12)			O	8	
H1-4-31	18048SW-3115	Spring Washer (@5)			O	8	
H1-4-32	15077BR-A001	Ball Bearing (698Zz)			O	4	
H1-4-33	15044EL-T121	Bid (S)				4	
H1-4-34	15045EL-UK01	Bid (L)				2	
H1-4-35	25013EL-UK02	X-Step Motor Driving Power 3				2	
H1-4-36	25019EL-T121	Power Cable 2 (1Ht-19)				2	
H1-4-37	02101300U040	X-Step Motor Driving Power				2	

Note



H1-6

This exploded view diagram illustrates the assembly of the H1-6 lighting fixture. The main components are labeled as follows:


- H1-6-1**: The main body of the fixture, shown in a perspective view.
- H1-6-2**: A long, thin, rectangular component, likely a reflector or diffuser, positioned below the main body.
- H1-6-3**: A long, thin, rectangular component, likely a reflector or diffuser, positioned below the main body.
- H1-6-4**: A long, thin, rectangular component, likely a reflector or diffuser, positioned below the main body.
- H1-6-5**: A small, rectangular component, likely a mounting bracket or connector, positioned at the bottom of the main body.
- H1-6-6**: A small, rectangular component, likely a mounting bracket or connector, positioned at the bottom of the main body.
- H1-6-7**: A small, rectangular component, likely a mounting bracket or connector, positioned at the bottom of the main body.
- H1-6-8**: A small, rectangular component, likely a mounting bracket or connector, positioned at the bottom of the main body.
- H1-6-9**: A small, rectangular component, likely a mounting bracket or connector, positioned at the bottom of the main body.
- H1-6-10**: A small, rectangular component, likely a mounting bracket or connector, positioned at the bottom of the main body.
- H1-6-11**: A small, rectangular component, likely a mounting bracket or connector, positioned at the bottom of the main body.
- H1-6-12**: A small, rectangular component, likely a mounting bracket or connector, positioned at the bottom of the main body.
- H1-6-13**: A small, rectangular component, likely a mounting bracket or connector, positioned at the bottom of the main body.
- H1-6-14**: A small, rectangular component, likely a mounting bracket or connector, positioned at the bottom of the main body.
- H1-6-15**: A small, rectangular component, likely a mounting bracket or connector, positioned at the bottom of the main body.
- H1-6-16**: A small, rectangular component, likely a mounting bracket or connector, positioned at the bottom of the main body.
- H1-6-17**: A small, rectangular component, likely a mounting bracket or connector, positioned at the bottom of the main body.

The diagram shows the assembly of the fixture, with the main body (H1-6-1) being the central component. The other components are shown in their relative positions, indicating how they fit together. The components are labeled with their respective part numbers, which are listed in the table below.


Part Number	Description
H1-6-1	Main body of the fixture
H1-6-2	Reflector/diffuser
H1-6-3	Reflector/diffuser
H1-6-4	Reflector/diffuser
H1-6-5	Mounting bracket/connector
H1-6-6	Mounting bracket/connector
H1-6-7	Mounting bracket/connector
H1-6-8	Mounting bracket/connector
H1-6-9	Mounting bracket/connector
H1-6-10	Mounting bracket/connector
H1-6-11	Mounting bracket/connector
H1-6-12	Mounting bracket/connector
H1-6-13	Mounting bracket/connector
H1-6-14	Mounting bracket/connector
H1-6-15	Mounting bracket/connector
H1-6-16	Mounting bracket/connector
H1-6-17	Mounting bracket/connector

Note

X-Y Drive (UH1506D-45)



H2-1



Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
H2-1-1	03003000UH60	Y-LM Guide Frame L620				4	
H2-1-2	14027SC-4113	Hex. Socket Bolt			O	16	
H2-1-3	03003SC-4113	Hex. Socket Bolt "B" (M8*L35)			O	12	
H2-1-4	15095SW-3115	Spring Washer (@8)			O	28	
H2-1-5	04029SW-A001	Stud Bolt Washer(S) (@8)			O	28	
H2-1-6	16074PR-UK06	Y-Lm Support Fixing Plate				2	
H2-1-7	14006SC-7113	Hex.Socket Bolt (M8*L15)			O	8	
H2-1-8	15095SW-3115	Spring Washer (@6)			O	8	
H2-1-9	08041SW-1111	Washer (@6)			O	8	
H2-1-10	08076SC-7113	Hex. Socket Bolt (M5*L15)			O	8	
H2-1-11	18048SW-3115	Spring Washer (@5)			O	8	
H2-1-12	16018SW-1111	Washer (@5)			O	8	
H2-1-13	03101300UH00	Bracket for Y-Sensor				2	
H2-1-14	03101300UH00	Bracket for Y-Sensor				2	
H2-1-15	02015SC-7113	Hex.Socket Bolt(M4*L10)			O	4	
H2-1-16	02028SW-9115	Spring Washer (@4)			O	4	
H2-1-17	05009SW-1111	Washer (@4-L)			O	4	
H2-1-18	09018EL-UK01	Sensor				2	
H2-1-19	08006SC-8118	Plus Screw (M3*L5)			O	4	
H2-1-20	03100600UH00	Tension Adjusting Plate				4	
H2-1-21	07016SC-7113	Hex.Socket Bolt (M4*L12)			O	8	
H2-1-22	18014SW-3115	Spring Washer (@4-No2)			O	8	
H2-1-23	18015SW-3111	Washer (4@)			O	16	
H2-1-24	03100700UH00	Fixed Block				4	
H2-1-25	11029SC-4113	Hex. Socket Bolt (M4*L20)			O	4	
H2-1-26	18014SW-3115	Spring Washer (@4-No2)			O	4	
H2-1-27	18015SW-3111	Washer (4@)			O	4	
H2-1-28	16028SC-7113	Hex. Socket Bolt (M5*L25)			O	4	
H2-1-29	18048SW-3115	Spring Washer (@5)			O	4	
H2-1-30	16018SW-1111	Washer (@5)			O	4	
H2-1-31	03100500UH00	Y-Tension Adjusting Bracket				4	
H2-1-32	08007SC-4517	Hex. Socket Set Screw (M3*L5)			O	8	
H2-1-33	03003400UH60	Y-Drive Timing Pulley				4	
H2-1-34	12018BR-T121	Needle Bearing Hk1010(Ina)				8	
H2-1-35	12019BR-T121	Fiber Washer R-Tw1020				8	
H2-1-36	16100CW-UK06	Timing Pulley Shaft (Y)				4	
H2-1-37	08062SC-7113	Hex. Socket Bolt (M5*L20)			O	8	


Note

H2

Note	
------	--

H2

H2-2



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
H2-2-1	16059MT-E131	Y Motor (103H89222-5212)				2	
H2-2-2	14046SC-7113	Hex.Socket Bolt (M6*L30)			O	8	
H2-2-3	16014SW-4115	Spring Washer (@6)			O	8	
H2-2-4	08057SW-1111	Washer (@6)			O	8	
H2-2-5	GP-007511-00	Y-Driving Box				1	
H2-2-6	14002SC-7113	Hex. Socket Bolt (M6*L15)			O	1	
H2-2-7	16014SW-4115	Spring Washer (@6)			O	5	
H2-2-8	08057SW-1111	Washer			O	5	
H2-2-9	01029BR-A001	Bearing(6004zz)			O	3	
H2-2-10	14058CW-A001	Bearing Stopper Collar				3	
H2-2-11	04012AF-A001	Screw(15/64-28)				8	
H2-2-12	GP-007517-00	Y-Driving Shaft "C"	UH1506D			2	
	03100800UH60	Y-Driving Shaft "C"	UH1208D			2	
H2-2-13	GP-007516-00	Y-Driving Shaft "B"	UH1506D			2	
	GP-004159-00	Y-Driving Shaft	UH1208D	Aug,24,04 ~ Apr,26,05	X	2	
	GP-004159-01		Apr,27,05 ~	△		2	
H2-2-14	03003800B000	Coupling				4	
H2-2-15	08091SC-7113	Hex. Socket Bolt (M6*L20)			O	16	
H2-2-16	03200200B000	Lower Shaft Timing Pulley				1	
H2-2-17	14061AF-4517	Hex. Socket Bolt (M8*L8)			O	2	
H2-2-18	BE-000023-00	Y-Driving Timing Belt				1	
H2-2-19	GP-007515-00	Y-Driving Box Driven Shaft				2	
H2-2-20	03005100U000	Coupling "A"				4	
H2-2-21	GP-005380-00	Coupling				1	
H2-2-22	GP-044367-00	Y-Driving Timing Pulley	Dec,02,08 ~	X		1	
	GP-044367-01		Jul,05,10 ~	△		1	
H2-2-23	GP-005379-00	Tension Adjusting Roller				1	
H2-2-24	03200400I000	Roller Bearing				2	
H2-2-25	GP-005378-00	Idler Bush				1	
H2-2-26	03200700I000	C-Ring				1	
H2-2-27	14060AF-4517	Hex. Socket Bolt (M6*L6)			O	1	
H2-2-28	GP-007512-00	Idler Shaft	Feb,05,05 ~ Dec,17,08	X		1	
	GP-007512-01		Dec,18,08 ~	△		1	
H2-2-29	GP-007513-00	Y-Driving Box Bracket				2	
H2-2-30	03003SC-4113	Hex. Socket Bolt "B"(M8*L35)			O	8	
H2-2-31	15095SW-3115	Spring Washer (@8)			O	8	
H2-2-32	04029SW-A001	Stud Bolt Washer(S) (@8)			O	8	
H2-2-33	GP-005374-00	Y-Driving Box CoverA				2	
H2-2-34	AS-002867-00	Y-Driving Box Assy	May,17,05 ~	X		2	

H2

H2-3

The diagram illustrates the assembly of the H2-3 unit. The components and their assembly sequence are as follows:

- H2-3-1**: The main base rail.
- H2-3-2**: A long, thin component that fits into the base rail.
- H2-3-3**: A long, thin component that fits into the base rail.
- H2-3-4**: A bracket that fits into the base rail.
- H2-3-5**: A screw that secures the bracket.
- H2-3-6**: A screw that secures the bracket.
- H2-3-7**: A screw that secures the bracket.
- H2-3-8**: A bracket that fits into the base rail.
- H2-3-9**: A screw that secures the bracket.
- H2-3-10**: A screw that secures the bracket.
- H2-3-11**: A screw that secures the bracket.
- H2-3-12**: A small component that fits into the base rail.
- H2-3-13**: A small component that fits into the base rail.
- H2-3-14**: A small component that fits into the base rail.
- H2-3-15**: A small component that fits into the base rail.
- H2-3-16**: A small component that fits into the base rail.
- H2-3-17**: A small component that fits into the base rail.
- H2-3-18**: A small component that fits into the base rail.
- H2-3-19**: A small component that fits into the base rail.

Note

H2

H2-4

Note

H2-5

The diagram illustrates the assembly of the H2-5 system. The main component is a long, thin rail (H2-5-1) with several mounting brackets and plates. The assembly steps are indicated by dashed lines and labels:

- H2-5-1**: The main rail.
- H2-5-2**: A small screw used to secure the rail.
- H2-5-3**: A mounting bracket attached to the rail.
- H2-5-4**, **H2-5-5**, **H2-5-6**: Screws used to secure the bracket.
- H2-5-7**: A mounting bracket attached to the rail.
- H2-5-8**: A mounting plate attached to the rail.
- H2-5-9**: A mounting plate attached to the rail.
- H2-5-10**, **H2-5-11**, **H2-5-12**: Screws used to secure the plates.
- H2-5-13**: A mounting bracket attached to the rail.
- H2-5-14**: A mounting plate attached to the rail.
- H2-5-15**: A mounting plate attached to the rail.
- H2-5-16**, **H2-5-17**: Screws used to secure the plates.
- H2-5-18**: A screw used to secure the rail.

Note

H2


H2-6

This exploded view diagram illustrates the assembly of the H2-6 lighting fixture. The components are labeled as follows:


- H2-6-1**: Main fixture body.
- H2-6-2**: Mounting bracket.
- H2-6-3**: Lens cover.
- H2-6-4**: Lens cover gasket.
- H2-6-5**: Mounting screw.
- H2-6-6**: Mounting screw.
- H2-6-7**: Mounting screw.
- H2-6-8**: Mounting screw.
- H2-6-9**: Mounting screw.
- H2-6-10**: Mounting screw.
- H2-6-11**: Mounting screw.
- H2-6-12**: Mounting screw.
- H2-6-13**: Mounting screw.
- H2-6-14**: Mounting screw.
- H2-6-15**: Mounting screw.
- H2-6-16**: Mounting screw.
- H2-6-17**: Mounting screw.
- H2-6-18**: Mounting screw.
- H2-6-19**: Mounting screw.
- H2-6-20**: Mounting screw.
- H2-6-21**: Mounting screw.
- H2-6-22**: Mounting screw.
- H2-6-23**: Mounting screw.
- H2-6-24**: Mounting screw.
- H2-6-25**: Mounting screw.

Note

X-Y Drive (UH1508D-45)



H3-1




Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
H3-1-1	03003000UH60	Y-LM Guide Frame L620				4	
H3-1-2	14027SC-4113	Hex. Socket Bolt				16	
H3-1-3	03003SC-4113	Hex. Socket Bolt "B" (M8*L35)			O	12	
H3-1-4	15095SW-3115	Spring Washer (@8)			O	28	
H3-1-5	04029SW-A001	Stud Bolt Washer(S) (@8)			O	28	
H3-1-6	16074PR-UK06	Y-Lm Support Fixing Plate				2	
H3-1-7	14006SC-7113	Hex.Socket Bolt (M8*L15)			O	8	
H3-1-8	15095SW-3115	Spring Washer (@6)			O	8	
H3-1-9	08041SW-1111	Washer (@6)			O	8	
H3-1-10	08076SC-7113	Hex. Socket Bolt (M5*L15)			O	8	
H3-1-11	18048SW-3115	Spring Washer (@5)			O	8	
H3-1-12	16018SW-1111	Washer (@5)			O	8	
H3-1-13	03101300UH00	Bracket for Y-Sensor				2	
H3-1-14	03101300UH00	Bracket for Y-Sensor				2	
H3-1-15	02015SC-7113	Hex.Socket Bolt(M4*L10)			O	4	
H3-1-16	02028SW-9115	Spring Washer (@4)			O	4	
H3-1-17	05009SW-1111	Washer (@4-L)			O	4	
H3-1-18	09018EL-UK01	Sensor				2	
H3-1-19	08006SC-8118	Plus Screw (M3*L5)			O	4	
H3-1-20	03100600UH00	Tension Adjusting Plate				4	
H3-1-21	07016SC-7113	Hex.Socket Bolt (M4*L12)			O	8	
H3-1-22	18014SW-3115	Spring Washer (@4-No2)			O	8	
H3-1-23	18015SW-3111	Washer (4@)			O	16	
H3-1-24	03100700UH00	Fixed Block				4	
H3-1-25	11029SC-4113	Hex. Socket Bolt (M4*L20)			O	4	
H3-1-26	18014SW-3115	Spring Washer (@4-No2)			O	4	
H3-1-27	18015SW-3111	Washer (4@)			O	4	
H3-1-28	16028SC-7113	Hex. Socket Bolt (M5*L25)			O	4	
H3-1-29	18048SW-3115	Spring Washer (@5)			O	4	
H3-1-30	16018SW-1111	Washer (@5)			O	4	
H3-1-31	03100500UH00	Y-Tension Adjusting Bracket				4	
H3-1-32	08007SC-4517	Hex. Socket Set Screw (M3*L5)			O	8	
H3-1-33	03003400UH60	Y-Drive Timing Pulley				4	
H3-1-34	12018BR-T121	Needle Bearing Hk1010(Ina)				8	
H3-1-35	12019BR-T121	Fiber Washer R-Tw1020				8	
H3-1-36	16100CW-UK06	Timing Pulley Shaft (Y)				4	
H3-1-37	08062SC-7113	Hex. Socket Bolt (M5*L20)			O	8	

H3

H3-2



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
H3-2-1	16059MT-E131	Y Motor (103H89222-5212)				2	
H3-2-2	14046SC-7113	Hex.Socket Bolt (M6*L30)			O	8	
H3-2-3	16014SW-4115	Spring Washer (@6)			O	8	
H3-2-4	08057SW-1111	Washer (@6)			O	8	
H3-2-5	GP-007511-00	Y-Driving Box				1	
H3-2-6	14002SC-7113	Hex. Socket Bolt (M6*L15)			O	1	
H3-2-7	16014SW-4115	Spring Washer (@6)			O	5	
H3-2-8	08057SW-1111	Washer			O	5	
H3-2-9	01029BR-A001	Bearing(6004zz)				3	
H3-2-10	14058CW-A001	Bearing Stopper Collar				3	
H3-2-11	04012AF-A001	Screw(15/64-28)				8	
H3-2-12	GP-007517-00	Y-Driving Shaft "C"				2	
	03100800UH60	Y-Driving Shaft "C"	UH1208D			2	
	GP-007516-00	Y-Driving Shaft "B"				2	
H3-2-13	GP-004159-00	Y-Driving Shaft	Aug,24,04 ~ Apr,26,05	X		2	
	GP-004159-01		Apr,27,05 ~	△		2	
H3-2-14	03003800B000	Coupling				4	
H3-2-15	08091SC-7113	Hex. Socket Bolt (M6*L20)			O	16	
H3-2-16	03200200B000	Lower Shaft Timing Pulley				1	
H3-2-17	14061AF-4517	Hex. Socket Bolt (M8*L8)			O	2	
H3-2-18	BE-000023-00	Y-Driving Timing Belt				1	
H3-2-19	GP-007515-00	Y-Driving Box Driven Shaft				2	
H3-2-20	03005100U000	Coupling "A"				4	
H3-2-21	GP-005380-00	Coupling				1	
H3-2-22	GP-044367-00	Y-Driving Timing Pulley	Dec,02,08 ~	X		1	
	GP-044367-01		Jul,05,10 ~	△		1	
H3-2-23	GP-005379-00	Tension Adjusting Roller				1	
H3-2-24	03200400I000	Roller Bearing			O	2	
H3-2-25	GP-005378-00	Idle Bush				1	
H3-2-26	03200700I000	C-Ring			O	1	
H3-2-27	14060AF-4517	Hex. Socket Bolt (M6*L6)			O	1	
H3-2-28	GP-007512-00	Idle Shaft	Feb,05,05 ~ Dec,17,08	X		1	
	GP-007512-01		Dec,18,08	△		1	
H3-2-29	GP-007513-00	Y-Driving Box Bracket				2	
H3-2-30	03003SC-4113	Hex. Socket Bolt "B"(M8*L35)			O	8	
H3-2-31	15095SW-3115	Spring Washer (@8)			O	8	
H3-2-32	04029SW-A001	Stud Bolt Washer(S) (@8)			O	8	
H3-2-33	GP-005374-00	Y-Driving Box CoverA				2	

H3

H3-3


The diagram illustrates the assembly of the H3-3 unit. The components and their assembly sequence are as follows:

- H3-3-1**: The main base rail, shown at the bottom of the diagram.
- H3-3-2**: A long, narrow component that fits into the base rail.
- H3-3-3**: A long, narrow component that fits into the base rail, shown with dashed lines indicating its position.
- H3-3-4**: A small, rectangular component that fits into the base rail.
- H3-3-5**, **H3-3-6**, **H3-3-7**: Screws used to secure the components into the base rail.
- H3-3-8**: A small, rectangular component that fits into the base rail.
- H3-3-9**, **H3-3-10**, **H3-3-11**: Screws used to secure the components into the base rail.
- H3-3-12**: A small, rectangular component that fits into the base rail.
- H3-3-13**, **H3-3-14**, **H3-3-15**, **H3-3-16**, **H3-3-17**, **H3-3-18**: Various small components and screws used to secure the components into the base rail.
- H3-3-19**: A small, rectangular component that fits into the base rail.

Note

H3

H3-4




Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
H3-4-1	14045AD-UK01	BELT BRACKET (B)				2	
H3-4-2	14049AD-UK01	BELT BRACKET (C)				2	
H3-4-3	15034SC-4113	HEX. SOCKET Bolt (M4*L45)			O	2	
H3-4-4	05009SW-1111	WASHER (@4-L)			O	2	
H3-4-5	03201100UH00	X Timing Belt (015-AT5-0299)				4	
H3-4-6	14051PR-UK01	FIXING PLATE				8	
H3-4-7	14052PR-UK01	FIXING PLATE HOLDER				8	
H3-4-8	13020SC-4113	HEX. SOCKET BOLT (M3*L8)			O	32	
H3-4-9	11019SW-9115	SPRING WASHER (3@)			O	32	
H3-4-10	08011SW-1111	SPRING WASHER (@3-S)			O	32	
H3-4-11	12017PU-T121	Timing Pulley "A"				4	
H3-4-12	12018BR-T121	Needle Bearing Hk1010(Ina)				8	
H3-4-13	12019BR-T121	FIBER WASHER R-TW1020				8	
H3-4-14	14060CW-UK01	TIMING PULLEY DRIVING PIN				4	
H3-4-15	15048SC-4119	PLUS SCREW (M5*L12)				4	
H3-4-16	08044SR-4013	E-RING (@8)			O	4	
H3-4-17	15076AF-UK01	X-MOTOR				4	
H3-4-18	08076SC-4113	HEX. SOCKET BOLT (M5*L12)			O	16	
H3-4-19	16019SW-4115	SPRING WASHER (@5)			O	16	
H3-4-20	16018SW-1111	WASHER (@5)			O	16	
H3-4-21	15061PR-UK01	MOTOR SPACE (@5*@11*2T)				16	
H3-4-22	14075PR-UK01	MOTOR BASE (R)				2	
H3-4-23	14074PR-UK01	MOTOR BASE (L)				2	
H3-4-24	15053SC-4119	PLUS SCREW (M5*L30)			O	8	
H3-4-25	14067AD-UK01	MOTOR FIXING SHAFT (B)				4	
H3-4-26	15055SC-4119	PLUS SCREW (M5*L35)			O	4	
H3-4-27	14063PU-UK01	Timing Pulley "B"				4	
H3-4-28	04014SC-4517	HEX.SOCKET SET SCREW(M5*L5)			O	8	
H3-4-29	14065AD-UK01	MOTOR FIXING SHAFT (A)				8	
H3-4-30	14069AD-UK01	Motor Block				4	
H3-4-31	08076SC-4113	HEX. SOCKET BOLT (M5*L12)			O	8	
H3-4-32	16019SW-4115	SPRING WASHER (@5)			O	8	
H3-4-33	14071BR-UK01	Bearing Bc616Zz				4	
H3-4-34	15044EL-T121	Bid (S)				4	
H3-4-35	25014EL-UK01	Cable (4Ht-14)				2	

H3

H3-5




Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
H3-5-1	GP-004143-00	X-LM RAIL "A" (THK SR15W- L580)				4	
H3-5-2	03200600UH00	X-LM RAIL "B" (THK SR15W- L690)				2	
H3-5-3	22006SC-7113	Hex. Socket Bolt (M3*L8)			O	88	
H3-5-4	15007PR-UK02	CONNECTING PLATE(L)				2	
H3-5-5	02015SC-4113	HEX.SOCKET BOLT (M4*L10)			O	4	
H3-5-6	18014SW-3115	Spring Washer (@4-No2)			O	4	
H3-5-7	18015SW-3111	WASHER (4@)			O	4	
H3-5-8	15011PR-UK02	CONNECTING PLATE(R)				2	
H3-5-9	02015SC-4113	HEX.SOCKET BOLT (M4*L10)			O	4	
H3-5-10	18014SW-3115	SPRING WASHER (@4-NO2)			O	4	
H3-5-11	18015SW-3111	WASHER (4@)			O	4	
H3-5-12	15015PR-UK02	Connecting Plate				8	
H3-5-13	02015SC-4113	HEX.SOCKET BOLT (M4*L10)			O	32	
H3-5-14	18014SW-3115	Spring Washer (@4-No2)			O	32	
H3-5-15	18015SW-3111	WASHER (4@)			O	32	
H3-5-16	GP-004144-00	LM Block Connecting Plate(L) (L=537)				2	
H3-5-17	02004SC-4113	HEX. SOCKET BOLT (M4*L8)			O	8	
H3-5-18	18014SW-3115	SPRING WASHER (@4-NO2)			O	8	
H3-5-19	18015SW-3111	WASHER (4@)			O	8	
H3-5-20	GP-004145-00	LM Block Connecting Plate(R) (L=537)				2	
H3-5-21	02004SC-4113	HEX. SOCKET BOLT (M4*L8)			O	8	
H3-5-22	18014SW-3115	SPRING WASHER (@4-NO2)			O	8	
H3-5-23	18015SW-3111	WASHER (4@)			O	8	
H3-5-24	14020PR-UK01	SPACE				4	
H3-5-25	03201200UH00	X-MOVING SENSOR PLATE				2	
H3-5-26	02004SC-4113	HEX. SOCKET BOLT (M4*L8)			O	4	
H3-5-27	18014SW-3115	SPRING WASHER (@4-NO2)			O	4	
H3-5-28	18015SW-3111	WASHER (4@)			O	4	
H3-5-29	14045AD-UK01	BELT BRACKET (B)				4	
H3-5-30	14048AD-UK01	BELT BRACKET (A)				2	
H3-5-31	15034SC-4113	HEX. SOCKET Bolt (M4*L45)			O	2	
H3-5-32	05009SW-1111	WASHER (@4-L)			O	2	

H3

H3-6



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
H3-6-1	GP-004142-00	X-FRAME(L=2135)	Aug,24,04 ~ Apr,26,05	X		2	
	GP-004142-01		Apr,27,05 ~ Jun,01,05	△		2	
	GP-004142-02		Jun,02,05 ~	△		2	
H3-6-2	15062SF-T121	Felt				12	
H3-6-3	03200700UH00	Tubular Frame Rail Plate				1	
H3-6-4	GP-004146-00	X-FRAME COVER				2	
H3-6-5	18153SC-3123	PLUS SCREW (M4*L10)			O	4	
H3-6-6	15042SC-3123	TRUSS SCREW (M4*L6)			O	32	
H3-6-7	GP-005104-00	X-Frame Side Cover Holder (L)				2	
H3-6-8	02004SC-4113	HEX. SOCKET BOLT (M4*L8)			O	8	
H3-6-9	18014SW-3115	SPRING WASHER (@4-NO2)			O	8	
H3-6-10	18015SW-3111	WASHER (4@)			O	8	
H3-6-11	GP-005105-00	X-Frame Side Cover Holder (R)				2	
H3-6-12	02004SC-4113	HEX. SOCKET BOLT (M4*L8)			O	8	
H3-6-13	18014SW-3115	SPRING WASHER (@4-NO2)			O	8	
H3-6-14	18015SW-3111	WASHER (4@)			O	8	
H3-6-15	GP-005106-00	X-FRAME SIDE COVER L				2	
H3-6-16	GP-005107-00	X-FRAME SIDE COVER R				2	
H3-6-17	15042SC-3123	TRUSS SCREW (M4*L6)			O	8	
H3-6-18	GP-004272-00	X-FRAME SUPPORT BAR	Aug,26,04 ~ Dec,01,04	X		2	
	GP-004272-01		Dec,02,04 ~	△		2	
H3-6-19	18047SC-7113	HEX. SOCKET BOLT (M5*L15)			O	4	
H3-6-20	18048SW-3115	SPRING WASHER (5@)			O	4	
H3-6-21	18049SW-3111	WASHER (@5)			O	4	
H3-6-22	07016SC-4113	HEX. SOCKET BOLT (M4*L12)			O	36	
H3-6-23	18014SW-3115	SPRING WASHER (@4-NO2)			O	36	
H3-6-24	18015SW-3111	WASHER (4@)			O	36	
H3-6-25	GP-005108-00	X-Frame Support Bar Cover L				2	
H3-6-26	GP-005109-00	X-Frame Support Bar Cover R				2	
H3-6-27	15112SC-7113	HEX. SOCKET SET SCREW(M3*L8)			O	8	
H3-6-28	11019SW-9115	SPRING WASHER (3@)			O	8	
H3-6-29	06011SW-2111	WASHER (@3)			O	8	
H3-6-30	03201900UH00	X-FRAME SCREW BUSH				8	
H3-6-31	03101700UH00	Roller Fixed Plate				4	
H3-6-32	15095SW-3115	Spring Washer (@8)			O	4	
H3-6-33	04032SN-A001	Hex. Nut (M8-No2)			O	4	
H3-6-34	15104CW-UK01	Roller Stud Bolt				4	

H3


H3-6

This diagram illustrates the exploded view of the H3-6 assembly, showing the relationship between various components. The main structure consists of a long, narrow frame (H3-6-1) with multiple internal rails (H3-6-2, H3-6-3, H3-6-4). Key components include:


- Top Rail Assembly:** H3-6-1 (main rail), H3-6-2 (internal rail), H3-6-3 (internal rail), H3-6-4 (internal rail).
- End Components:** H3-6-5 (end cap), H3-6-6 (end cap), H3-6-7 (end cap), H3-6-8 (end cap), H3-6-9 (end cap), H3-6-10 (end cap), H3-6-11 (end cap), H3-6-12 (end cap), H3-6-13 (end cap), H3-6-14 (end cap), H3-6-15 (end cap), H3-6-16 (end cap), H3-6-17 (end cap), H3-6-18 (end cap), H3-6-19 (end cap), H3-6-20 (end cap), H3-6-21 (end cap), H3-6-22 (end cap), H3-6-23 (end cap), H3-6-24 (end cap), H3-6-25 (end cap), H3-6-26 (end cap), H3-6-27 (end cap), H3-6-28 (end cap), H3-6-29 (end cap), H3-6-30 (end cap), H3-6-31 (end cap), H3-6-32 (end cap), H3-6-33 (end cap), H3-6-34 (end cap), H3-6-35 (end cap), H3-6-36 (end cap), H3-6-37 (end cap), H3-6-38 (end cap), H3-6-39 (end cap), H3-6-40 (end cap), H3-6-41 (end cap), H3-6-42 (end cap), H3-6-43 (end cap), H3-6-44 (end cap), H3-6-45 (end cap), H3-6-46 (end cap), H3-6-47 (end cap), H3-6-48 (end cap), H3-6-49 (end cap), H3-6-50 (end cap), H3-6-51 (end cap), H3-6-52 (end cap), H3-6-53 (end cap), H3-6-54 (end cap), H3-6-55 (end cap), H3-6-56 (end cap), H3-6-57 (end cap), H3-6-58 (end cap), H3-6-59 (end cap).
- Internal Components:** H3-6-101 (internal rail), H3-6-102 (internal rail), H3-6-103 (internal rail), H3-6-104 (internal rail), H3-6-105 (internal rail), H3-6-106 (internal rail), H3-6-107 (internal rail), H3-6-108 (internal rail), H3-6-109 (internal rail), H3-6-110 (internal rail), H3-6-111 (internal rail), H3-6-112 (internal rail), H3-6-113 (internal rail), H3-6-114 (internal rail), H3-6-115 (internal rail), H3-6-116 (internal rail), H3-6-117 (internal rail), H3-6-118 (internal rail), H3-6-119 (internal rail), H3-6-120 (internal rail), H3-6-121 (internal rail), H3-6-122 (internal rail), H3-6-123 (internal rail), H3-6-124 (internal rail), H3-6-125 (internal rail), H3-6-126 (internal rail), H3-6-127 (internal rail), H3-6-128 (internal rail), H3-6-129 (internal rail), H3-6-130 (internal rail), H3-6-131 (internal rail), H3-6-132 (internal rail), H3-6-133 (internal rail), H3-6-134 (internal rail), H3-6-135 (internal rail), H3-6-136 (internal rail), H3-6-137 (internal rail), H3-6-138 (internal rail), H3-6-139 (internal rail), H3-6-140 (internal rail), H3-6-141 (internal rail), H3-6-142 (internal rail), H3-6-143 (internal rail), H3-6-144 (internal rail), H3-6-145 (internal rail), H3-6-146 (internal rail), H3-6-147 (internal rail), H3-6-148 (internal rail), H3-6-149 (internal rail), H3-6-150 (internal rail), H3-6-151 (internal rail), H3-6-152 (internal rail), H3-6-153 (internal rail), H3-6-154 (internal rail), H3-6-155 (internal rail), H3-6-156 (internal rail), H3-6-157 (internal rail), H3-6-158 (internal rail), H3-6-159 (internal rail), H3-6-160 (internal rail), H3-6-161 (internal rail), H3-6-162 (internal rail), H3-6-163 (internal rail), H3-6-164 (internal rail), H3-6-165 (internal rail), H3-6-166 (internal rail), H3-6-167 (internal rail), H3-6-168 (internal rail), H3-6-169 (internal rail), H3-6-170 (internal rail), H3-6-171 (internal rail), H3-6-172 (internal rail), H3-6-173 (internal rail), H3-6-174 (internal rail), H3-6-175 (internal rail), H3-6-176 (internal rail), H3-6-177 (internal rail), H3-6-178 (internal rail), H3-6-179 (internal rail), H3-6-180 (internal rail), H3-6-181 (internal rail), H3-6-182 (internal rail), H3-6-183 (internal rail), H3-6-184 (internal rail), H3-6-185 (internal rail), H3-6-186 (internal rail), H3-6-187 (internal rail), H3-6-188 (internal rail), H3-6-189 (internal rail), H3-6-190 (internal rail), H3-6-191 (internal rail), H3-6-192 (internal rail), H3-6-193 (internal rail), H3-6-194 (internal rail), H3-6-195 (internal rail), H3-6-196 (internal rail), H3-6-197 (internal rail), H3-6-198 (internal rail), H3-6-199 (internal rail), H3-6-200 (internal rail).

H3

X-Y Drive (UH1512D-45)



H4-1



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
H4-1-1	GP-004148-00	Y-LM Guide Frame L620	Aug,24,04 ~ Mar,18,08	X		4	
	GP-004148-01		Mar,19,08 ~	△		4	
H4-1-2	02033SC-4113	Hex. Socket Bolt			O	16	
H4-1-3	03003SC-4113	Hex. Socket Bolt "B" (M8*L35)			O	12	
H4-1-4	15095SW-3115	Spring Washer (@8)			O	28	
H4-1-5	04029SW-A001	Stud Bolt Washer(S) (@8)			O	28	
H4-1-6	16074PR-UK06	Y-Lm Support Fixing Plate				2	
H4-1-7	14002SC-7113	Hex.Socket Bolt (M6*L15)			O	8	
H4-1-8	16014SW-4115	Spring Washer (@6)			O	8	
H4-1-9	08057SW-1111	Washer (@6)			O	8	
H4-1-10	03016SC-4113	Hex. Socket Bolt (M5*L15)			O	8	
H4-1-11	18048SW-3115	Spring Washer (@5)			O	8	
H4-1-12	16018SW-1111	Washer (@5)			O	8	
H4-1-13	03101300UH00	Sensor Bracket				1	
H4-1-14	03101300UH00	Sensor Bracket				1	
H4-1-15	02015SC-7113	Hex.Socket Bolt (M4*L10)			O	4	
H4-1-16	02028SW-9115	Spring Washer (@4)			O	4	
H4-1-17	05009SW-1111	Washer (@4-L)			O	4	
H4-1-18	02107300UH80	Cable (Sh-73)				2	
H4-1-19	06010SC-8118	Plus Screw (M3*L4)			O	4	
H4-1-20	03100600UH00	Tension Adjusting Plate				4	
H4-1-21	07016SC-7113	Hex.Socket Bolt (M4*L12)			O	8	
H4-1-22	18014SW-3115	Spring Washer (@4-No2)			O	8	
H4-1-23	18015SW-3111	Washer (4@)			O	16	
H4-1-24	03100700UH00	Fixed Block				4	
H4-1-25	11029SC-4113	Hex. Socket Bolt (M4*L20)			O	4	
H4-1-26	18014SW-3115	Spring Washer (@4-No2)			O	4	
H4-1-27	18015SW-3111	Washer (4@)			O	4	
H4-1-28	15030SC-7113	Hex. Socket Bolt (M5*L30)			O	4	
H4-1-29	18048SW-3115	Spring Washer (@5)			O	4	
H4-1-30	16018SW-1111	Washer (@5)			O	4	
H4-1-31	03100500UH00	Y-Tension Adjusting Bracket				4	
H4-1-32	08007SC-4517	Hex. Socket Set Screw (M3*L5)			O	8	
H4-1-33	04001000 E000	Y-Drive Timing Pulley				4	
H4-1-34	12018BR-T121	Needle Bearing Hk1010(Ina)				8	
H4-1-35	12019BR-T121	Fiber Washer R-Tw1020				8	
H4-1-36	16100CW-UK06	Timing Pulley Shaft (Y)				4	
H4-1-37	08062SC-7113	Hex. Socket Bolt (M5*L20)			O	8	

H4-1

The diagram illustrates the assembly of the H4-1 unit. The main components are shown in an exploded view, with dashed lines indicating their relative positions and assembly sequence. The components are labeled with part numbers:

- H4-1-1: Main horizontal rail
- H4-1-2: Small pin
- H4-1-3: Small pin
- H4-1-4: Small pin
- H4-1-5: Small pin
- H4-1-6: Small pin
- H4-1-7: Small pin
- H4-1-8: Small pin
- H4-1-9: Small pin
- H4-1-10: Small pin
- H4-1-11: Small pin
- H4-1-12: Small pin
- H4-1-13: Small pin
- H4-1-14: Small pin
- H4-1-15: Small pin
- H4-1-16: Small pin
- H4-1-17: Small pin
- H4-1-18: Small pin
- H4-1-19: Small pin
- H4-1-20: Small pin
- H4-1-21: Small pin
- H4-1-22: Small pin
- H4-1-23: Small pin
- H4-1-24: Small pin
- H4-1-25: Small pin
- H4-1-26: Small pin
- H4-1-27: Small pin
- H4-1-28: Small pin
- H4-1-29: Small pin
- H4-1-30: Small pin
- H4-1-31: Small pin
- H4-1-32: Small pin
- H4-1-33: Small pin
- H4-1-34: Small pin
- H4-1-35: Small pin
- H4-1-36: Small pin
- H4-1-37: Small pin
- H4-1-38: Small pin
- H4-1-39: Small pin
- H4-1-40: Small pin
- H4-1-41: Small pin
- H4-1-42: Small pin
- H4-1-43: Small pin
- H4-1-44: Small pin
- H4-1-45: Small pin
- H4-1-46: Small pin
- H4-1-47: Small pin
- H4-1-48: Small pin
- H4-1-49: Small pin
- H4-1-50: Small pin
- H4-1-51: Small pin
- H4-1-52: Small pin
- H4-1-53: Small pin
- H4-1-54: Small pin
- H4-1-55: Small pin
- H4-1-56: Small pin

H4

H4-2

The diagram illustrates the assembly of the H4-2 unit. The main components and their assembly sequence are as follows:

- H4-2-1**: The central cylindrical component.
- H4-2-2**: A small screw used to secure the front plate.
- H4-2-3**: A small screw used to secure the front plate.
- H4-2-4**: A small screw used to secure the front plate.
- H4-2-5**: The front plate, which is attached to the main unit.
- H4-2-6**: A screw used to secure the front plate.
- H4-2-7**: A screw used to secure the front plate.
- H4-2-8**: A screw used to secure the front plate.
- H4-2-9**: A small screw used to secure the front plate.
- H4-2-10**: A small screw used to secure the front plate.
- H4-2-11**: A small screw used to secure the front plate.
- H4-2-12**: A small screw used to secure the front plate.
- H4-2-13**: A small screw used to secure the front plate.
- H4-2-14**: A small screw used to secure the front plate.
- H4-2-15**: A small screw used to secure the front plate.
- H4-2-16**: A small screw used to secure the front plate.

Note

H4

H4-3


The diagram illustrates the assembly of the H4-3 component. The main assembly sequence is shown in a perspective view at the bottom, with dashed lines indicating the assembly path. The components are labeled as follows:

- H4-3-1: Main body component.
- H4-3-2: Pin component.
- H4-3-3: Base component.
- H4-3-4: Bracket component.
- H4-3-5: Pin component.
- H4-3-6: Pin component.
- H4-3-7: Pin component.
- H4-3-8: Plate component.
- H4-3-9: Pin component.
- H4-3-10: Pin component.
- H4-3-11: Pin component.
- H4-3-12: Plate component.
- H4-3-13: Pin component.
- H4-3-14: Pin component.
- H4-3-15: Pin component.
- H4-3-16: Pin component.
- H4-3-17: Pin component.
- H4-3-18: Pin component.
- H4-3-19: Pin component.

Note

[illegible]

H4-4



Note


Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
H4-4-1	14045AD-UK01	Belt Bracket (B)				2	
H4-4-2	14049AD-UK01	Belt Bracket (C)				2	
H4-4-3	15034SC-4113	Hex. Socket Bolt (M4*L45)			O	2	
H4-4-4	05009SW-1111	Washer (@4-L)			O	2	
H4-4-5	03201100UH00	X-Timing Belt (L=1260)				4	
H4-4-6	14051PR-UK01	Fixing Plate				8	
H4-4-7	14052PR-UK01	Fixing Plate Holder				8	
H4-4-8	03071SC-A001	Hex.Socket Bolt (M3*L15)			O	32	
H4-4-9	11019SW-9115	Spring Washer (3@)			O	32	
H4-4-10	08011SW-1111	Spring Washer (@3-S)			O	32	
H4-4-11	12017PU-T121	Timing Pulley "A"				4	
H4-4-12	12018BR-T121	Needle Bearing Hk1010(Ina)				8	
H4-4-13	12019BR-T121	Fiber Washer R-Tw1020				8	
H4-4-14	03106000U000	Timing Pulley Driving Pin				4	
H4-4-15	15048SC-4119	Plus Screw (M5*L12)			O	4	
H4-4-16	08044SR-4013	E-Ring (@8)				4	
H4-4-17	15076AF-UK01	X-Motor				4	
H4-4-18	08076SC-7113	Hex. Socket Bolt (M5*L12)			O	40	
H4-4-19	18048SW-3115	Spring Washer (@5)			O	40	
H4-4-20	16018SW-1111	Washer (@5)			O	16	
H4-4-21	15061PR-UK01	Motor Space (@5*@11*2T)				16	
H4-4-22	14074PR-UK01	Motor Base (L)				2	
H4-4-23	14075PR-UK01	Motor Base (R)				2	
H4-4-24	15053SC-4119	Plus Screw (M5*L30)			O	8	
H4-4-25	14067AD-UK01	Motor Fixing Shaft (B)				4	
H4-4-26	15055SC-4119	Plus Screw (M5*L35)			O	4	
H4-4-27	14063PU-UK01	Timing Pulley "B"				4	
H4-4-28	04014SC-4517	Hex.Socket Set Screw(M5*L5)			O	8	
H4-4-29	14065AD-UK01	Motor Fixing Shaft (A)				8	
H4-4-30	14069AD-UK01	Motor Block				4	
H4-4-31	14071BR-UK01	Bearing Bc616Zz			O	4	
H4-4-32	15044EL-T121	Bid (S)				4	
H4-4-33	25009EL-UK06	Cable (25-09)				2	

H4

This diagram illustrates the exploded view of the H4-5 assembly, showing the following components and their assembly sequence:

- Base Components:** H4-5-1 (Main Base), H4-5-2 (Intermediate Base), and H4-5-3 (End Base).
- Mounting Brackets and Plates:** H4-5-4, H4-5-9, H4-5-10, H4-5-15, H4-5-21, H4-5-14, and H4-5-8.
- Fasteners:** H4-5-5, H4-5-6, H4-5-7, H4-5-11, H4-5-12, H4-5-13, H4-5-18, H4-5-19, H4-5-20, H4-5-22, H4-5-23, and H4-5-24.
- Assembly Sequence:** The components are numbered 1 through 24, indicating the order in which they should be assembled.

H4-6



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
H4-6-1	GP-005070-00	X-Lm Guide Frame	Oct,06,04 ~ Jun,01,06	X		2	
	GP-005070-01		Jun,02,06 ~	△		2	
H4-6-2	15062SF-T121	Felt				16	
H4-6-3	03200700UH00	Tubular Frame Rail Plate				2	
H4-6-4	03201300UH00	X-Cover (L=2931)				24	
H4-6-5	18153SC-3123	Plus Screw (M4*L10)			O	2	
H4-6-6	15042SC-3123	Truss Screw (M4*L6)			O	4	
H4-6-7	GP-005104-00	X-Frame Side Cover Holder (L)				2	
H4-6-8	GP-005105-00	X-Frame Side Cover Holder (R)				2	
H4-6-9	02023SC-7113	Hex. Socket Bolt (M4*L8)			O	16	
H4-6-10	02028SW-9115	Spring Washer (@4)			O	16	
H4-6-11	05009SW-1111	Washer (@4-L)			O	16	
H4-6-12	GP-005106-00	X-Axis Frame Side Cover (L)				2	
H4-6-13	GP-005107-00	X-Axis Frame Side Cover (R)				2	
H4-6-14	15042SC-3123	Truss Screw (M4*L6)			O	8	
H4-6-15	25052EL-UK01	Last-Sensor (Black) 4Ht-52				2	
H4-6-16	25053EL-UK01	Last-Sensor (White) 4Ht-53				2	
H4-6-17	15067PR-UK01	Sensor Plate				4	
H4-6-18	15043EL-UK01	X-Positioning Sensor				4	
H4-6-19	06010AF-8118	Plus Screw(M3*L4)			O	8	
H4-6-20	GP-005071-00	X-FRAME SUPPORT BAR	Oct,06,04 ~ Dec,01,04	X		2	
	GP-005071-01		Dec,02,04 ~ May,17,05	△		2	
	GP-005071-02		May,18,05 ~	△		2	
H4-6-21	18047SC-7113	HEX. SOCKET BOLT (M5*L15)			O	4	
H4-6-22	18048SW-3115	SPRING WASHER (5@)			O	4	
H4-6-23	18049SW-3111	WASHER (@5)			O	4	
H4-6-24	02004SC-4113	HEX. SOCKET BOLT (M4*L10)			O	36	
H4-6-25	18014SW-3115	SPRING WASHER (@4-NO2)			O	36	
H4-6-26	18015SW-3111	WASHER (4@)			O	36	
H4-6-27	03000200UH80	X-Frame Support Bar Cover L				2	
H4-6-28	03000200UH80	X-Frame Support Bar Cover R				2	
H4-6-29	15112SC-7113	HEX. SOCKET SET SCREW(M3*L8)			O	8	
H4-6-30	11019SW-9115	SPRING WASHER (3@)			O	8	
H4-6-31	06011SW-2111	WASHER (@3)			O	8	
H4-6-32	15082PR-W121	FIXING PLATE FOR BUSHING				2	
H4-6-33	02023SC-7113	HEX.SOCKET BOLT (M4*L8)			O	8	
H4-6-34	03000100UH00	Roller Plate Cover				8	

H4


H4-6

This diagram illustrates the exploded view of the H4-6 assembly, showing the relationship between various components. The main structure consists of a long, narrow base (H4-6-4) with a central rail (H4-6-3) and a top rail (H4-6-2). A large, curved component (H4-6-1) is positioned above the base. Various smaller components, including brackets, pins, and connectors, are shown with callouts indicating their assembly points. The components are labeled with part numbers such as H4-6-1, H4-6-2, H4-6-3, H4-6-4, H4-6-5, H4-6-6, H4-6-7, H4-6-8, H4-6-9, H4-6-10, H4-6-11, H4-6-12, H4-6-13, H4-6-14, H4-6-15, H4-6-16, H4-6-17, H4-6-18, H4-6-19, H4-6-20, H4-6-21, H4-6-22, H4-6-23, H4-6-24, H4-6-25, H4-6-26, H4-6-27, H4-6-28, H4-6-29, H4-6-30, H4-6-31, H4-6-32, H4-6-33, H4-6-34, H4-6-35, H4-6-36, H4-6-37, H4-6-38, H4-6-39, H4-6-40, H4-6-41, H4-6-42, H4-6-43, H4-6-44, H4-6-45, H4-6-46, H4-6-47, H4-6-48, H4-6-49, H4-6-50, and H4-6-51. The diagram also shows a cable assembly (H4-6-52) with multiple connectors.


Note

H4

SETTING 1



I-1



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
I-1-1	EP-000141-00	Upper Thread Hook Motor Unit				1	
I-1-2	GP-015086-00	Motor Base				1	
I-1-3	06025MC-7113	Hex.Socket Bolt (M6*L25)			O	4	
I-1-4	16014SW-4115	Spring Washer (@6)			O	4	
I-1-5	08057SW-1111	Washer (@6)			O	4	
I-1-6	03003300H000	Cam Shaft Fixing Block				4	
I-1-7	05008MC-4517	Hex.Socket Bolt (M5*L8)			O	2	
I-1-8	GP-005184-00	SENSOR SENSING ADJUSTING RING	Oct,14,04 ~ May,18,05			1	
	GP-005184-01		May,19,05 ~			1	
I-1-9	04014SC-4517	Hex.Socket Set Screw (M5*L5)			O	2	
I-1-10	03003500H000	Motor Driving Cam Shaft				1	
I-1-11	04014SC-4517	Hex.Socket Set Screw (M5*L5)			O	1	
I-1-12	GP-015085-00	UPPER THREAD HOOK SENSOR BASE				1	
I-1-13	07035SC-7113	Bracket Screw (M3*L6)			O	2	
I-1-14	15-027A-2070	SENSOR				1	
I-1-15	13061SC-8119	Plus Screw (M3*L10)			O	1	
I-1-16	03003910H000	Upper Thread Driving Plate				1	
I-1-17	WS-000549-00	Stud Bolt Washer	Feb,20,09 ~			1	
	WS-000549-01		Jun,24,09 ~				
I-1-18	03004200HE00	Motor Driving Connect Plate				1	
I-1-19	03004400H000	Motor Driving Connect Bearing				2	
I-1-20	03008300H000	Connecting Plate Stud Screw A			O	1	
I-1-21	03004500H000	Connecting Plate Pin Washer				1	
I-1-22	03003810H000	Stud Bolt For Driving Plate				1	
I-1-23	03004110H000	DRIVING PLATE BLOCK B				2	
I-1-24	18047SC-7113	HEX/ SOCKET BOLT (M5*L15)				2	
I-1-25	18048SW-3115	SPRING WASHER (5@)			O	2	
I-1-26	18049SW-3111	WASHER (@5)			O	2	
I-1-27	04032SN-A001	HEX. NUT (M8-NO2)			O	1	
I-1-28	15095SW-3115	SPRING WASHER (@8)			O	1	
I-1-29	03004800H000	Connecting Plate Knuckle				1	
I-1-30	03004700H000	Connecting Plate Stud Screw				1	
I-1-31	03026SW-9115	SPRING WASHER (@6)			O	1	
I-1-32	13042SN-1111	Hex.Nut (M6*T5-R)			O	1	
I-1-33	04032SN-A001	Hex. Nut (M8-No2)			O	1	
I-1-34	03002610H000	Return Spring Stopper				6	
I-1-35	05008SC-4113	Hex.Socket Bolt (M4*L16)			O	6	
I-1-36	03002700H000	Return Spring				3	
I-1-37	03002800H000	Return Spring Stopper Washer				3	

This exploded view diagram illustrates the assembly of the motor unit. The components are labeled with part numbers and assembly order indicators (I-1-1 through I-1-48). The diagram shows the motor housing, mounting bracket, and various fasteners and sensors. Key components include the motor housing (I-1-1), mounting bracket (I-1-2), and various sensors and fasteners (I-1-3 through I-1-48). The diagram is divided into several sections by dashed lines, indicating the assembly sequence. The motor housing is shown at the top left, and the mounting bracket is shown in the center. The various fasteners and sensors are shown around the motor housing and mounting bracket, with lines indicating their assembly points. The diagram is a technical drawing of a mechanical assembly, showing the exploded view of the motor unit. The components are labeled with part numbers and assembly order indicators (I-1-1 through I-1-48). The diagram shows the motor housing, mounting bracket, and various fasteners and sensors. Key components include the motor housing (I-1-1), mounting bracket (I-1-2), and various sensors and fasteners (I-1-3 through I-1-48). The diagram is divided into several sections by dashed lines, indicating the assembly sequence. The motor housing is shown at the top left, and the mounting bracket is shown in the center. The various fasteners and sensors are shown around the motor housing and mounting bracket, with lines indicating their assembly points. The diagram is a technical drawing of a mechanical assembly, showing the exploded view of the motor unit.

Note


I-2

This diagram illustrates the exploded view of the I-2 assembly. The components are labeled with callouts I-2-1 through I-2-19. The assembly includes a main housing (I-2-1), a motor (I-2-9), a gear (I-2-10), a pin (I-2-13), a nut (I-2-11), a washer (I-2-12), a bracket (I-2-17), a lever (I-2-2), a spring (I-2-4), a pin (I-2-8), a pin (I-2-5), a pin (I-2-7), a pin (I-2-6), a pin (I-2-16), a pin (I-2-15), a pin (I-2-14), a pin (I-2-3), and a pin (I-2-18). The diagram shows the relative positions and assembly sequence of these parts.

Note




I-4




Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
I-4-1	04033AF-D002	Rotary Hook Set				6	
I-4-2	04034AF-A001	Bobbin Case Set				6	
I-4-3	04035AF-A001	Bobbin				6	
I-4-4	GP-005358-00	Rotary Hook Support	Nov,01,04 ~ Jul,12,05	X		6	
	GP-005358-01		Jul,13,05 ~	△		6	
I-4-5	02011SC-3125	Rotary Hook Support Screw				12	
I-4-6	GP-005359-00	Bed Cover	Nov,01,04 ~ May,14,05	X		6	
	GP-005359-01		May,15,05 ~ Aug,24,05	△		6	
	GP-005359-02		Aug,25,05 ~	△		6	
I-4-7	02030SC-T121	Bed Cover Screw (9/64" 40)				18	
I-4-8	GP-005360-00	Hook Cover	Nov,01,05 ~ Oct,19,05	X		6	
	GP-005360-01		Oct,20,05 ~ May,24,06	△		6	
	GP-005360-02		May,25,06 ~	△		6	
I-4-9	GP-005361-00	Hook Cover Insert				12	
I-4-10	HG-000001-00	Hook Cover Hinge				6	
I-4-11	08014AF-A001	Plus Screw (M3*L8)			O	12	
I-4-12	AS-001429-00	Picker Base Ass'Y	Nov,01,05 ~ May,29,06	X		6	
	AS-001429-01		May,30,06 ~ Dec,03,08	△		6	
	AS-001429-02		Dec,04,08 ~	△		6	
I-4-13	GP-005368-00	Picker				6	
I-4-14	07018SC-8118	Plus Screw (M3*L8)			O	12	
I-4-15	WS-000085-00	Washer for Picker Base				6	
I-4-16	15159SR-4013	E-Ring (3@)				6	
I-4-17	GP-005366-00	Picker Bracket				6	
I-4-18	116410S-8118	Driver Screw 11/64-40,L10				6	
I-4-19	116410S-8118	Driver Screw 11/64-40,L10				6	
I-4-20	GP-005362-00	Hook Cover Holder				6	
I-4-21	GP-005369-00	Picker Stopper	Nov,01,05 ~ May,18,05	X		6	
	GP-005369-01		May,19,05 ~	△		6	
I-4-22	AS-003154-00	PICKER SOLENOID	Jul,19,05 ~ Aug,21,06	X		6	
	AS-003154-01		Aug,22,06 ~	△		6	
I-4-23	02015SC-7113	Hex.Socket Bolt(M4*L10)			O	12	
I-4-24	08012CW-T121	Connecting Plate Stud Screw				6	

SETTING 2



I1-1



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
I1-1-1	EP-000141-00	Upper Thread Hook Motor Unit				1	
I1-1-2	GP-015086-00	Motor Base				1	
I1-1-3	06025MC-7113	Hex.Socket Bolt(M6*L25)			O	4	
I1-1-4	16014SW-4115	Spring Washer (@6)			O	4	
I1-1-5	08057SW-1111	Washer (@6)			O	4	
I1-1-6	03003300H000	Cam Shaft Fixing Block				4	
I1-1-7	05008MC-4517	Hex.Socket Bolt(M5*L8)			O	2	
I1-1-8	GP-005184-00	SENSOR SENSING ADJUSTING RING	Oct,14,04 ~ May,18,05			2	
	GP-005184-01		May,19,05 ~			2	
I1-1-9	04014SC-4517	Hex.Socket Set Screw(M5*L5)			O	2	
I1-1-10	03003500H000	Motor Driving Cam Shaft				1	
I1-1-11	04014SC-4517	Hex.Socket Set Screw(M5*L5)			O	1	
I1-1-12	GP-015085-00	UPPER THREAD HOOK SENSOR BASE				1	
I1-1-13	07035SC-7113	Bracket Screw (M3*L6)			O	2	
I1-1-14	15-027A-2070	SENSOR				1	
I1-1-15	13061SC-8119	Plus Screw (M3*L10)			O	1	
I1-1-16	03003910H000	Upper Thread Driving Plate				1	
I1-1-17	WS-000549-00	Stud Bolt Washer	Feb,20,09 ~ Jun,24,09		O	1	
	WS-000549-01		Jun,24,09 ~				
I1-1-18	03004200HE00	Motor Driving Connect Plate				1	
I1-1-19	03004400H000	Motor Driving Connect Bearing			O	2	
I1-1-20	03008300H000	Connecting Plate Stud Screw A				1	
I1-1-21	03004500H000	Connecting Plate Pin Washer				1	
I1-1-22	03003810H000	Stud Bolt For Driving Plate				1	
I1-1-23	03004110H000	DRIVING PLATE BLOCK B				2	
I1-1-24	18047SC-7113	HEX/ SOCKET BOLT (M5*L15)			O	2	
I1-1-25	18048SW-3115	SPRING WASHER (5@)			O	2	
I1-1-26	18049SW-3111	WASHER (@5)			O	2	
I1-1-27	04032SN-A001	HEX. NUT (M8-NO2)			O	1	
I1-1-28	15095SW-3115	SPRING WASHER (@8)			O	1	
I1-1-29	03004800H000	Connecting Plate Knuckle				1	
I1-1-30	03004700H000	Connecting Plate Stud Screw				1	
I1-1-31	03026SW-9115	SPRING WASHER (@6)			O	1	
I1-1-32	13042SN-1111	Hex.Nut (M6*T5-R)			O	1	
I1-1-33	04032SN-A001	Hex. Nut (M8-No2)			O	1	
I1-1-34	03002610H000	Return Spring Stopper				6	
I1-1-35	05008SC-4113	Hex.Socket Bolt (M4*L16)			O	6	
I1-1-36	03002700H000	Return Spring				3	
I1-1-37	03002800H000	Return Spring Stopper Washer				3	

This exploded view diagram illustrates the assembly of the I1-1 unit. The components are labeled with part numbers and their assembly sequence:


- I1-1-1**: Main housing or base plate.
- I1-1-2**: Mounting bracket or plate.
- I1-1-3**: Small cylindrical component.
- I1-1-4**: Small cylindrical component.
- I1-1-5**: Small cylindrical component.
- I1-1-6**: Small cylindrical component.
- I1-1-7**: Small cylindrical component.
- I1-1-8**: Small cylindrical component.
- I1-1-9**: Small cylindrical component.
- I1-1-10**: Small cylindrical component.
- I1-1-11**: Small cylindrical component.
- I1-1-12**: Small cylindrical component.
- I1-1-13**: Small cylindrical component.
- I1-1-14**: Small cylindrical component.
- I1-1-15**: Small cylindrical component.
- I1-1-16**: Small cylindrical component.
- I1-1-17**: Small cylindrical component.
- I1-1-18**: Small cylindrical component.
- I1-1-19**: Small cylindrical component.
- I1-1-20**: Small cylindrical component.
- I1-1-21**: Small cylindrical component.
- I1-1-22**: Small cylindrical component.
- I1-1-23**: Small cylindrical component.
- I1-1-24**: Small cylindrical component.
- I1-1-25**: Small cylindrical component.
- I1-1-26**: Small cylindrical component.
- I1-1-27**: Small cylindrical component.
- I1-1-28**: Small cylindrical component.
- I1-1-29**: Small cylindrical component.
- I1-1-30**: Small cylindrical component.
- I1-1-31**: Small cylindrical component.
- I1-1-32**: Small cylindrical component.
- I1-1-33**: Small cylindrical component.
- I1-1-34**: Small cylindrical component.
- I1-1-35**: Small cylindrical component.
- I1-1-36**: Small cylindrical component.
- I1-1-37**: Small cylindrical component.
- I1-1-38**: Small cylindrical component.
- I1-1-39**: Small cylindrical component.
- I1-1-40**: Small cylindrical component.
- I1-1-41**: Small cylindrical component.
- I1-1-42**: Small cylindrical component.
- I1-1-43**: Small cylindrical component.
- I1-1-44**: Small cylindrical component.
- I1-1-45**: Small cylindrical component.
- I1-1-46**: Small cylindrical component.
- I1-1-47**: Small cylindrical component.
- I1-1-48**: Small cylindrical component.
- I1-1-49**: Small cylindrical component.
- I1-1-50**: Small cylindrical component.
- I1-1-51**: Small cylindrical component.

[illegible]

Note

[illegible]

SPOOL



J-1


This exploded view diagram illustrates the assembly of the J-1 unit. The components are labeled as follows:

- J-1-1**: The main rectangular base plate with mounting holes.
- J-1-2**: A small screw used to secure the front panel.
- J-1-3**: A small screw used to secure the front panel.
- J-1-4**: A small screw used to secure the front panel.
- J-1-5**: A small screw used to secure the front panel.
- J-1-6**: A small screw used to secure the front panel.
- J-1-7**: A small rectangular plate used to secure the front panel.
- J-1-8**: A small circular component used to secure the front panel.
- J-1-9**: A small circular component used to secure the front panel.
- J-1-10**: A small circular component used to secure the front panel.
- J-1-11**: A small circular component used to secure the front panel.
- J-1-12**: A small circular component used to secure the front panel.
- J-1-13**: A small circular component used to secure the front panel.
- J-1-14**: A small rectangular plate used to secure the front panel.
- J-1-15**: A small circular component used to secure the front panel.
- J-1-16**: A small circular component used to secure the front panel.
- J-1-17**: A small circular component used to secure the front panel.
- J-1-18**: A small circular component used to secure the front panel.

Note




J-2



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
J-1-1	10600100H000	THREAD ANGLE FRAME				8	
J-1-2	GP-004913-00	THREAD ANGLE "A" L=820 UH1504D				2	
	05200105UH60	THREAD ANGLE "A" L=1220 UH1506D					
	GP-004135-00	THREAD ANGLE "A" L=1620 UH1208D	Aug,23,04 ~ Apr,15,08	X			
	GP-004135-01		Apr,16,08 ~	△			
	05200105UH00	THREAD ANGLE "A" L=2420 UH1512D					
J-1-3	GP-004914-00	THREAD ANGLE "B" L=820 UH1504D				2	
	05200205UH60	THREAD ANGLE "B" L=1220 UH1506D					
	GP-004136-00	THREAD ANGLE "B" L=1620 UH1208D	Aug,23,04 ~ Apr,15,08	X			
	GP-004136-01		Apr,16,08 ~	△			
	05200205UH00	THREAD ANGLE "B" L=2420 UH1512D					
J-1-4	GP-004915-00	THREAD ANGLE "C" L=820 UH1504D				2	
	05200305UH60	THREAD ANGLE "C" L=1220 UH1506D					
	GP-004137-00	THREAD ANGLE "C" L=1620 UH1208D	Aug,23,04 ~ Apr,15,08	X			
	GP-004137-01		Apr,16,08 ~	△			
	05200305UH00	THREAD ANGLE "C" L=2420 UH1512D					
J-1-5	GP-005006-00	THREAD ANGLE "D" L=820 UH1504D				2	
	05200405UH60	THREAD ANGLE "D" L=1220 UH1506D					
	GP-004138-00	THREAD ANGLE "D" L=1620 UH1208D	Aug,23,04 ~ Apr,15,08	X			
	GP-004138-01		Apr,16,08 ~	△			
	05200415UH00	THREAD ANGLE "D" L=2420 UH1512D					
J-1-6	02015SC-7113	HEX.SOCKET BOLT(M4*L10)			O	24	
J-1-7	02028SW-9115	SPRING WASHER (@4)			O	24	
J-1-8	06003SW-2111	WASHER (@4)			O	24	
J-1-9	03016SC-4113	CAP FRAME SET SCREW				16	
J-1-10	10600110B000	SUB TENSION ADJUSTING SET				84	
J-1-11	10600210B000	SUB TENSION ADJUSTING SET				6	
J-1-12	18048SW-3115	SPRING WASHER (@5)			O	90	
J-1-13	03031SN-A001	PIN. NUT (11/64,N=40)			O	90	
J-1-14	12042PM-A001	EYELET				180	

Table



This diagram illustrates the exploded view of the K1-1000000 assembly. The main structure is a long, rectangular frame composed of several interconnected components. The assembly sequence is indicated by the following labels:


- K-1-11**: A rectangular component at the top left.
- K-1-14**, **K-1-13**, **K-1-12**, and **K-1-15**: Small components and fasteners associated with K-1-11.
- K-1-6** and **K-1-7**: Fasteners used for assembly.
- K-1-4**, **K-1-3**, and **K-1-1**: Components forming the left side of the frame.
- K-1-10**, **K-1-9**, and **K-1-8**: Fasteners and components for the lower left section.
- K-1-2**: A U-shaped component in the center.
- K-1-8**, **K-1-9**, and **K-1-10**: Fasteners for the central section.
- K-1-1**: A rectangular component on the right side.
- K-1-19**, **K-1-18**, **K-1-17**, and **K-1-20**: Fasteners and components for the bottom right section.
- K-1-16**: A rectangular component at the bottom right.

The diagram uses dashed lines to show the alignment and assembly path of the various parts.

[illegible]

K1

K-2




Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
K-2-1	GP-004907-00	TABLE SUPPORT A	Sep,25,04 ~ Aug,10,06	X		4	
	GP-004907-01		Aug,11,06 ~	△		4	
K-2-2	GP-004908-00	TABLE SUPPORT B	Sep,25,04 ~ Aug,10,06	X		8	
	GP-004908-01		Aug,11,06 ~	△		8	
K-2-3	GP-008797-00	TABLE SUPPORT C	Apr,26,05 ~ Aug,10,06	X		10	
	GP-008797-01		Aug,11,06 ~	△		10	
K-2-4	16009SC-4113	HEX.SOCKET BOLT(M10*L25)			O	54	
K-2-5	16029SW-4115	SPRING WASHER (10@)			O	54	
K-2-6	16009SC-8330	TAPPING SCREW (M6*L20)			O	74	
K-2-7	GP-010695-00	TABLE SUPPORT B	Jul,18,05 ~ Aug,10,06	X		2	
	GP-010695-01		Aug,11,06 ~	△		2	
K-2-8	16005RB-A001	Table Support End Cap(L)				28	
K-2-9	05001700U000	TABLE SUPPORT PLATE				32	
K-2-10	05001500UK40	ANGLE SUPPORT				8	
K-2-11	08076SC-4113	HEX. SOCKET BOLT (M5*L12)			O	16	
K-2-12	16019SW-4115	SPRING WASHER (@5)			O	16	
K-2-13	16018SW-1111	WASHER (@5)			O	16	
K-2-14	05010400U000	TABLE SUPPORTER (B2) L=402				2	
K-2-15	05010400U000	TABLE SUPPORTER (B2) L=402				2	
K-2-16	08076SC-4113	HEX. SOCKET BOLT (M5*L12)			O	16	
K-2-17	16019SW-4115	SPRING WASHER (@5)			O	16	
K-2-18	16018SW-1111	WASHER (@5)			O	16	
K-2-19	16052AD-UK01	TABLE SUPPORT GUIDE				4	
K-2-20	02015SC-7113	Hex.Socket Bolt(M4*L10)			O	8	
K-2-21	02028SW-9115	Spring Washer (@4)			O	8	
K-2-22	05009SW-1111	Washer (@4-L)			O	8	
K-2-23	17062SC-UK01	Table Support Stopper Screw			O	4	
K-2-24	05001300U000	TABLE SUPPORT L=263				4	
K-2-25	16061PR-UK01	TABLE SUPPORT PLATE (A)				4	
K-2-26	17012SC-8329	Hex. Socket Set Screw(M4*L16)			O	8	
K-2-27	16058AD-UK01	TABLE SUPPORT PLATE (B)				4	
K-2-28	15089SC-7119	C.S Screw (M4*L12)			O	8	
K-2-29	17063SC-UK01	Table Support Stopper Screw			O	4	
K-2-30	16016PR-UK01	GEAR COVER				3	
K-2-31	02030SC-T121	BED COVER SCREW(9/64" 40)				6	

K1

K-3



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
K-3-1	GP-004901-00	MOVABLE TABLE	Sep,25,04 ~ Apr,25,05	X		2	
	GP-004901-01		Apr,26,05 ~	X		2	
K-3-2	GP-004896-00	FIXED TABLE "A"	Sep,25,04 ~ Apr,25,05	X		1	
	GP-004896-01		Apr,26,05 ~	X		1	
K-3-3	GP-004897-00	FIXED TABLE "B"	Sep,25,04 ~ Apr,25,05	X		1	
	GP-004897-01		Apr,26,05 ~	X		1	
K-3-4	GP-004898-00	FIXED TABLE "C"	Sep,25,04 ~ Apr,25,05	X		1	
	GP-004898-01		Apr,26,05 ~	X		1	
K-3-5	GP-004899-00	FIXED TABLE "D"	Sep,25,04 ~ Apr,25,05	X		1	
	GP-004899-01		Apr,26,05 ~	X		1	
K-3-6	GP-004900-00	FIXED TABLE "E"	Sep,25,04 ~ Apr,25,05	X		1	
	GP-004900-01		Apr,26,05 ~	X		2	
K-3-7	16018PR-UK01	MES CAM DRIVING BOX COVER				2	
K-3-8	02030SC-T121	BED COVER SCREW(9/64" 40)			O	8	
K-3-9	05001400UH60	THREAD CUTTING BOX COVER B				1	
K-3-10	02030SC-T121	BED COVER SCREW(9/64" 40)			O	4	
K-3-11	GP-004903-00	Y-LM Guide Cover A				1	
K-3-12	08101SC-8329	TAPPING SCREW (M3*L16)			O	4	
K-3-13	GP-004904-00	Y-LM Guide Cover B				1	
K-3-14	08101SC-8329	TAPPING SCREW (M3*L16)			O	6	
K-3-15	GP-004905-00	Y-LM Guide Cover C				1	
K-3-16	08101SC-8329	TAPPING SCREW (M3*L16)			O	4	
K-3-17	GP-004906-00	Y-LM Guide Cover D				1	
K-3-18	08101SC-8329	TAPPING SCREW (M3*L16)			O	6	
K-3-19	GP-004910-00	Y-MOTOR COVER				2	
K-3-20	08101SC-8329	TAPPING SCREW (M3*L16)			O	8	
K-3-21	05002400UH60	OP Holder Support Cover (A)				1	
K-3-22	GP-004909-00	OP Holder Support Cover (B)	Sep,25,04 ~ Jun,30,05	X		1	
	GP-004909-01		Jul,01,05 ~	X		1	
K-3-23	08101SC-8329	TAPPING SCREW (M3*L16)			O	4	
K-3-24	16065PR-UK01	CLAMP PLATE				4	
K-3-25	16009SC-8330	Tapping Screw (M6*L20)			O	12	
K-3-26	16067ET-UK01	TABLE TOGGLE CLAMP				12	
K-3-27	16009SC-8330	Tapping Screw (M6*L20)			O	48	
K-3-28	16063PM-UK01	TABLE HOLDING BLOCK				4	
K-3-29	16009SC-8330	TAPPING SCREW (M6*L20)			O	8	
K-3-30	16016PR-UK01	GEAR COVER				3	
K-3-31	02030SC-T121	BED COVER SCREW(9/64" 40)			O	6	

K-4


This exploded view diagram illustrates the assembly of the K-4 unit. The components are labeled as follows:

- K-4-1**: Main base plate.
- K-4-2**: Central support structure.
- K-4-3**: Upper support structure.
- K-4-4**: Lower support structure.
- K-4-5**: Side support structure.
- K-4-6**: Small rectangular component.
- K-4-7**: Screws used for assembly.
- K-4-8**: Long horizontal support bar.
- K-4-9**: Horizontal support bar.
- K-4-10**: Horizontal support bar.
- K-4-11**: Horizontal support bar.
- K-4-12**: Horizontal support bar.
- K-4-13**: Small rectangular component.
- K-4-14**: Small rectangular component.
- K-4-15**: Screws used for assembly.
- K-4-16**: Small rectangular component.
- K-4-17**: Small rectangular component.
- K-4-18**: Small rectangular component.
- K-4-19**: Screws used for assembly.
- K-4-20**: Small rectangular component.
- K-4-21**: Screws used for assembly.
- K-4-22**: Small rectangular component.
- K-4-23**: Screws used for assembly.

Note

K1

K-5



Note


Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
K-5-1	GP-004116-00	MOVABLE TABLE "A"				2	
K-5-2	GP-004117-00	MOVABLE TABLE "B"	Aug,23,04 ~ Apr,26,05	X		2	
	GP-004117-01		Apr,27,05 ~ Aug,31,05	X		2	
	GP-004117-02		Sep,01,05 ~	X		2	
K-5-3	GP-004118-00	MOVABLE TABLE "C"				2	
K-5-4	GP-004119-00	FIXED TABLE "A"	Aug,23,04 ~ Apr,26,05	X		1	
	GP-004119-01		Apr,27,05 ~	X		1	
K-5-5	GP-008894-00	FIXED TABLE "B"				1	
K-5-6	GP-004120-00	FIXED TABLE "C"	Aug,23,04 ~ Apr,26,05	X		1	
	GP-004120-01		Apr,27,05 ~	X		1	
K-5-7	GP-004121-00	FIXED TABLE "D"	Aug,23,04 ~ Apr,26,05	X		1	
	GP-004121-01		Apr,27,05 ~	X		1	
K-5-8	GP-008895-00	FIXED TABLE "H"	Apr,27,05 ~ Jul,19,05	X		1	
	GP-008895-01		Jul,20,05 ~	X		1	
K-5-9	GP-008900-00	FIXED TABLE "I"				1	
K-5-10	GP-004120-00	FIXED TABLE "C"	Aug,23,04 ~ Apr,26,05	X		1	
	GP-004120-01		Apr,27,05 ~	X		1	
K-5-11	16005RB-A001	Fixed Table "D"(3X3공용)				1	
K-5-12	16018PR-UK01	MES CAM DRIVING BOX COVER				2	
K-5-13	02030SC-T121	BED COVER SCREW(9/64" 40)			O	8	
K-5-14	05001400UH60	THREAD CUTTING BOX COVER B				1	
K-5-15	02030SC-T121	BED COVER SCREW(9/64" 40)			O	4	
K-5-16	GP-004127-00	Y-LM Guide Cover A				1	
K-5-17	08101SC-8329	TAPPING SCREW (M3*L16)			O	10	
K-5-18	GP-004129-00	Y-LM Guide Cover C				1	
K-5-19	08101SC-8329	TAPPING SCREW (M3*L16)			O	11	
K-5-20	GP-004130-00	Y-LM Guide Cover D				1	
K-5-21	08101SC-8329	TAPPING SCREW (M3*L16)			O	11	
K-5-22	GP-004131-00	Y-LM Guide Cover E				1	
K-5-23	08101SC-8329	TAPPING SCREW (M3*L16)			O	10	
K-5-24	GP-004132-00	COUPLING COVER				2	
K-5-25	GP-008898-00	Y-LM GUIDE COVER C				1	
K-5-26	08101SC-8329	TAPPING SCREW (M3*L16)			O	9	
K-5-27	GP-008899-00	Y-LM GUIDE COVER D				1	
K-5-28	08101SC-8329	TAPPING SCREW (M3*L16)			O	9	
K-5-29	GP-007514-00	Y-Driving Box Cover B				2	
K-5-30	08101SC-8329	TAPPING SCREW (M3*L16)			O	12	

K1

[illegible]

109

K-6




Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
K-6-1	GP-005174-00	MOVABLE TABLE "A"				2	
K-6-2	GP-005175-00	MOVABLE TABLE "B"				2	
K-6-3	GP-005176-00	MOVABLE TABLE "C"				2	
K-6-4	GP-005177-00	MOVABLE TABLE "D"				2	
K-6-5	GP-004119-00	FIXED TABLE "A"	Aug,23,04 ~ Apr,26,05	X		1	
	GP-004119-01		Apr,27,05	X		1	
K-6-6	05000200NH60	FIXED TABLE "B"				1	
K-6-7	GP-005058-00	FIXED TABLE "C"	Aug,23,04 ~ Apr,26,05	X		2	
	GP-005058-01		Apr,27,05	X		2	
K-6-8	GP-005059-00	FIXED TABLE "D"				2	
K-6-9	GP-004121-00	FIXED TABLE "E"	Aug,23,04 ~ Apr,26,05	X		1	
	GP-004121-01		Apr,27,05 ~	X		1	
K-6-10	GP-004122-00	FIXED TABLE "F"				1	
K-6-11	05000700NH60	FIXED TABLE "G"				1	
K-6-12	GP-004123-00	FIXED TABLE "H"				1	
K-6-13	GP-004124-00	FIXED TABLE "I"				1	
K-6-14	GP-004125-00	FIXED TABLE "J"				1	
K-6-15	16018PR-UK01	MES CAM DRIVING BOX COVER				2	
K-6-16	02030SC-T121	BED COVER SCREW(9/64" 40)			O	8	
K-6-17	05001400UH60	THREAD CUTTING BOX COVER B				1	
K-6-18	02030SC-T121	BED COVER SCREW(9/64" 40)			O	4	
K-6-19	GP-004127-00	Y-LM Guide Cover A				1	
K-6-20	08101SC-8329	TAPPING SCREW (M3*L16)			O	10	
K-6-21	GP-004128-00	Y-LM Guide Cover B	Aug,23,04 ~ Apr,26,05	X		4	
	GP-004128-01		Apr,27,05	X		4	
K-6-22	08101SC-8329	TAPPING SCREW (M3*L16)			O	64	
K-6-23	GP-004129-00	Y-LM Guide Cover C				1	
K-6-24	08101SC-8329	TAPPING SCREW (M3*L16)			O	11	
K-6-25	GP-004130-00	Y-LM Guide Cover D				1	
K-6-26	08101SC-8329	TAPPING SCREW (M3*L16)			O	11	
K-6-27	GP-004131-00	Y-LM Guide Cover E				1	
K-6-28	08101SC-8329	TAPPING SCREW (M3*L16)			O	10	
K-6-29	05001800UH60	COUPLING COVER A				2	
K-6-30	GP-004132-00	COUPLING COVER B				1	
K-6-31	05000120UH80	Y-MOTOR COUPLING COVER R				2	
K-6-32	05000110UH80	Y-MOTOR COUPLING COVER L				2	
K-6-33	08101SC-8329	TAPPING SCREW (M3*L16)			O	16	

[illegible]

Cable




L-3




L-4



L-5



L-1



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
L-1-1	02000400B000	CABLE COVER HOLDER				4	
L-1-2	08076SC-7113	Hex. Socket Bolt (M5*L12)			O	8	
L-1-3	18048SW-3115	Spring Washer (@5)			O	8	
L-1-4	16018SW-1111	Washer (@5)			O	8	
L-1-5	01002600UH60	X-MOTOR CABLE HOLDER				2	
L-1-6	08076SC-7113	Hex. Socket Bolt(M5*L12)			O	4	
L-1-7	16018SW-1111	Washer (@5)			O	4	
L-1-8	02054RB-UK01	Clamp Rubber				2	
L-1-9	02053PR-UK01	Cable Clamp				2	
L-1-10	18013AF-7113	Hex. Socket Bolt(M4*L10)			O	2	
L-1-11	18049SW-3111	Washer (@5)			O	2	
L-1-12	02105700U040	Cable (Sh-57-2)				2	
L-1-13	02105610U040	Sh-56-2				2	
L-1-14	02106000U040	Cable (Sh-60-2)				2	
L-1-15	BD-000310-00	Color Change Board	Dec,05,05 ~ Apr,25,06	X		2	
	BD-000310-01		Apr,26,06 ~ Jun,18,06	△		2	
	BD-000310-02		Jun,19,06 ~ Jul,24,06	△		2	
	BD-000310-03		Jul,25,06 ~ Aug,27,06	△		2	
	BD-000310-04		Aug,28,06 ~ Sep,24,06	△		2	
	BD-000310-05		Sep,25,06 ~ Oct,19,06	△		2	
	BD-000310-06		Oct,20,06 ~ Feb,04,07	△		2	
	BD-000310-07		Feb,05,07 ~ Dec,20,07	△		2	
	BD-000310-08		Dec,21,07 ~ Jan,15,08	△		2	
	BD-000310-09		Jan,16,08 ~ Apr,20,08	△		2	
	BD-000310-10		Apr,21,08 ~ Jan,23,09	△		2	
	BD-000310-11		Jan,23,09 ~ Sep,03,09	△		2	
	BD-000310-12		Sep,03,09 ~ Nov,17,09	△		2	
	BD-000310-13		Nov,17,09 ~ Dec,14,09	△		2	
	BD-000310-14		Dec,14,09 ~	△		2	
L-1-16	02105900U000	Sh-59				2	
L-1-17	BD-000232-00	Thread Sensing Board	Aug,16,05 ~ Sep,29,05	X		6	
	BD-000232-01		Sep,30,05 ~ Nov,02,05	△			
	BD-000232-02		Nov,03,05 ~ Jan,31,06	△			
	BD-000232-03		Feb,01,06 ~ Apr,25,06	△			
	BD-000232-04		Apr,26,06 ~ Jun,30,06	△			
	BD-000232-05		Jul,01,06 ~ Jul,14,06	△			
	BD-000232-06		Jul,15,06 ~ Sep,18,06	△			
	BD-000232-07		Sep,19,06 ~ Oct,19,06	△			
	BD-000232-08		Oct,20,06 ~ Sep,09,07	△			
	BD-000232-09		Sep,10,07 ~ Dec,12,07	△			
	BD-000232-10		Dec,13,07 ~ Dec,20,12	△			

[illegible]

Note

[illegible]


This exploded view diagram illustrates the assembly of the L-2000 Series LED lighting fixture. The main components shown are:

- L-2-1**: Mounting bracket for the main housing.
- L-2-2**: Screw for the mounting bracket.
- L-2-3**: Nut for the mounting bracket.
- L-2-4**: Main housing of the fixture.
- L-2-5**: Screw for the main housing.
- L-2-6**: Mounting bracket for the LED module.
- L-2-7**: LED module.
- L-2-8**: Screw for the LED module.
- L-2-9**: Connector for the LED module.
- L-2-10**: Cable for the LED module.
- L-2-11**: Mounting bracket for the LED module.
- L-2-12**: Cable for the LED module.
- L-2-13**: Nut for the LED module.
- L-2-14**: Mounting bracket for the LED module.
- L-2-15**: Mounting bracket for the LED module.
- L-2-16**: Mounting bracket for the LED module.
- L-2-17**: Screw for the LED module.
- L-2-18**: Mounting bracket for the LED module.
- L-2-19**: Screw for the LED module.
- L-2-20**: Cable for the LED module.

[illegible]

115


L-3




Note

[illegible]

L-4

[illegible]


L-5




Note

[illegible]

CON Box & OP Box



M-1



Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
M-1-1	BD-000311-00	Main Drive (ASSY)(220V)//BD-000312-00(110V)				2	
M-1-2	07-004S-SM5S	Main Drive (ASSY) Screw (set) (M4xL10)				4	
M-1-3	BD-000144-00	XY Driver Board(220V)//BD-000146-00(110V)				4	
M-1-4	GP-013784-00	Driver Radiator				1	
M-1-5	05008AF-4113	XY Driver Board Screw(set) (M4xL16)				12	
M-1-6	05-002S-SW70	PCB Guide (TRCG-3300)				8	
M-1-7	07-004S-SM5S	Driver Radiator Screw(set) (M4xL10)				4	
M-1-8	BD-000306-00	IO MC Board				2	
M-1-9	BD-000343-00	IO LED Board				1	
M-1-10	10-006S-AT10	IO MC Board Connecting Stud (3-5-20)				4	
M-1-11	10-028S-SC53	IO MC Board Screw(set) (M3xL7)				4	
M-1-12	10-028S-SC53	IO LED Board Screw(set) (M3xL7)				4	
M-1-13	GP-014028-01	IO MC Bracket				1	
M-1-14	GP-014027-01	DDC Bracket				1	
M-1-15	GP-013783-00	DDC Radiator				1	
M-1-16	BD-000307-00	DDC Board				1	
M-1-17	BD-000383-00	DDC LED Board				1	
M-1-18	07-005S-SM5S	DDC Radiator Screw(set) (M3xL7)				4	
M-1-19	GP-015654-00	DDC Radiator Sheet				1	
M-1-20	10-028S-SC53	DDC Board Screw(set) (M3xL7)				4	
M-1-21	10-028S-SC53	DDC LED Board Screw(set) (M3xL7)				4	
M-1-22	GP-014029-01	SMPS Bracket				1	
M-1-23	EP-000029-00	SMPS				2	
M-1-24	GP-015653-00	SMPS Radiator				2	
M-1-25	GP-012118-00	SMPS Radiator Sheet				2	
M-1-26	BD-000308-00	UNIT Board				1	
M-1-27	GP-010543-01	SMPS Fixing Stud (3-5-45)				8	
M-1-28	08-002M-SW67	SMPS Fixing Stud (3-5-10)				4	
M-1-29	GP-014042-00	SMPS Fixture				1	
M-1-30	10-028S-SC53	UNIT Board Screw(set) (M3xL7)				4	
M-1-31	07-005S-SM5S	SMPS Radiator Screw(set) (M3xL10)				2	
M-1-32	07-005S-SM5S	SMPS Fixture Screw(set) (M3xL10)				2	
M-1-33	01-005A-BT01	Control Box FAN				1	
M-1-34	SC-000392-00	Control Box FAN Screw (M4xL30)				4	
M-1-35	09-041S-3701	FAN Nut (M4)				4	
M-1-36	GP-014030-01	LAMP Bracket				1	

M-1

Note

Note

M-3


This exploded view diagram illustrates the assembly of the M-3 device. The components are labeled as follows:

- M-3-1**: The main device unit, shown at an angle.
- M-3-13**: The rectangular frame or bezel that surrounds the device.
- M-3-8**, **M-3-9**, and **M-3-10**: Three screws used to secure the frame to the device.
- M-3-11**: A mounting plate or bracket that fits behind the frame.
- M-3-12**: A screw used to secure the mounting plate to the frame.
- M-3-6**: A vertical post or pin that passes through the mounting plate and frame.
- M-3-7**: A screw used to secure the mounting plate to the device.
- M-3-2**: The base mounting plate or bracket that the entire assembly is mounted to.
- M-2-3**, **M-3-4**, and **M-3-5**: Three screws used to secure the base mounting plate to the device.

Dashed lines indicate the alignment and assembly path for the components.


Note

LAMP & SWITCH



127

Bobbin Winder



O




08000010B000 : Bobbin Winder Assy

130


O

131

COVER



P-1




Note

Ref.No	Part No.	Part Name	Application date	Interchangeability	Hardware	Q'ty	Remarks
P-1-1	GP-008790-00	BODY SIDE COVER				2	
P-1-2	02044SC-3123	TRUSS SCREW (M5*L8)			O	20	
P-1-3	01000300UH61	BEAM BRACKET COVER (L)				1	
P-1-4	01000400UH61	BEAM BRACKET COVER (R)				1	
P-1-5	02044SC-3123	TRUSS SCREW (M5*L8)			O	18	
P-1-6	02054PR-A001	MAIN MOTOR PULLEY COVER				1	
P-1-7	02044SC-3123	TRUSS SCREW (M5*L8)			O	1	
P-1-8	01000500UH61	BODY FRONT COVER A				1	
P-1-9	01000600UH61	BODY FRONT COVER B				1	
P-1-10	01000700UH61	BODY FRONT COVER C				2	
P-1-11	GP-0041110-00	BODY FRONT COVER D				1	
P-1-12	GP-0041111-00	BODY FRONT COVER E				1	
P-1-13	01001000UH61	BODY FRONT COVER F				1	
P-1-14	01001100UH61	BODY FRONT COVER G				1	
P-1-15	02044SC-3123	TRUSS SCREW (M5*L8)			O	24	
P-1-16	01002900UH60	TABLE SUPPORT (A)				2	
P-1-17	GP-0041115-00	TABLE SUPPORT (C)				2	
P-1-18	05001400UH80	TABLE SUPPORT ANGLE B L399				4	
P-1-19	GP-016753-00	BODY INSIDE COVER A				1	
P-1-20	02044SC-3123	TRUSS SCREW (M5*L8)			O	40	
P-1-21	GP-005688-00	BODY INSIDE COVER C	Nov,18,04 ~ Apr,24,05	x		1	
	GP-005688-01		Apr,25,05 ~	X		1	
P-1-22	GP-007852-00	BODY INSIDE COVER B	Mar,05,05 ~ Apr,24,05	X		1	
	GP-007852-01		Apr,25,05 ~	X		1	
P-1-23	GP-008893-00	BODY INSIDE COVER B				1	
P-1-24	02101ET-UK01	BRAND MARK				1	
P-1-25	08000205UH61	Model Mark				1	
P-1-26	GP-005982-00	CABLE COVER FOR OP SUPPORT				2	
P-1-27	02044SC-3123	TRUSS SCREW (M5*L8)			O	4	
P-1-28	02097ET-B001	MODEL NAME PLATE				1	
P-1-29	02010SC-3123	TRUSS SCREW (M4*L8)			O	4	

P

134

FRAME (UH1504D-45)



Q1

136

This exploded view diagram illustrates the components of the Q1-2-1 LED light fixture. The main housing, labeled Q1-2-1, is shown in a dashed outline. The internal LED panel, Q1-2-2, is positioned to be inserted into the housing. The panel is secured by a bracket, Q1-2-3, which is attached to the housing with screws, Q1-2-4. The panel itself features a mounting bracket, Q1-2-5, and a series of LED chips, Q1-2-6. The panel is also secured by a bracket, Q1-2-7, which is attached to the housing with screws, Q1-2-8. The panel is also secured by a bracket, Q1-2-9, which is attached to the housing with screws, Q1-2-10. The panel is also secured by a bracket, Q1-2-11, which is attached to the housing with screws, Q1-2-12.

[illegible]

Q1-3

This diagram illustrates the exploded view of the Q1-3 assembly, showing the relationship between various components. The main structure consists of a rectangular frame formed by rails and end plates. Key components include:


- Q1-3-1**: A long horizontal rail.
- Q1-3-2**: A long horizontal rail.
- Q1-3-3**: A vertical rail.
- Q1-3-4**: A vertical rail.
- Q1-3-5**: A small vertical rail.
- Q1-3-6**: A small vertical rail.
- Q1-3-7**: A small vertical rail.
- Q1-3-8**: A small vertical rail.
- Q1-3-9**: A small vertical rail.
- Q1-3-10**: A small vertical rail.
- Q1-3-11**: A small vertical rail.
- Q1-3-12**: A small vertical rail.
- Q1-3-13**: A small vertical rail.
- Q1-3-14**: A small vertical rail.
- Q1-3-15**: A small vertical rail.
- Q1-3-16**: A small vertical rail.
- Q1-3-17**: A small vertical rail.
- Q1-3-18**: A small vertical rail.

The diagram shows how these components are assembled together, with various fasteners and connectors used to secure the structure. The exploded view allows for a clear understanding of the assembly process and the placement of each part.

Note

Q1

FRAME (UH1506D-45)



Q2-1

This diagram illustrates the exploded view of the Q2-1 assembly. The main component is a long, narrow metal rail (Q2-1-1) with a central track. It is supported by two large, L-shaped brackets (Q2-1-3). The rail is secured by several screws: Q2-1-4, Q2-1-5, and Q2-1-6 at the top left; Q2-1-12 at the top right; and Q2-1-10, Q2-1-11, and Q2-1-7 at the bottom right. A small component (Q2-1-8) is shown near the bottom right bracket. The diagram also shows a smaller assembly (Q2-1-2) at the bottom right, which includes a bracket (Q2-1-2) and a screw (Q2-1-8). A dashed line indicates the connection between the main rail and the smaller assembly.

Note

Q2

Q2-2

Q2-2-2
Q2-2-10

Q2-2-4
Q2-2-13

Q2-2-5
Q2-2-14

Q2-2-3
Q2-2-11

Q2-2-1
Q2-2-15

Q2-2-7

Q2-2-8

Q2-2-9

Q2-2-6
Q2-2-16

Q2-2-5
Q2-2-12

Note

Q2

Q2-3


This exploded view diagram illustrates the assembly of the Q2-3 frame. The components are labeled as follows:

- Q2-3-1**: Long horizontal frame rail.
- Q2-3-2**, **Q2-3-3**: Small pins or spacers for the top rail.
- Q2-3-4**, **Q2-3-5**, **Q2-3-6**: Small pins or spacers for the bottom rail.
- Q2-3-7**: Long horizontal frame rail (bottom).
- Q2-3-8**: Vertical frame rail (right).
- Q2-3-9**: L-shaped corner bracket.
- Q2-3-10**: Small pins or spacers for the corner brackets.
- Q2-3-11**: Small pins or spacers for the corner brackets.
- Q2-3-12**: Small pins or spacers for the corner brackets.
- Q2-3-13**: Small pins or spacers for the corner brackets.
- Q2-3-14**: Small pins or spacers for the corner brackets.
- Q2-3-15**: Small pins or spacers for the corner brackets.
- Q2-3-16**: Small pins or spacers for the corner brackets.
- Q2-3-17**: Small pins or spacers for the corner brackets.
- Q2-3-18**: Small pins or spacers for the corner brackets.
- Q2-3-19**: Small pins or spacers for the corner brackets.
- Q2-3-20**: Small pins or spacers for the corner brackets.
- Q2-3-21**: Small pins or spacers for the corner brackets.

Note

Q2

FRAME (UH1508D-45)



This diagram illustrates the exploded view of the Q3-1 assembly, showing the main frame and various sub-components. The components are labeled as follows:

- Main Frame:** Q3-1-1
- Top Rail:** Q3-1-2
- Bottom Rail:** Q3-1-3
- End Caps:** Q3-1-4, Q3-1-5
- Mounting Brackets:** Q3-1-6, Q3-1-7, Q3-1-8, Q3-1-9, Q3-1-10, Q3-1-11, Q3-1-12, Q3-1-13, Q3-1-14, Q3-1-15, Q3-1-16, Q3-1-17, Q3-1-18, Q3-1-19, Q3-1-20, Q3-1-21, Q3-1-22, Q3-1-23, Q3-1-24
- Fasteners:** Q3-1-10, Q3-1-11, Q3-1-12, Q3-1-13, Q3-1-14, Q3-1-15, Q3-1-16, Q3-1-17, Q3-1-18, Q3-1-19, Q3-1-20, Q3-1-21, Q3-1-22, Q3-1-23, Q3-1-24

The diagram shows the assembly sequence and the relative positions of the components. The main frame (Q3-1-1) is the central component, with the top rail (Q3-1-2) and bottom rail (Q3-1-3) attached to it. The end caps (Q3-1-4, Q3-1-5) are shown at the ends of the rails. The mounting brackets (Q3-1-6 to Q3-1-24) are shown in their respective positions, with fasteners (Q3-1-10 to Q3-1-24) used to secure them.

Note

Page 10 of 10

Q3-2

This diagram illustrates the exploded view of the Q3-2 door assembly. The components are labeled as follows:

- Q3-2-1**: The main door frame or outer casing.
- Q3-2-2**: A rectangular plate or bracket.
- Q3-2-3**: A small screw or fastener.
- Q3-2-4**: A small rectangular component, possibly a hinge or latch part.
- Q3-2-5**: The inner door panel or liner.
- Q3-2-6**: A large screw or bolt.
- Q3-2-7**: A small screw or fastener.
- Q3-2-8**: A small screw or fastener.
- Q3-2-9**: A small screw or fastener.

The diagram shows the spatial relationship between these parts, indicating how they are assembled into the final door unit.

Note

Q3

Q3-3

This exploded view diagram illustrates the assembly of the Q3-3 LED display. The main components shown are:


- Q3-3-1:** The central LED display panel.
- Q3-3-2:** The front bezel or frame.
- Q3-3-3:** The rear bezel or frame.
- Q3-3-4:** Corner mounting brackets.
- Q3-3-5:** Screws for mounting the bezels.
- Q3-3-6:** Mounting brackets for the rear bezel.
- Q3-3-7:** Screws for mounting the rear bezel.
- Q3-3-8:** Screws for mounting the front bezel.
- Q3-3-9:** Screws for mounting the corner brackets.
- Q3-3-10:** Screws for mounting the rear bezel.
- Q3-3-11:** Screws for mounting the rear bezel.
- Q3-3-12:** Screws for mounting the rear bezel.
- Q3-3-13:** Screws for mounting the rear bezel.
- Q3-3-14:** Screws for mounting the rear bezel.
- Q3-3-15:** Screws for mounting the rear bezel.
- Q3-3-16:** Screws for mounting the rear bezel.
- Q3-3-17:** A support stand or base.
- Q3-3-18:** A horizontal support bar.

The diagram shows the assembly process, with components being mounted onto the main display panel and bezels. The exploded view allows for a clear understanding of the relative positions and assembly sequence of the parts.

Note

Q3

FRAME (UH1512D-45)



This exploded view diagram illustrates the assembly of the Q4-1 system. The main components and their assembly sequence are as follows:

- Q4-1-1**: The main horizontal rail assembly.
- Q4-1-2**: A circular component that fits into the rail.
- Q4-1-3**: A small rectangular component that fits into the rail.
- Q4-1-4** and **Q4-1-5**: Two small rectangular components that fit into the rail.
- Q4-1-6**: A small rectangular component that fits into the rail.
- Q4-1-7**: A small rectangular component that fits into the rail.
- Q4-1-8**: A small rectangular component that fits into the rail.
- Q4-1-9**: A small rectangular component that fits into the rail.
- Q4-1-10**: A small rectangular component that fits into the rail.
- Q4-1-11**: A small rectangular component that fits into the rail.
- Q4-1-12**: A small rectangular component that fits into the rail.
- Q4-1-13**: A small rectangular component that fits into the rail.
- Q4-1-14**: A small rectangular component that fits into the rail.
- Q4-1-15**: A small rectangular component that fits into the rail.
- Q4-1-16**: A small rectangular component that fits into the rail.
- Q4-1-17**: A small rectangular component that fits into the rail.
- Q4-1-18**: A small rectangular component that fits into the rail.
- Q4-1-19**: A small rectangular component that fits into the rail.
- Q4-1-20**: A small rectangular component that fits into the rail.
- Q4-1-21**: A small rectangular component that fits into the rail.
- Q4-1-22**: A small rectangular component that fits into the rail.
- Q4-1-23**: A small rectangular component that fits into the rail.
- Q4-1-24**: A small rectangular component that fits into the rail.
- Q4-1-25**: A small rectangular component that fits into the rail.
- Q4-1-26**: A small rectangular component that fits into the rail.

[illegible]

Q4-2

The diagram illustrates the assembly of the Q4-2 device, showing two main components, Q4-2-1 and Q4-2-5, and their associated sub-components.

Component Q4-2-1 (Top):

- Q4-2-1: The main upper housing.
- Q4-2-4: A small rectangular component located inside the housing.
- Q4-2-12: A small rectangular component located inside the housing, adjacent to Q4-2-4.
- Q4-2-2: A small rectangular component located on the side of the housing.
- Q4-2-10: A small rectangular component located on the side of the housing, adjacent to Q4-2-2.
- Q4-2-3: A small rectangular component located on the side of the housing.
- Q4-2-11: A small rectangular component located on the side of the housing, adjacent to Q4-2-3.

Component Q4-2-5 (Bottom):

- Q4-2-5: The main lower housing.
- Q4-2-8: A small rectangular component located on the side of the housing.
- Q4-2-7: A small rectangular component located on the side of the housing, adjacent to Q4-2-8.
- Q4-2-9: A small rectangular component located on the side of the housing.
- Q4-2-6: A small rectangular component located on the side of the housing.
- Q4-2-13: A small rectangular component located on the side of the housing, adjacent to Q4-2-6.

Note

Q4

Q4-3

This exploded view diagram illustrates the assembly of the Q4-3 LED display. The components are labeled as follows:

- Q4-3-1**: Main display panel.
- Q4-3-2**: Longitudinal support rail.
- Q4-3-3**: L-shaped corner support bracket.
- Q4-3-4**: L-shaped corner support bracket.
- Q4-3-5**: L-shaped corner support bracket.
- Q4-3-6**: L-shaped corner support bracket.
- Q4-3-7**: L-shaped corner support bracket.
- Q4-3-8**: L-shaped corner support bracket.
- Q4-3-9**: L-shaped corner support bracket.
- Q4-3-10**: L-shaped corner support bracket.
- Q4-3-11**: Longitudinal support rail.
- Q4-3-12**: Longitudinal support rail.
- Q4-3-13**: Longitudinal support rail.
- Q4-3-14**: Longitudinal support rail.
- Q4-3-15**: Longitudinal support rail.
- Q4-3-16**: Longitudinal support rail.
- Q4-3-17, 18, 19**: Longitudinal support rail.
- Q4-3-20**: Longitudinal support rail.

The diagram shows the assembly of the display panel (Q4-3-1) onto the support rails (Q4-3-2, Q4-3-11, Q4-3-12, Q4-3-13, Q4-3-14, Q4-3-15, Q4-3-16, Q4-3-17, 18, 19, Q4-3-20) using the corner brackets (Q4-3-3, Q4-3-4, Q4-3-5, Q4-3-6, Q4-3-7, Q4-3-8, Q4-3-9, Q4-3-10) and the support rails (Q4-3-11, Q4-3-12, Q4-3-13, Q4-3-14, Q4-3-15, Q4-3-16, Q4-3-17, 18, 19, Q4-3-20).

Note

Q4

R. Index

Part No.	Part Name	Page	Ref.No
08076SC-4113	HEX. SOCKET BOLT (M5*L12)	76	H3-4-18
08076SC-4113	HEX. SOCKET BOLT (M5*L12)	76	H3-4-31
08076SC-4113	HEX. SOCKET BOLT (M5*L12)	105	K-2-11
08076SC-4113	HEX. SOCKET BOLT (M5*L12)	105	K-2-16
08076SC-7113	Hex. Socket Bolt (M5*L12)	24	C-4-6
08076SC-7113	Hex. Socket Bolt (M5*L12)	60	H1-4-17
08076SC-7113	Hex. Socket Bolt (M5*L12)	60	H1-4-30
08076SC-7113	Hex. Socket Bolt (M5*L15)	64	H2-1-10
08076SC-7113	Hex. Socket Bolt (M5*L12)	68	H2-4-17
08076SC-7113	Hex. Socket Bolt (M5*L15)	72	H3-1-10
08076SC-7113	Hex. Socket Bolt (M5*L12)	85	H4-4-18
08076SC-7113	Hex. Socket Bolt (M5*L12)	113	L-1-2
08076SC-7113	Hex. Socket Bolt (M5*L12)	113	L-1-6
08087SC-7113	Hex. Socket Bolt (M8*L25)	25	C-5-2
08091SC-7113	HEX. SOCKET BOLT (M6*L20)	33	E-1-2
08091SC-7113	HEX. SOCKET BOLT (M6*L20)	35	E-3-5
08091SC-7113	Hex. Socket Bolt (M6*L20)	35	E-3-22
08091SC-7113	HEX. SOCKET BOLT (M6*L20)	36	E-4-2
08091SC-7113	HEX. SOCKET BOLT (M6*L20)	39	E1-1-2
08091SC-7113	HEX. SOCKET BOLT (M6*L20)	41	E1-3-5
08091SC-7113	Hex. Socket Bolt (M6*L20)	41	E1-3-22
08091SC-7113	HEX. SOCKET BOLT (M6*L20)	42	E1-4-2
08091SC-7113	Hex. Socket Bolt (M6*L20)	57	H1-1-45
08091SC-7113	Hex. Socket Bolt (M6*L20)	58	H1-2-10
08091SC-7113	Hex. Socket Bolt (M6*L20)	66	H2-2-15
08091SC-7113	Hex. Socket Bolt (M6*L20)	74	H3-2-15
08091SC-7113	Hex. Socket Bolt (M6*L20)	82	H4-1-45
08091SC-7113	Hex. Socket Bolt (M6*L20)	83	H4-2-10
08091SC-7113	Hex. Socket Bolt (M6*L20)	125	N-1-6
08100100UH60	Tubular Frame L2404	148	Q4-1-1
08101SC-8329	TAPPING SCREW (M3*L16)	106	K-3-12
08101SC-8329	TAPPING SCREW (M3*L16)	106	K-3-14
08101SC-8329	TAPPING SCREW (M3*L16)	106	K-3-16
08101SC-8329	TAPPING SCREW (M3*L16)	106	K-3-18
08101SC-8329	TAPPING SCREW (M3*L16)	106	K-3-20
08101SC-8329	TAPPING SCREW (M3*L16)	106	K-3-23
08101SC-8329	TAPPING SCREW (M3*L16)	107	K-4-7
08101SC-8329	TAPPING SCREW (M3*L16)	108	K-5-17
08101SC-8329	TAPPING SCREW (M3*L16)	108	K-5-19
08101SC-8329	TAPPING SCREW (M3*L16)	108	K-5-21
08101SC-8329	TAPPING SCREW (M3*L16)	108	K-5-23
08101SC-8329	TAPPING SCREW (M3*L16)	108	K-5-26
08101SC-8329	TAPPING SCREW (M3*L16)	108	K-5-28
08101SC-8329	TAPPING SCREW (M3*L16)	108	K-5-30
08101SC-8329	TAPPING SCREW (M3*L16)	109	K-5-33
08101SC-8329	TAPPING SCREW (M3*L16)	110	K-6-20
08101SC-8329	TAPPING SCREW (M3*L16)	110	K-6-22
08101SC-8329	TAPPING SCREW (M3*L16)	110	K-6-24
08101SC-8329	TAPPING SCREW (M3*L16)	110	K-6-26
08101SC-8329	TAPPING SCREW (M3*L16)	110	K-6-28
08101SC-8329	TAPPING SCREW (M3*L16)	110	K-6-33
08102300B000	Half Turn Sensor (Gp1S51V)	49	F-3-17
08102300B000	Half Turn Sensor (Gp1S51V)	61	H1-5-21

Part No.	Part Name	Page	Ref.No
08102EL-A001	Zero Point Sensor Ass'Y	29	D-3-12
08113SC-A001	Collar Screw	12	A-2-5
08113SC-A001	COLLAR SCREW 11/64,N=40,L6	16	B-3-15
08113SC-A001	Collar Screw	49	F-3-8
08113SC-A001	Collar Screw	49	F-3-16
08113SC-A001	Collar Screw	50	F-4-8
08122CW-A001	MES PIN	30	D-4-15
08122CW-UK01	Lever Pin "B"	31	D-5-11
08123CW-T121	MOVING MES CONNECTING LINK PIN	30	D-4-16
08200002I000	Head Assy 6c	46	F-1-32
08200003I000	Head Assy 9c	46	F-1-32
08200004I000	Head Assy 12c	46	F-1-32
08200100UH00	Tubular Frame (320*435)	141	Q2-2-2
08200100UH00	Tubular (Inner) 45*44	145	Q3-2-1
08200100UH00	Tubular (Inner)	149	Q4-2-1
08200200UH00	Tubular Frame (320*435)	141	Q2-2-1
08200200UH00	Tubular (Outer) 45*44	145	Q3-2-5
08200200UH00	Tubular (Outer)	149	Q4-2-5
08200300UH00	Tubular Frame Holder (L)	141	Q2-2-11
08200300UH00	Tubular Frame Holder (L)	149	Q4-2-10
08200400UH00	Tubular Frame Holder (R)	141	Q2-2-13
08200400UH00	Tubular Frame Holder (R)	149	Q4-2-12
08200500I000	PRESSER FOOT	45	F-1-19
08200503A000	Take-Up Lever Shaft (9C)	47	F-2-17
08200700H000	Needle Bar Felt	45	F-1-10
08200800A000	Take-Up Lever Shaft Bush(R)	47	F-2-23
08200900I000	Presser Foot Holder A'ssy	45	F-1-20
08201000I000	Needle Bar Return Spring	45	F-1-18
08201200H000	Presser Foot Cushion Rubber A	45	F-1-25
08201303I000	Head Rail 9C	45	F-1-4
08201400H000	Needle Bar Holder	45	F-1-15
08201600H000	NEEDLE FIXED HOLDER	46	F-1-26
08202000A000	Tension Plate Holder (9C)	52	G-1-16
08202000I000	Tension Plate Holder (12C)	52	G-1-16
08203000A000	Take-Up Lever Shaft Bush(L)	27	D-1-2
08203000A000	Take-Up Lever Shaft Bush(L)	47	F-2-22
08300100UH00	Square Frame "A" L=2544	150	Q4-3-1
08300103I000	Tension Unit	52	G-1-2
08300200UH00	Square Frame "B" L=2544	150	Q4-3-2
08300203I000	Board Base	53	G-2-10
08300300UH00	Connecting Plate "E"	146	Q3-3-4
08300300UH00	Connect Plate (E)	150	Q4-3-6
08300303I000	Insert Bush. Connecting Plate "A"	54	G-3-5
08300400A000	Lamp Cover	53	G-2-17
08300403I000	Insert Bush. Connecting Plate "B"	54	G-3-6
08300703I000	Roller Base Ass'y	53	G-2-2
08300800B000	Thread Breakage Wheel	53	G-2-3
08308300B000	Thread Detecting Wheel Stud "B"	53	G-2-5
08310000B000	Tension Adjusting Set	52	G-1-14
08320000I000	Sub Tension Adjusting Set	52	G-1-5
08500000I000	Upper Thread Catcher Assy	92	I-2-19
08500000I000	Upper Thread Catcher Assy	98	I1-2-19
08600003B000	Upper Thread Presser Base Assy 9C	93	I-3-11

Part No.	Part Name	Page	Ref.No
08600004B000	Upper Thread Presser Base Assy 12C	93	I-3-11
08600005B000	Upper Thread Presser Base Assy 15C	93	I-3-11
09000100U000	Tubular Frame Fixing Screw	136	Q1-1-20
09000100U000	Tubular Frame Fixing Screw	138	Q1-3-18
09000100U000	Tubular Frame Fixing Screw	140	Q2-1-12
09000100U000	Tubular Frame Fixing Screw	144	Q3-1-10
09000100U000	Tubular Frame Fixing Screw	148	Q4-1-10
09000100U000	Tubular Frame Fixing Screw	150	Q4-3-16
09000103UH00	Top Shaft Cover "A-4" (9C)	128	N-4-13
09000104UH00	Top Shaft Cover "A-4" (12C)	128	N-4-13
09000105UH00	Top Shaft Cover "A-4" (15C)	128	N-4-13
09000200H000	TOP SHAFT COVER BRACKET (L)	128	N-4-1
09000203UH00	Top Shaft Cover "A-3" (9C)	128	N-4-12
09000203UH60	Top Shaft Cover "A-2" (9C)	128	N-4-11
09000204UH00	Top Shaft Cover "A-3" (12C)	128	N-4-12
09000204UH60	Top Shaft Cover "A-2" (12C)	128	N-4-11
09000205UH00	Top Shaft Cover "A-3" (15C)	128	N-4-12
09000205UH60	Top Shaft Cover "A-2" (15C)	128	N-4-11
09000303UH00	Top Shaft Cover "A-1" (9C)	128	N-4-10
09000304UH00	Top Shaft Cover "A-1" (12C)	128	N-4-10
09000305UH00	Top Shaft Cover "A-1"	128	N-4-10
09000415UH00	SURFACE COVER L287	127	N-3-14
09000600UH60	M/C STARTING BRACKET	115	L-2-6
09000700U000	BALLAST	125	N-1-19
09005SC-3123	Truss Screw (M3*L6)	17	B-4-14
09005SC-3123	Truss Bolt (M3*L5)	47	F-2-11
09005SC-3123	Truss Screw (M3*L6)	52	G-1-9
09005SC-3123	Truss Screw (M3*L6)	52	G-1-12
09005SC-3123	Truss Screw (M3*L6)	53	G-2-16
09005SC-3123	Truss Screw (M3*L6)	54	G-3-7
09005SC-3123	TRUSS SCREW (M3*L6)	127	N-3-19
09-012S-CE53	Earth Sticker	122	M-2-25
09018EL-UK01	Sensor	64	H2-1-18
09018EL-UK01	Sensor	72	H3-1-18
09-023C-SC53	QC Passed Sticker	122	M-2-20
09026PR-AB00	Upper Thread Presser Base 12C	93	I-3-1
09026PR-AB00	Upper Thread Presser Base 12C	99	I1-3-1
09027ET-AB00	Velcro (12C)	93	I-3-2
09027ET-AB00	Velcro (12C)	99	I1-3-2
09027ET-T151	Velcro (15C)	93	I-3-2
09027ET-T151	Velcro (15C)	99	I1-3-2
09029PR-AB00	Presser Base Cover (12C)	93	I-3-3
09029PR-AB00	Presser Base Cover (12C)	99	I1-3-3
09029PR-T151	Presser Base Cover (15C)	93	I-3-3
09029PR-T151	Presser Base Cover (15C)	99	I1-3-3
09030PR-A002	Upper Thread Presser Base 9C	93	I-3-1
09030PR-A002	Upper Thread Presser Base 9C	99	I1-3-1
09031ET-A002	Velcro (9C)	93	I-3-2
09031ET-A002	Velcro (9C)	99	I1-3-2
09033PR-A002	Presser Base Cover (9C)	93	I-3-3
09033PR-A002	Presser Base Cover (9C)	99	I1-3-3
09038CW-A001	Thread Presser Space	93	I-3-5
09038CW-A001	Thread Presser Space	99	I1-3-5

R. Index

Part No.	Part Name	Page	Ref.No
09040PR-A001	Bracket (L)	93	I-3-6
09040PR-A001	Bracket (L)	99	I1-3-6
09041PR-A001	Bracket (R)	93	I-3-7
09041PR-A001	Bracket (R)	99	I1-3-7
09-041S-3701	FAN Nut (M4)	120	M-1-35
09044PR-A001	Upper Thread Holder Disk Set	93	I-3-10
09044PR-A001	Upper Thread Holder Disk Set	99	I1-3-10
09052PR-T151	Upper Thread Presser Base 15C	93	I-3-1
09052PR-T151	Upper Thread Presser Base 15C	99	I1-3-1
09100000U000	Attachment (R)	136	Q1-1-21
09100000U000	Attachment (R)	144	Q3-1-17
09100000U000	Attachment (R)	148	Q4-1-20
09100100U000	Attachment (R)	136	Q1-1-10
09100100U000	Attachment (R)	144	Q3-1-15
09100100U000	Attachment (R)	148	Q4-1-11
09100200U000	Fixed Clip Bracket Screw	136	Q1-1-14
09100200U000	Fixed Clip Bracket Screw	144	Q3-1-13
09100200U000	Fixed Clip Bracket Screw	148	Q4-1-15
09100200UHF0	Attachment(R) - Set	140	Q2-1-2
09100300UHF0	Attachment(L) - Set	140	Q2-1-3
09100410U000	Attachment (Set-L)	136	Q1-1-23
09100410U000	Attachment (Set-L)	144	Q3-1-23
09100410U000	Attachment (Set-L)	148	Q4-1-25
09100510U000	Attachment (Set-R)	136	Q1-1-24
09100510U000	Attachment (Set-R)	144	Q3-1-24
09100510U000	Attachment (Set-R)	148	Q4-1-26
09200000U000	Attachment (L)	136	Q1-1-22
09200000U000	Attachment (L)	144	Q3-1-18
09200000U000	Attachment (L)	148	Q4-1-21
09200100U000	Attachment (L)	136	Q1-1-11
09200100U000	Attachment (L)	144	Q3-1-16
09200100U000	Attachment (L)	148	Q4-1-12
09600300UH60	Square Frame Connecting Plate	142	Q2-3-1
10000100A000	THREAD GUIDE L=200	101	J-1-18
10-003M-PT01	Side Cover Screw (M4xL8)	122	M-2-8
10-005A-DU33	Earth Plate	122	M-2-12
10-006S-AT10	IO MC Board Connecting Stud (3-5-20)	120	M-1-10
10009EL-A002	UPPER THREAD CATCHER SOL.	22	C-2-11
10010SC-8119	Plus Screw (M3*L5)	138	Q1-3-8
10010SC-8119	Plus Screw (M3*L5)	142	Q2-3-11
10010SC-8119	Plus Screw (M3*L5)	146	Q3-3-9
10010SC-8119	Plus Screw (M3*L5)	150	Q4-3-9
10011SC-8119	Plus Screw (M3*L6)	137	Q1-2-4
10011SC-8119	Plus Screw (M3*L6)	141	Q2-2-5
10011SC-8119	Plus Screw (M3*L6)	145	Q3-2-3
10011SC-8119	Plus Screw (M3*L6)	149	Q4-2-3
10-021B-DU33	DUAL Sticker(9)	122	M-2-24
10-028S-CS53	LAMP Board Screw(set) (M3xL7)	121	M-1-39
10-028S-CS53	Wiper Motor Driver Screw(set) (M3xL7)	121	M-1-40
10-028S-CS53	IO MC Board Screw(set) (M3xL7)	120	M-1-11
10-028S-CS53	IO LED Board Screw(set) (M3xL7)	120	M-1-12
10-028S-CS53	DDC Board Screw(set) (M3xL7)	120	M-1-20
10-028S-CS53	DDC LED Board Screw(set) (M3xL7)	120	M-1-21

Part No.	Part Name	Page	Ref.No
10-028S-CS53	UNIT Board Screw(set) (M3xL7)	120	M-1-30
10110000A000	Eyelet "B" (12C)	47	F-2-7
10200100H000	Thread Guide Bush "A-1"	47	F-2-2
10200103B000	Head Face Plate (U) 9C	47	F-2-1
10300003A000	Thread Guide (M) Set (9C)	47	F-2-4
10300004A000	Thread Guide (M) Set (12C)	47	F-2-4
10300005A000	Thread Guide (M) Set (15C)	47	F-2-4
10500110B000	SCREW BUSH C (M8*P0.75)	148	Q4-1-6
10600100H000	THREAD ANGLE FRAME	102	J-1-1
10600110B000	SUB TENSION ADJUSTING SET	102	J-1-10
10600210B000	SUB TENSION ADJUSTING SET	102	J-1-11
10900003I000	Thread Holding Device A'ssy	47	F-2-13
11000110UH00	LAMP BRACKET	125	N-1-5
11005CW-UK01	SPOOL PLATE FIXING BOLT M6*L21	101	J-1-3
11009PR-B001	Thread Breakage Detecting Plate	52	G-1-8
11009SC-A001	Stud Screw	54	G-3-8
11012PR-B001	Thread Guide	47	F-2-10
11012PR-B001	Thread Guide (New)	52	G-1-11
11014SN-1211	Hex.Nut (M3-No2)	29	D-3-6
11014SN-1211	Hex.Nut (M3-No2)	52	G-1-10
11014SN-1211	Hex.Nut (M3-No2)	52	G-1-13
11019SW-9115	Spring Washer (3@)	23	C-3-21
11019SW-9115	Spring Washer (3@)	57	H1-1-53
11019SW-9115	Spring Washer (3@)	59	H1-3-10
11019SW-9115	Spring Washer (3@)	60	H1-4-9
11019SW-9115	Spring Washer (3@)	61	H1-5-5
11019SW-9115	Spring Washer (3@)	65	H2-1-53
11019SW-9115	Spring Washer (3@)	67	H2-3-10
11019SW-9115	Spring Washer (3@)	73	H3-1-53
11019SW-9115	Spring Washer (3@)	75	H3-3-10
11019SW-9115	SPRING WASHER (3@)	76	H3-4-9
11019SW-9115	SPRING WASHER (3@)	78	H3-6-28
11019SW-9115	Spring Washer (3@)	82	H4-1-53
11019SW-9115	Spring Washer (3@)	84	H4-3-10
11019SW-9115	Spring Washer (3@)	85	H4-4-9
11019SW-9115	SPRING WASHER (3@)	87	H4-6-30
11020PM-B001	Tension Plate Holder (15C)	52	G-1-16
11021SC-4113	Hex. Socket Bolt (M4*L35)	52	G-1-17
11029SC-4113	Hex. Socket Bolt (M4*L20)	56	H1-1-25
11029SC-4113	Hex. Socket Bolt (M4*L20)	64	H2-1-25
11029SC-4113	Hex. Socket Bolt (M4*L20)	72	H3-1-25
11029SC-4113	Hex. Socket Bolt (M4*L20)	81	H4-1-25
11029SC-4113	Hex. Socket Bolt (M4*L20)	92	I-2-13
11029SC-4113	Hex. Socket Bolt (M4*L20)	98	I1-2-13
11029SC-4113	Hex. Socket Bolt (M4*L20)	136	Q1-1-4
11029SC-4113	Hex. Socket Bolt (M4*L20)	144	Q3-1-4
11029SC-4113	Hex. Socket Bolt (M4*L20)	148	Q4-1-4
11032PR-T151	CABLE SUPPORTER	54	G-3-3
11047PR-A002	Cable Support "B"	47	F-2-24
11049SC-A001	Board Stud Bolt	114	L-1-18
11075PM-B001	Thread Sensor Roller(B1)Set	53	G-2-1
11083CW-B001	Thread Detecting Wheel Stud "A"	53	G-2-6
11101200T000	Upper Dead Point Stopper	45	F-1-13

Part No.	Part Name	Page	Ref.No
116410S-8118	Driver Screw 11/64-40,L10	94	I-4-18
116410S-8118	Driver Screw 11/64-40,L10	94	I-4-19
12001703I000	Head Face Plate(L) (9C)	47	F-2-9
12001704I000	Head Face Plate(L) (12C)	47	F-2-9
12001900U060	Upper Thread Hook Motor Cover	91	I-1-42
12001900U060	Upper Thread Hook Motor Cover	97	I1-1-42
12004PR-W121	SPOOL PLATE SUPPORT BASE	101	J-1-7
12010SN-1211	Hex.Nut (M5)	49	F-3-23
12010SN-1211	Hex.Nut (M5)	59	H1-3-17
12010SN-1211	Hex.Nut (M5)	67	H2-3-17
12010SN-1211	Hex.Nut (M5)	75	H3-3-17
12010SN-1211	Hex.Nut (M5)	84	H4-3-17
12010SN-1211	HEX.NUT (M5)	101	J-1-13
12012PM-A001	SPOOL HOLDER	101	J-1-8
12012-PM-A001	Spool Holder	130	O-1-5
12015SF-A001	SPOOL STAND (L=330)	101	J-1-17
12017PU-T121	Timing Pulley "A"	60	H1-4-11
12017PU-T121	Timing Pulley "A"	68	H2-4-11
12017PU-T121	Timing Pulley "A"	76	H3-4-11
12017PU-T121	Timing Pulley "A"	85	H4-4-11
12018BR-T121	Needle Bearing Hk1010(Ina)	56	H1-1-34
12018BR-T121	Needle Bearing Hk1010(Ina)	60	H1-4-11
12018BR-T121	Needle Bearing Hk1010(Ina)	64	H2-1-34
12018BR-T121	Needle Bearing Hk1010(Ina)	68	H2-4-11
12018BR-T121	Needle Bearing Hk1010(Ina)	72	H3-1-34
12018BR-T121	Needle Bearing Hk1010(Ina)	76	H3-4-12
12018BR-T121	Needle Bearing Hk1010(Ina)	81	H4-1-34
12018BR-T121	Needle Bearing Hk1010(Ina)	85	H4-4-12
12019BR-T121	FIBER WASHER R-TW1020	34	E-2-24
12019BR-T121	FIBER WASHER R-TW1020	40	E1-2-24
12019BR-T121	Fiber Washer R-Tw1020	56	H1-1-35
12019BR-T121	Fiber Washer R-Tw1020	60	H1-4-12
12019BR-T121	Fiber Washer R-Tw1020	64	H2-1-35
12019BR-T121	Fiber Washer R-Tw1020	68	H2-4-12
12019BR-T121	Fiber Washer R-Tw1020	72	H3-1-35
12019BR-T121	FIBER WASHER R-TW1020	76	H3-4-13
12019BR-T121	Fiber Washer R-Tw1020	81	H4-1-35
12019BR-T121	Fiber Washer R-Tw1020	85	H4-4-13
12033RB-UK01	CUSHION RUBBER	101	J-1-14
12042PM-A001	EYELET	102	J-1-14
12048BT-T121	X-Axis Timing Belt	60	H1-4-5
12048BT-T121	X-Axis Timing Belt	68	H2-4-5
12052SF-A001	SPOOL SPONGE	101	J-1-9
12209100U000	CAP GUIDE	92	I-2-18
12209100U000	CAP GUIDE	98	I1-2-18
13001CA-UK06	Color Change Base	49	F-3-1
13003000T000	Mes Shaft Collar	30	D-4-17
13005CM-UK06	Color Change Cam	49	F-3-12
13007CW-UK06	Color Change Shaft	49	F-3-7
13009SC-A001	COLOR CHANGE CAM GEAR SCREW	101	J-1-10
13010BR-T121	Washer(@12* @26*1T)	49	F-3-10
13010CW-UK06	Color Change Collar	49	F-3-14
13015PR-UK06	Potentiometer Bracket	50	F-4-12

R. Index

Part No.	Part Name	Page	Ref.No
13019PR-A001	Half Turm Film Washer (T1.0)	50	F-4-9
13020GA-UK06	Color Change Gear (L)	50	F-4-7
13020SC-4113	HEX. SOCKET BOLT (M3*L8)	76	H3-4-8
13021GA-UK06	Color Change Gear (R)	49	F-3-15
13022AD-UK06	Color Change Passivity Handle	50	F-4-5
13026BR-T121	NEEDLE BEARING (6002Z)	36	E-4-11
13026BR-T121	NEEDLE BEARING (6002Z)	42	E1-4-11
13026BR-T121	Needle Bearing (6002Z)	57	H1-1-46
13026BR-T121	Needle Bearing (6002Z)	65	H2-1-46
13026BR-T121	Needle Bearing (6002Z)	73	H3-1-46
13026BR-T121	Needle Bearing (6002Z)	82	H4-1-46
13026CL-D104	Color Change Roller Base (9C)	49	F-3-20
13026CL-UK06	Color Change Roller Base (12C)	49	F-3-20
13026CL-UK16	Color Change Roller Base (15C)	49	F-3-20
13032AD-UK06	Color Change Film Set	49	F-3-5
13032GA-UK06	INDEX SHAFT GEAR UK06	34	E-2-2
13032GA-UK06	INDEX SHAFT GEAR UK06	34	E-2-15
13032GA-UK06	INDEX SHAFT GEAR UK06	40	E1-2-2
13032GA-UK06	INDEX SHAFT GEAR UK06	40	E1-2-15
13034GA-UK06	MIDDLE SHAFT GEAR UK06	34	E-2-23
13034GA-UK06	MIDDLE SHAFT GEAR UK06	40	E1-2-23
13036BR-UK01	MIDDLE SHAFT GEAR NEEDLE BEARING@10-@19NNB	34	E-2-23
13036BR-UK01	MIDDLE SHAFT GEAR NEEDLE BEARING@10-@19NNB	40	E1-2-23
13038CW-UK01	COLLAR	34	E-2-25
13038CW-UK01	COLLAR	40	E1-2-25
13041BR-UK01	Washer(12*@26*1T)	49	F-3-11
13041SH-UK01	MIDDLE SHAFT	34	E-2-18
13041SH-UK01	MIDDLE SHAFT	40	E1-2-18
13042SN-1111	HEX.NUT (M6*T5-R)	36	E-4-10
13042SN-1111	HEX.NUT (M6*T5-R)	42	E1-4-10
13042SN-1111	Hex.Nut (M6*T5-R)	90	I-1-32
13042SN-1111	Hex.Nut (M6*T5-R)	96	I1-1-32
13048SC-A001	Bracket "A" Screw	128	N-4-3
13053PR-UK01	ANGLE PLATE BASE	33	E-1-13
13053PR-UK01	ANGLE PLATE BASE	39	E1-1-13
13054ET-UK01	ANGLE DISK (L)	33	E-1-18
13054SC-3123	Switch Cover Screw(set) (M3xL8)	121	M-1-44
13054SC-3123	Truss Screw (M3*L8)	130	O-1-19
13061SC-8119	PLUS SCREW (M3*L10)	33	E-1-14
13061SC-8119	PLUS SCREW (M3*L10)	34	E-2-8
13061SC-8119	PLUS SCREW (M3*L10)	39	E1-1-14
13061SC-8119	PLUS SCREW (M3*L10)	40	E1-2-8
13061SC-8119	Plus Screw (M3*L10)	90	I-1-15
13061SC-8119	Plus Screw (M3*L10)	96	I1-1-15
13106PR-UK01	IDLER SPACER	36	E-4-13
13106PR-UK01	IDLER SPACER	42	E1-4-13
13107CW-UK01	COLLAR	33	E-1-6
13107CW-UK01	COLLAR	39	E1-1-6
13118CS-UK01	IDLER SUPPORT BRACKET	36	E-4-5
13118CS-UK01	IDLER SUPPORT BRACKET	42	E1-4-5
13120CW-UK01	IDLER SHAFT	36	E-4-12
13120CW-UK01	IDLER SHAFT	42	E1-4-12
13123CW-E121	IDELR PLATE	36	E-4-1

Part No.	Part Name	Page	Ref.No
13123CW-E121	IDELR PLATE	42	E1-4-1
14002SC-7113	Hex.Socket Bolt (M6*L15)	56	H1-1-7
14002SC-7113	Hex. Socket Bolt (M6*L15)	66	H2-2-6
14002SC-7113	Hex. Socket Bolt (M6*L15)	74	H3-2-6
14002SC-7113	Hex.Socket Bolt (M6*L15)	81	H4-1-7
14002SC-7113	HEX.SOCKET BOLT (M6*L15)	126	N-2-7
14003SC-4113	HEX. SOCKET BOLT (M8*L20)	134	P-2-7
14006SC-7113	HEX.SOCKET SET SCREW(M8*L15)	33	E-1-15
14006SC-7113	HEX.SOCKET SET SCREW(M8*L15)	39	E1-1-15
14006SC-7113	Hex.Socket Bolt (M8*L15)	64	H2-1-7
14006SC-7113	Hex.Socket Bolt (M8*L15)	72	H3-1-7
14006SC-7113	HEX.SOCKET SET SCREW(M8*L15)	134	P-2-11
14014SC-7113	Hex.Socket Set Screw(M5*L8)	125	N-1-9
14020PR-UK01	Space	61	H1-5-14
14020PR-UK01	Space	69	H2-5-15
14020PR-UK01	SPACE	77	H3-5-24
14020PR-UK01	Space	86	H4-5-16
14027SC-4113	HEX.SOCKET BOLT (M8*L30)	36	E-4-6
14027SC-4113	HEX.SOCKET BOLT (M8*L30)	42	E1-4-6
14027SC-4113	Hex.Socket Bolt (M8*L30)	58	H1-2-6
14027SC-4113	Hex. Socket Bolt	64	H2-1-2
14027SC-4113	Hex. Socket Bolt	72	H3-1-2
14027SC-4113	Hex.Socket Bolt (M8*L30)	83	H4-2-6
14045AD-UK01	Belt Bracket (B)	60	H1-4-1
14045AD-UK01	Belt Bracket (B)	61	H1-5-19
14045AD-UK01	Belt Bracket (B)	68	H2-4-1
14045AD-UK01	Belt Bracket (B)	69	H2-5-16
14045AD-UK01	BELT BRACKET (B)	76	H3-4-1
14045AD-UK01	BELT BRACKET (B)	77	H3-5-29
14045AD-UK01	Belt Bracket (B)	85	H4-4-1
14045AD-UK01	Belt Bracket (B)	86	H4-5-17
14046SC-7113	HEX.SOCKET BOLT (M6*L30)	37	E-5-6
14046SC-7113	HEX.SOCKET BOLT (M6*L30)	43	E1-5-6
14046SC-7113	Hex.Socket Bolt (M6*L30)	66	H2-2-2
14046SC-7113	Hex.Socket Bolt (M6*L30)	74	H3-2-2
14046SC-7113	Hex.Socket Bolt (M6*L30)	83	H4-2-2
14048AD-UK01	Belt Bracket (A)	61	H1-5-18
14048AD-UK01	Belt Bracket (A)	69	H2-5-17
14048AD-UK01	BELT BRACKET (A)	77	H3-5-30
14048AD-UK01	Belt Bracket (A)	86	H4-5-20
14049AD-UK01	Belt Bracket (C)	60	H1-4-2
14049AD-UK01	Belt Bracket (C)	68	H2-4-2
14049AD-UK01	BELT BRACKET (C)	76	H3-4-2
14049AD-UK01	Belt Bracket (C)	85	H4-4-2
14051PR-UK01	Fixing Plate	60	H1-4-6
14051PR-UK01	Fixing Plate	68	H2-4-6
14051PR-UK01	FIXING PLATE	76	H3-4-6
14051PR-UK01	Fixing Plate	85	H4-4-6
14052PR-UK01	Fixing Plate Holder	60	H1-4-7
14052PR-UK01	Fixing Plate Holder	68	H2-4-7
14052PR-UK01	FIXING PLATE HOLDER	76	H3-4-7
14052PR-UK01	Fixing Plate Holder	85	H4-4-7
14058CW-A001	COLLAR "A"	33	E-1-11

Part No.	Part Name	Page	Ref.No
14058CW-A001	COLLAR "A"	39	E1-1-11
14058CW-A001	Bearing Stopper Collar	66	H2-2-10
14058CW-A001	Bearing Stopper Collar	74	H3-2-10
14060AF-4517	Hex.Socket Screw(M6*L6)	25	C-5-11
14060AF-4517	HEX.SOCKET SCREW(M6*L6)	33	E-1-7
14060AF-4517	HEX.SOCKET SCREW(M6*L6)	33	E-1-12
14060AF-4517	HEX.SOCKET SCREW(M6*L6)	35	E-3-13
14060AF-4517	HEX.SOCKET SCREW(M6*L6)	35	E-3-15
14060AF-4517	HEX.SOCKET SCREW(M6*L6)	35	E-3-17
14060AF-4517	HEX.SOCKET SCREW(M6*L6)	36	E-4-14
14060AF-4517	HEX.SOCKET SCREW(M6*L6)	39	E1-1-7
14060AF-4517	HEX.SOCKET SCREW(M6*L6)	39	E1-1-12
14060AF-4517	HEX.SOCKET SCREW(M6*L6)	40	E1-2-6
14060AF-4517	HEX.SOCKET SCREW(M6*L6)	41	E1-3-13
14060AF-4517	HEX.SOCKET SCREW(M6*L6)	41	E1-3-15
14060AF-4517	HEX.SOCKET SCREW(M6*L6)	41	E1-3-17
14060AF-4517	HEX.SOCKET SCREW(M6*L6)	42	E1-4-14
14060AF-4517	Hex. Socket Bolt (M6*L6)	66	H2-2-27
14060AF-4517	Hex. Socket Bolt (M6*L6)	74	H3-2-27
14060CW-UK01	TIMING PULLEY DRIVING PIN	76	H3-4-14
14061AF-4517	HEX.SOCKET SCREW(M8*L8)	33	E-1-10
14061AF-4517	HEX.SOCKET SCREW(M8*L8)	39	E1-1-10
14061AF-4517	Hex. Socket Bolt (M8*L8)	66	H2-2-17
14061AF-4517	Hex. Socket Bolt (M8*L8)	74	H3-2-17
14063PU-UK01	Timing Pulley "B"	60	H1-4-26
14063PU-UK01	Timing Pulley "B"	68	H2-4-25
14063PU-UK01	Timing Pulley "B"	76	H3-4-27
14063PU-UK01	Timing Pulley "B"	85	H4-4-27
14063SC-A001	TENSION CONTROL BOLT (M6*L40)	36	E-4-9
14063SC-A001	Tension Control Bolt (M6*L40)	37	E-5-16
14063SC-A001	TENSION CONTROL BOLT (M6*L40)	42	E1-4-9
14063SC-A001	Tension Control Bolt (M6*L40)	43	E1-5-16
14065AD-UK01	Motor Fixing Shaft (A)	60	H1-4-28
14065AD-UK01	Motor Fixing Shaft (A)	68	H2-4-27
14065AD-UK01	MOTOR FIXING SHAFT (A)	76	H3-4-29
14065AD-UK01	Motor Fixing Shaft (A)	85	H4-4-29
14067AD-UK01	Motor Fixing Shaft (B)	60	H1-4-24
14067AD-UK01	Motor Fixing Shaft (B)	68	H2-4-23
14067AD-UK01	MOTOR FIXING SHAFT (B)	76	H3-4-25
14067AD-UK01	Motor Fixing Shaft (B)	85	H4-4-25
14069AD-UK01	Motor Block	68	H2-4-28
14069AD-UK01	Motor Block	76	H3-4-30
14069AD-UK01	Motor Block	85	H4-4-30
14071BR-UK01	Bearing Bc616Zz	68	H2-4-29
14071BR-UK01	Bearing Bc616Zz	76	H3-4-33
14071BR-UK01	Bearing Bc616Zz	85	H4-4-31
14074PR-UK01	Motor Base (L)	68	H2-4-21
14074PR-UK01	MOTOR BASE (L)	76	H3-4-23
14074PR-UK01	Motor Base (L)	85	H4-4-22
14075PR-UK01	Motor Base (R)	68	H2-4-20
14075PR-UK01	MOTOR BASE (R)	76	H3-4-22
14075PR-UK01	Motor Base (R)	85	H4-4-23
15001BR-B001	Cam Roller Bearing	59	H1-3-18

R. Index

Part No.	Part Name	Page	Ref.No
15001BR-B001	Cam Roller Bearing	67	H2-3-18
15001BR-B001	Cam Roller Bearing	75	H3-3-18
15001BR-B001	Cam Roller Bearing	84	H4-3-18
15002CW-B001	Cam Roller Stud (A)	59	H1-3-13
15002CW-B001	Cam Roller Stud (A)	84	H4-3-13
15003CW-B001	Cam Roller Stud (B)	59	H1-3-16
15003CW-B001	Cam Roller Stud (B)	67	H2-3-16
15003CW-B001	Cam Roller Stud (B)	75	H3-3-16
15003CW-B001	Cam Roller Stud (B)	84	H4-3-16
15007PR-UK02	Connecting Plate(L)	69	H2-5-3
15007PR-UK02	CONNECTING PLATE(L)	77	H3-5-4
15007PR-UK02	Connecting Plate(L)	86	H4-5-4
15011PR-UK02	CONNECTING PLATE(R)	77	H3-5-8
15011PR-UK02	Connecting Plate(R)	86	H4-5-8
15012MT-T121	Potentiometer (7824 R1K L25)	50	F-4-10
15014PR-T121	Potentiometer Washer	50	F-4-11
15015PR-UK02	Connecting Plate	61	H1-5-8
15015PR-UK02	Connecting Plate	69	H2-5-8
15015PR-UK02	Connecting Plate	77	H3-5-12
15015PR-UK02	Connecting Plate	86	H4-5-9
15-027A-2070	SENSOR	90	I-1-14
15-027A-2070	SENSOR	96	I1-1-14
15029AF-T121	Roller Set	49	F-3-21
15029SN-3211	Hex. Nut (M4-No2)	59	H1-3-14
15029SN-3211	Hex. Nut (M4-No2)	67	H2-3-14
15029SN-3211	Hex. Nut (M4-No2)	75	H3-3-14
15029SN-3211	Hex. Nut (M4-No2)	84	H4-3-14
15030SC-7113	HEX. SOCKET BOLT (M5*L30)	37	E-5-2
15030SC-7113	HEX. SOCKET BOLT (M5*L30)	43	E1-5-2
15030SC-7113	Hex. Socket Bolt (M5*L30)	56	H1-1-28
15030SC-7113	Hex. Socket Bolt (M5*L30)	81	H4-1-28
15034SC-4113	Hex. Socket Bolt (M4*L45)	60	H1-4-3
15034SC-4113	Hex. Socket Bolt (M4*L45)	61	H1-5-20
15034SC-4113	Hex. Socket Bolt (M4*L45)	68	H2-4-3
15034SC-4113	Hex. Socket Bolt (M4*L45)	69	H2-5-18
15034SC-4113	HEX. SOCKET Bolt (M4*L45)	76	H3-4-3
15034SC-4113	HEX. SOCKET Bolt (M4*L45)	77	H3-5-31
15034SC-4113	Hex. Socket Bolt (M4*L45)	85	H4-4-3
15034SC-4113	Hex. Socket Bolt (M4*L45)	86	H4-5-18
15042SC-3123	Truss Screw (M4*L6)	62	H1-6-5
15042SC-3123	TRUSS SCREW (M4*L6)	62	H1-6-12
15042SC-3123	Truss Screw (M4*L6)	70	H2-6-5
15042SC-3123	Truss Screw (M4*L6)	70	H2-6-14
15042SC-3123	TRUSS SCREW (M4*L6)	78	H3-6-6
15042SC-3123	TRUSS SCREW (M4*L6)	78	H3-6-17
15042SC-3123	Truss Screw (M4*L6)	87	H4-6-6
15042SC-3123	Truss Screw (M4*L6)	87	H4-6-14
15042SC-3123	TRUSS SCREW (M4*L6)	127	N-3-3
15042SC-3123	Truss Screw (M4*L6)	130	O-1-9
15042SC-3123	Truss Screw (M4*L6)	138	Q1-3-17
15042SC-3123	Truss Screw (M4*L6)	142	Q2-3-15
15042SC-3123	Truss Screw (M4*L6)	146	Q3-3-11
15042SC-3123	Truss Screw (M4*L6)	146	Q3-3-13

Part No.	Part Name	Page	Ref.No
15042SC-3123	Truss Screw (M4*L6)	150	Q4-3-13
15043EL-UK01	X-Positioning Sensor	87	H4-6-18
15044EL-T121	Bid (S)	60	H1-4-33
15044EL-T121	Bid (S)	68	H2-4-30
15044EL-T121	Bid (S)	76	H3-4-34
15044EL-T121	Bid (S)	85	H4-4-32
15045EL-UK01	Bid (L)	58	H1-2-15
15045EL-UK01	Bid (L)	60	H1-4-34
15045EL-UK01	Bid (L)	79	H3-6-56
15045EL-UK01	Bid (L)	83	H4-2-16
15045EL-UK01	Bid (L)	88	H4-6-52
15048SC-4119	Plus Screw (M5*L12)	60	H1-4-14
15048SC-4119	PLUS SCREW (M5*L12)	76	H3-4-15
15048SC-4119	Plus Screw (M5*L12)	85	H4-4-15
15053SC-4119	Plus Screw (M5*L30)	60	H1-4-23
15053SC-4119	Plus Screw (M5*L30)	68	H2-4-22
15053SC-4119	PLUS SCREW (M5*L30)	76	H3-4-24
15053SC-4119	Plus Screw (M5*L30)	85	H4-4-24
15055SC-4119	Plus Screw (M5*L35)	60	H1-4-25
15055SC-4119	Plus Screw (M5*L35)	68	H2-4-24
15055SC-4119	PLUS SCREW (M5*L35)	76	H3-4-26
15055SC-4119	Plus Screw (M5*L35)	85	H4-4-26
15057CS-UK01	Y-Driving Motor Bracket	58	H1-2-5
15059PR-UK02	X-Motor Space	60	H1-4-20
15060PR-UK02	X-Motor Base(L)	60	H1-4-22
15061PR-UK01	Motor Space (@5*@11*2T)	68	H2-4-19
15061PR-UK01	MOTOR SPACE (@5*@11*2T)	76	H3-4-21
15061PR-UK01	Motor Space (@5*@11*2T)	85	H4-4-21
15061PR-UK02	X-Motor Base(R)	60	H1-4-21
15062SF-T121	Felt	62	H1-6-2
15062SF-T121	Felt	78	H3-6-2
15062SF-T121	Felt	87	H4-6-2
15064AF-A001	C.S Screw (M3*L3.5)	141	Q2-2-12
15064AF-A001	C.S Screw (M3*L3.5)	141	Q2-2-14
15064AF-A001	C.S Screw (M3*L3.5)	149	Q4-2-11
15067PR-UK01	Sensor Plate	70	H2-6-17
15067PR-UK01	SENSOR PLATE	79	H3-6-44
15067PR-UK01	Sensor Plate	87	H4-6-17
15076AF-UK01	X-Motor (103H8221-5044)	68	H2-4-16
15076AF-UK01	X-MOTOR	76	H3-4-17
15076AF-UK01	X-Motor	85	H4-4-17
15077BR-A001	Ball Bearing (698Zz)	60	H1-4-32
15082PR-W121	FIXING PLATE FOR BUSHING	62	H1-6-7
15082PR-W121	FIXING PLATE FOR BUSHING	79	H3-6-42
15082PR-W121	FIXING PLATE FOR BUSHING	87	H4-6-32
15087PR-UK02	Cable Plate For Bushing	62	H1-6-9
15087PR-UK02	CABLE PLATE FOR BUSHING	79	H3-6-57
15087PR-UK02	Cable Plate For Bushing	88	H4-6-48
15089SC-7119	C.S Screw (M4*L10)	52	G-1-4
15089SC-7119	C.S Screw (M4*L12)	105	K-2-28
15089SC-7119	C.S SCREW (M4*L10)	126	N-2-2
15095SW-3115	Spring Washer (@8)	19	B-6-3
15095SW-3115	Spring Washer (@8)	25	C-5-3

Part No.	Part Name	Page	Ref.No
15095SW-3115	Spring Washer (@8)	28	D-2-17
15095SW-3115	Spring Washer (@8)	31	D-5-8
15095SW-3115	SPRING WAHSEr(@8)	33	E-1-16
15095SW-3115	SPRING WASHER(@8)	36	E-4-7
15095SW-3115	SPRING WAHSEr(@8)	39	E1-1-16
15095SW-3115	SPRING WASHER(@8)	42	E1-4-7
15095SW-3115	Spring Washer (@8)	56	H1-1-5
15095SW-3115	Spring Washer (@8)	58	H1-2-7
15095SW-3115	Spring Washer (@8)	64	H2-1-4
15095SW-3115	Spring Washer (@6)	64	H2-1-8
15095SW-3115	Spring Washer (@8)	66	H2-2-31
15095SW-3115	Spring Washer (@8)	72	H3-1-4
15095SW-3115	Spring Washer (@6)	72	H3-1-8
15095SW-3115	Spring Washer (@8)	74	H3-2-31
15095SW-3115	Spring Washer (@8)	78	H3-6-32
15095SW-3115	Spring Washer (@8)	81	H4-1-4
15095SW-3115	Spring Washer (@8)	83	H4-2-7
15095SW-3115	SPRING WASHER (@8)	90	I-1-28
15095SW-3115	SPRING WASHER (@8)	96	I1-1-28
15095SW-3115	SPRING WASHER (@8)	134	P-2-8
15095SW-3115	SPRING WASHER (@8)	134	P-2-12
15095SW-4115	Spring Washer (@8)	123	M-3-4
15104CW-UK01	Roller Stud Bolt	78	H3-6-34
15104CW-UK01	Roller Stud Bolt	88	H4-6-40
15105SC-4113	HEX.SOCKET BOLT (M4*L15)	126	N-2-17
15106BR-A001	Flange Bearing (1280Zz)	79	H3-6-35
15106BR-A001	Flange Bearing (1280Zz)	88	H4-6-42
15107CW-UK01	Roller Collar	79	H3-6-37
15107CW-UK01	Roller Collar	88	H4-6-43
15112SC-7113	HEX. SOCKET SET SCREW(M3*L8)	78	H3-6-27
15112SC-7113	HEX. SOCKET SET SCREW(M3*L8)	87	H4-6-29
15130AF-A001	Roller Guide	79	H3-6-36
15130AF-A001	Roller Guide	88	H4-6-41
15159SR-4013	E-Ring (3@)	94	I-4-16
15159SR-4013	E-Ring (3@)	137	Q1-2-10
15159SR-4013	E-Ring (3@)	141	Q2-2-9
15159SR-4013	E-Ring (3@)	145	Q3-2-9
15159SR-4013	E-Ring (3@)	149	Q4-2-9
16005RB-A001	Table Support End Cap(L)	105	K-2-8
16005RB-A001	Fixed Table "D"(3X3공용)	108	K-5-11
16009SC-4113	HEX.SOCKET BOLT(M10*L25)	35	E-3-2
16009SC-4113	HEX.SOCKET BOLT(M10*L25)	41	E1-3-2
16009SC-4113	HEX.SOCKET BOLT(M10*L25)	105	K-2-4
16009SC-8330	TAPPING SCREW (M6*L20)	104	K-1-7
16009SC-8330	TAPPING SCREW (M6*L20)	104	K-1-15
16009SC-8330	TAPPING SCREW (M6*L20)	104	K-1-20
16009SC-8330	TAPPING SCREW (M6*L20)	105	K-2-6
16009SC-8330	Tapping Screw (M6*L20)	106	K-3-25
16009SC-8330	Tapping Screw (M6*L20)	106	K-3-27
16009SC-8330	TAPPING SCREW (M6*L20)	106	K-3-29
16009SC-8330	TAPPING SCREW (M6*L20)	107	K-4-19
16009SC-8330	TAPPING SCREW (M6*L20)	107	K-4-23
16009SC-8330	Tapping Screw (M6*L20)	109	K-5-35

R. Index

Part No.	Part Name	Page	Ref.No
16009SC-8330	Tapping Screw (M6*L20)	109	K-5-37
16009SC-8330	TAPPING SCREW (M6*L20)	109	K-5-39
16009SC-8330	Tapping Screw (M6*L20)	111	K-6-35
16009SC-8330	Tapping Screw (M6*L20)	111	K-6-37
16009SC-8330	TAPPING SCREW (M6*L20)	111	K-6-39
16014SW-4115	Spring Washer (@6)	56	H1-1-8
16014SW-4115	Spring Washer (@6)	66	H2-2-3
16014SW-4115	Spring Washer (@6)	66	H2-2-7
16014SW-4115	Spring Washer (@6)	74	H3-2-3
16014SW-4115	Spring Washer (@6)	74	H3-2-7
16014SW-4115	Spring Washer (@6)	81	H4-1-8
16014SW-4115	Spring Washer (@6)	83	H4-2-3
16014SW-4115	Spring Washer (@6)	90	I-1-4
16014SW-4115	Spring Washer (@6)	96	I1-1-4
16014SW-4115	Spring Washer (@6)	125	N-1-7
16014SW-4115	SPRING WASHER (@6)	126	N-2-8
16014SW-4115	Spring Washer (@4)	126	N-2-18
16016PR-UK01	GEAR COVER	105	K-2-30
16016PR-UK01	GEAR COVER	106	K-3-30
16018PR-UK01	MES CAM DRIVING BOX COVER	106	K-3-7
16018PR-UK01	MES CAM DRIVING BOX COVER	107	K-4-13
16018PR-UK01	MES CAM DRIVING BOX COVER	108	K-5-12
16018PR-UK01	MES CAM DRIVING BOX COVER	110	K-6-15
16018SW-1111	Washer (@5)	24	C-4-7
16018SW-1111	Washer (@5)	56	H1-1-12
16018SW-1111	Washer (@5)	56	H1-1-30
16018SW-1111	Washer (@5)	57	H1-1-39
16018SW-1111	Washer (@5)	58	H1-2-4
16018SW-1111	Washer (@5)	60	H1-4-19
16018SW-1111	Washer (@5)	64	H2-1-12
16018SW-1111	Washer (@5)	64	H2-1-30
16018SW-1111	Washer (@5)	65	H2-1-39
16018SW-1111	Washer (@5)	72	H3-1-12
16018SW-1111	Washer (@5)	72	H3-1-30
16018SW-1111	Washer (@5)	73	H3-1-39
16018SW-1111	WASHER (@5)	76	H3-4-20
16018SW-1111	Washer (@5)	81	H4-1-12
16018SW-1111	Washer (@5)	81	H4-1-30
16018SW-1111	Washer (@5)	82	H4-1-39
16018SW-1111	Washer (@5)	85	H4-4-20
16018SW-1111	WASHER (@5)	104	K-1-6
16018SW-1111	WASHER (@5)	104	K-1-10
16018SW-1111	WASHER (@5)	104	K-1-14
16018SW-1111	WASHER (@5)	104	K-1-19
16018SW-1111	WASHER (@5)	105	K-2-13
16018SW-1111	WASHER (@5)	105	K-2-18
16018SW-1111	Washer (@5)	113	L-1-4
16018SW-1111	Washer (@5)	113	L-1-7
16018SW-1111	Control Box Washer	122	M-2-19
16018SW-1111	Stud Bolt Washer(S) (@5)	123	M-3-10
16018SW-1111	WASHER (@5)	127	N-3-12
16019SW-4115	SPRING WASHER (@5)	76	H3-4-19
16019SW-4115	SPRING WASHER (@5)	76	H3-4-32

Part No.	Part Name	Page	Ref.No
16019SW-4115	SPRING WASHER (@5)	104	K-1-5
16019SW-4115	SPRING WASHER (@5)	104	K-1-9
16019SW-4115	SPRING WASHER (@5)	104	K-1-13
16019SW-4115	SPRING WASHER (@5)	104	K-1-18
16019SW-4115	SPRING WASHER (@5)	105	K-2-12
16019SW-4115	SPRING WASHER (@5)	105	K-2-17
16019SW-4115	Control Box Spring Washer	122	M-2-18
16019SW-4115	Spring Washer (@5)	123	M-3-9
16021CW-A001	Table Support Stud	31	D-5-6
16028SC-7113	Hex. Socket Bolt (M5*L25)	64	H2-1-28
16028SC-7113	Hex. Socket Bolt (M5*L25)	72	H3-1-28
16029SW-3115	SPRING WASHER (10@)	12	A-2-26
16029SW-4115	SPRING WASHER (10@)	105	K-2-5
16052AD-UK01	TABLE SUPPORT GUIDE	105	K-2-19
16055MT-UK06	Y Motor	58	H1-2-1
16058AD-UK01	TABLE SUPPORT PLATE (B)	105	K-2-27
16059MT-E131	Y Motor (103H89222-5212)	66	H2-2-1
16059MT-E131	Y Motor (103H89222-5212)	74	H3-2-1
16059MT-E131	Y Motor (103H89222-5212)	83	H4-2-1
16059SC-7113	Hex. Socket Bolt (M6*L20)	65	H2-1-45
16059SC-7113	Hex. Socket Bolt (M6*L20)	73	H3-1-45
16061PR-UK01	TABLE SUPPORT PLATE (A)	105	K-2-25
16063PM-UK01	TABLE HOLDING BLOCK	106	K-3-28
16063PM-UK01	TABLE HOLDING BLOCK	107	K-4-18
16063PM-UK01	TABLE HOLDING BLOCK	109	K-5-38
16063PM-UK01	TABLE HOLDING BLOCK	111	K-6-38
16065PR-UK01	CLAMP PLATE	106	K-3-24
16065PR-UK01	CLAMP PLATE	107	K-4-22
16065PR-UK01	CLAMP PLATE	109	K-5-34
16065PR-UK01	CLAMP PLATE	111	K-6-34
16067ET-UK01	TABLE TOGGLE CLAMP	106	K-3-26
16067ET-UK01	TABLE TOGGLE CLAMP	107	K-4-20
16067ET-UK01	TABLE TOGGLE CLAMP	109	K-5-36
16067ET-UK01	TABLE TOGGLE CLAMP	111	K-6-36
16074PR-UK06	Y-Lm Support Fixing Plate	56	H1-1-6
16074PR-UK06	Y-Lm Support Fixing Plate	64	H2-1-6
16074PR-UK06	Y-Lm Support Fixing Plate	72	H3-1-6
16074PR-UK06	Y-Lm Support Fixing Plate	81	H4-1-6
16100CW-UK06	Timing Pulley Shaft (Y)	56	H1-1-36
16100CW-UK06	Timing Pulley Shaft (Y)	64	H2-1-36
16100CW-UK06	Timing Pulley Shaft (Y)	72	H3-1-36
16100CW-UK06	Timing Pulley Shaft (Y)	81	H4-1-36
16104CL-H001	Belt Catcher Plate (Y)	59	H1-3-12
16104CL-H001	Belt Catcher Plate (Y)	67	H2-3-12
16104CL-H001	Belt Catcher Plate (Y)	75	H3-3-12
16104CL-H001	Belt Catcher Plate (Y)	84	H4-3-12
17012SC-8329	Hex. Socket Set Screw(M4*L16)	105	K-2-26
17014PR-UK01	Tubular Holder "A"	137	Q1-2-3
17014PR-UK01	Tubular Holder "A"	141	Q2-2-3
17014PR-UK01	Tubular Holder "A"	145	Q3-2-2
17014PR-UK01	Tubular Holder "A"	149	Q4-2-2
17015PR-UK01	Tubular Holder "B"	137	Q1-2-5
17015PR-UK01	Tubular Holder "B"	141	Q2-2-4

Part No.	Part Name	Page	Ref.No
17015PR-UK01	Tubular Holder "B"	145	Q3-2-4
17015PR-UK01	Tubular Holder "B"	149	Q4-2-4
17062SC-UK01	Table Support Stopper Screw	105	K-2-23
17063SC-UK01	Table Support Stopper Screw	105	K-2-29
18013AF-7113	Hex. Socket Bolt (M4*L10)	113	L-1-10
18014SW-3115	Spring Washer (@4)	23	C-3-5
18014SW-3115	Spring Washer (@4-No2)	29	D-3-10
18014SW-3115	Spring Washer (@4-No2)	29	D-3-15
18014SW-3115	SPRING WASHER (@4-NO2)	33	E-1-21
18014SW-3115	SPRING WASHER (@4-NO2)	34	E-2-21
18014SW-3115	SPRING WASHER (@4-NO2)	39	E1-1-21
18014SW-3115	SPRING WASHER (@4-NO2)	40	E1-2-21
18014SW-3115	Spring Washer (@4-No2)	49	F-3-3
18014SW-3115	Spring Washer (@4-No2)	56	H1-1-22
18014SW-3115	Spring Washer (@4-No2)	56	H1-1-26
18014SW-3115	Spring Washer (@4-No2)	57	H1-1-41
18014SW-3115	Spring Washer (@4-No2)	59	H1-3-6
18014SW-3115	SPRING WASHER (@4-NO2)	62	H1-6-16
18014SW-3115	Spring Washer (@4-No2)	64	H2-1-22
18014SW-3115	Spring Washer (@4-No2)	64	H2-1-26
18014SW-3115	Spring Washer (@4-No2)	65	H2-1-41
18014SW-3115	Spring Washer (@4-No2)	67	H2-3-6
18014SW-3115	Spring Washer (@4-No2)	68	H2-4-9
18014SW-3115	Spring Washer (@4-No2)	69	H2-5-5
18014SW-3115	Spring Washer (@4-No2)	69	H2-5-11
18014SW-3115	Spring Washer (@4-No2)	70	H2-6-10
18014SW-3115	SPRING WASHER (@4-NO2)	70	H2-6-16
18014SW-3115	Spring Washer (@4-No2)	70	H2-6-19
18014SW-3115	Spring Washer (@4-No2)	72	H3-1-22
18014SW-3115	Spring Washer (@4-No2)	72	H3-1-26
18014SW-3115	Spring Washer (@4-No2)	73	H3-1-41
18014SW-3115	Spring Washer (@4-No2)	75	H3-3-6
18014SW-3115	Spring Washer (@4-No2)	77	H3-5-6
18014SW-3115	SPRING WASHER (@4-NO2)	77	H3-5-10
18014SW-3115	Spring Washer (@4-No2)	77	H3-5-14
18014SW-3115	SPRING WASHER (@4-NO2)	77	H3-5-18
18014SW-3115	SPRING WASHER (@4-NO2)	77	H3-5-22
18014SW-3115	SPRING WASHER (@4-NO2)	77	H3-5-27
18014SW-3115	SPRING WASHER (@4-NO2)	78	H3-6-9
18014SW-3115	SPRING WASHER (@4-NO2)	78	H3-6-13
18014SW-3115	SPRING WASHER (@4-NO2)	78	H3-6-23
18014SW-3115	Spring Washer (@4-No2)	79	H3-6-40
18014SW-3115	Spring Washer (@4-No2)	79	H3-6-48
18014SW-3115	Spring Washer (@4-No2)	81	H4-1-22
18014SW-3115	Spring Washer (@4-No2)	81	H4-1-26
18014SW-3115	Spring Washer (@4-No2)	82	H4-1-41
18014SW-3115	Spring Washer (@4-No2)	84	H4-3-6
18014SW-3115	SPRING WASHER (@4-NO2)	87	H4-6-25
18014SW-3115	Spring Washer (@4-No2)	88	H4-6-38
18014SW-3115	SPRING WASHER (4@)	91	I-1-44
18014SW-3115	Spring Washer (@4-No2)	91	I-1-48
18014SW-3115	Spring Washer (@4-No2)	92	I-2-15
18014SW-3115	SPRING WASHER (4@)	97	I1-1-44

R. Index

Part No.	Part Name	Page	Ref.No
GP-004904-00	Y-LM Guide Cover B	106	K-3-13
GP-004905-00	Y-LM Guide Cover C	106	K-3-15
GP-004906-00	Y-LM Guide Cover D	106	K-3-17
GP-004907-00	TABLE SUPPORT A	105	K-2-1
GP-004907-01	TABLE SUPPORT A	105	K-2-1
GP-004908-00	TABLE SUPPORT B	105	K-2-2
GP-004908-01	TABLE SUPPORT B	105	K-2-2
GP-004909-00	OP Holder Support Cover (B)	106	K-3-22
GP-004909-01	OP Holder Support Cover (B)	106	K-3-22
GP-004910-00	Y-MOTOR COVER	106	K-3-19
GP-004911-00	SPOOL PLATE L=880 UH1504D	101	J-1-1
GP-004913-00	THREAD ANGLE "A" L=820 UH1504D	102	J-1-2
GP-004914-00	THREAD ANGLE "B" L=820 UH1504D	102	J-1-3
GP-004915-00	THREAD ANGLE "C" L=820 UH1504D	102	J-1-4
GP-004916-00	Connecting Plate(R)	61	H1-5-7
GP-004917-00	Connecting Plate(L)	61	H1-5-3
GP-004918-00	X-Lm Guide (Sr15W,L1480)	61	H1-5-1
GP-004919-00	LM Block Driving Plate(L)	61	H1-5-17
GP-004920-00	LM Block Driving Plate(R)	61	H1-5-16
GP-004921-00	Lm Block Connecting Plate(R)	61	H1-5-13
GP-004922-00	Lm Block Connecting Plate(L)	61	H1-5-9
GP-004923-00	Perception Plate	61	H1-5-15
GP-004923-01	Perception Plate	61	H1-5-15
GP-004924-00	X-Frame Cover	62	H1-6-4
GP-004929-00	X-FRAME	62	H1-6-1
GP-004929-01	X-FRAME	62	H1-6-1
GP-004929-02	X-FRAME	62	H1-6-1
GP-004929-03	X-FRAME	62	H1-6-1
GP-004929-04	X-FRAME	62	H1-6-1
GP-004930-00	Y-LM Guide Frame L620	56	H1-1-1
GP-004930-01	Y-LM Guide Frame L620	56	H1-1-1
GP-004932-00	Square Frame (A)	138	Q1-3-1
GP-004933-00	Square Frame (B)	138	Q1-3-2
GP-004934-00	Mes Driving Shaft "A" L=418 UH1504D	27	D-1-17
GP-004935-00	TOP SHAFT A [1447.7mm] UH1504D	35	E-3-19
GP-004936-00	TOP SHAFT B [1259.2mm] UH1504D	41	E1-3-19
GP-004937-00	Upper Thread Driving Shaft A(L=575) UH1504D	91	I-1-41
GP-004938-00	Upper Thread Driving Shaft B(L=649) UH1504D	97	I1-1-41
GP-004941-00	LOW SHAFT A [704mm] UH1504D	34	E-2-17
GP-004942-00	LOW SHAFT B [902.5mm] UH1504D	40	E1-2-17
GP-004943-00	Head Transportation Shaft UH1504D	47	F-2-20
GP-004944-00	Y-Driving Shaft	58	H1-2-14
GP-004945-00	Tubular Frame	136	Q1-1-1
GP-004945-01	Tubular Frame	136	Q1-1-1
GP-005006-00	THREAD ANGLE "D" L=820 UH1504D	102	J-1-5
GP-005007-00	TOP SHAFT COVER B-1 UH1504D	127	N-3-7
GP-005008-00	TOP SHAFT COVER B-2 UH1504D	127	N-3-8
GP-005008-01	TOP SHAFT COVER B-2 UH1504D	127	N-3-8
GP-005021-00	Bracket For X-Y Connecting	59	H1-3-4
GP-005021-00	Bracket For X-Y Connecting	67	H2-3-4
GP-005021-00	Bracket For X-Y Connecting	75	H3-3-4
GP-005022-00	Y-Lm Support Fixing Plate(A)	57	H1-1-56
GP-005026-00	Upper Shaft Cover (A) UH1504D	128	N-4-15

Part No.	Part Name	Page	Ref.No
GP-005027-00	Switch Base UH1504D	126	N-2-16
GP-005043-00	UPPER THREAD HOOK DRIVING SHAF UH1208D	47	F-2-20
GP-005047-00	Tubular Frame Rail Plate	62	H1-6-3
GP-005058-00	FIXED TABLE "C"	110	K-6-7
GP-005058-01	FIXED TABLE "C"	110	K-6-7
GP-005059-00	FIXED TABLE "D"	110	K-6-8
GP-005061-00	SPOOL PLATE L=2480 UH1512D	101	J-1-1
GP-005065-00	Oil Tank Cover (L) UH1512D	24	C-4-9
GP-005070-00	X-Lm Guide Frame	87	H4-6-1
GP-005070-01	X-Lm Guide Frame	87	H4-6-1
GP-005071-00	X-FRAME SUPPORT BAR	87	H4-6-20
GP-005071-01	X-FRAME SUPPORT BAR	87	H4-6-20
GP-005071-02	X-FRAME SUPPORT BAR	87	H4-6-20
GP-005072-00	TOP SHAFT A [1197.7mm] UH1512D	35	E-3-19
GP-005074-00	TOP SHAFT B [1500mm] UH1512D	41	E1-3-19
GP-005075-00	TOP SHAFT C [1309mm] UH1512D	35	E-3-20
GP-005075-00	TOP SHAFT C [1309mm] UH1512D	41	E1-3-20
GP-005076-00	Upper Thread Driving Shaft B(L=2295)UH1512D	97	I1-1-41
GP-005077-00	LOW SHAFT B [1302.5mm] UH1512D	40	E1-2-17
GP-005078-00	Y-Driving Shaft UH1512D	83	H4-2-11
GP-005078-01	Y-Driving Shaft UH1512D	83	H4-2-11
GP-005089-00	UPPER THREAD DRIVING SHAFT UH912D	47	F-2-20
GP-005089-01	UPPER THREAD DRIVING SHAFT UH912D	47	F-2-20
GP-005104-00	X-Frame Side Cover Holder (L)	62	H1-6-13
GP-005104-00	X-FRAME SIDE COVER HOLDER (L)	70	H2-6-7
GP-005104-00	X-Frame Side Cover Holder (L)	78	H3-6-7
GP-005104-00	X-Frame Side Cover Holder (L)	87	H4-6-7
GP-005105-00	X-Frame Side Cover Holder (R)	62	H1-6-14
GP-005105-00	X-FRAME SIDE COVER HOLDER (R)	70	H2-6-8
GP-005105-00	X-Frame Side Cover Holder (R)	78	H3-6-11
GP-005105-00	X-Frame Side Cover Holder (R)	87	H4-6-8
GP-005106-00	X-FRAME SIDE COVER L	62	H1-6-10
GP-005106-00	X-AXIS FRAME SIDE COVER (L)	70	H2-6-12
GP-005106-00	X-FRAME SIDE COVER L	78	H3-6-15
GP-005106-00	X-Axis Frame Side Cover (L)	87	H4-6-12
GP-005107-00	X-FRAME SIDE COVER R	62	H1-6-11
GP-005107-00	X-AXIS FRAME SIDE COVER (R)	70	H2-6-13
GP-005107-00	X-FRAME SIDE COVER R	78	H3-6-16
GP-005107-00	X-Axis Frame Side Cover (R)	87	H4-6-13
GP-005108-00	X-Frame Support Bar Cover L	78	H3-6-25
GP-005109-00	X-Frame Support Bar Cover R	78	H3-6-26
GP-005174-00	MOVABLE TABLE "A"	110	K-6-1
GP-005175-00	MOVABLE TABLE "B"	110	K-6-2
GP-005176-00	MOVABLE TABLE "C"	110	K-6-3
GP-005177-00	MOVABLE TABLE "D"	110	K-6-4
GP-005184-00	SENSOR SENSING ADJUSTING RING	90	I-1-8
GP-005184-00	SENSOR SENSING ADJUSTING RING	96	I1-1-8
GP-005184-01	SENSOR SENSING ADJUSTING RING	90	I-1-8
GP-005184-01	SENSOR SENSING ADJUSTING RING	96	I1-1-8
GP-005355-00	Bed "A"	12	A-2-1
GP-005357-00	Needle Plate Bracket	30	D-4-22
GP-005357-01	Needle Plate Bracket	30	D-4-22
GP-005357-02	Needle Plate Bracket	30	D-4-22

Part No.	Part Name	Page	Ref.No
GP-005358-00	Rotary Hook Support	94	I-4-4
GP-005358-01	Rotary Hook Support	94	I-4-4
GP-005359-00	Bed Cover	94	I-4-6
GP-005359-01	Bed Cover	94	I-4-6
GP-005359-02	Bed Cover	94	I-4-6
GP-005360-00	Hook Cover	94	I-4-8
GP-005360-01	Hook Cover	94	I-4-8
GP-005360-02	Hook Cover	94	I-4-8
GP-005361-00	Hook Cover Insert	94	I-4-9
GP-005362-00	Hook Cover Holder	94	I-4-20
GP-005366-00	Picker Bracket	94	I-4-17
GP-005368-00	Picker	94	I-4-13
GP-005369-00	Picker Stopper	94	I-4-21
GP-005369-01	Picker Stopper	94	I-4-21
GP-005374-00	Y-Driving Box CoverA	66	H2-2-33
GP-005374-00	Y-Driving Box CoverA	74	H3-2-33
GP-005378-00	Idler Bush	66	H2-2-25
GP-005378-00	Idler Bush	74	H3-2-25
GP-005379-00	Tension Adjusting Roller	66	H2-2-23
GP-005379-00	Tension Adjusting Roller	74	H3-2-23
GP-005380-00	Coupling	66	H2-2-21
GP-005380-00	Coupling	74	H3-2-21
GP-005688-00	BODY INSIDE COVER C	133	P-1-21
GP-005688-01	BODY INSIDE COVER C	133	P-1-21
GP-005982-00	CABLE COVER FOR OP SUPPORT	133	P-1-26
GP-006119-00	PRESSER FOOT (L)	45	F-1-19
GP-006252-00	Cam Bushing	49	F-3-9
GP-006638-00	Moving Mes Shaft	30	D-4-8
GP-007144-00	Y-Bearing Bracket (R)	65	H2-1-43
GP-007144-00	Y-Bearing Bracket (R)	73	H3-1-43
GP-007145-00	Y-Bearing Bracket (L)	65	H2-1-44
GP-007145-00	Y-Bearing Bracket (L)	73	H3-1-44
GP-007148-00	Y-Driving Shaft "A"	83	H4-2-15
GP-007216-00	Needle Bar Return Spring	45	F-1-23
GP-007216-01	Needle Bar Return Spring	45	F-1-23
GP-007248-00	ARM TOP COVER	21	C-1-5
GP-007360-00	Head (9C)	45	F-1-1
GP-007360-01	Head (9C)	45	F-1-1
GP-007360-02	Head (9C)	45	F-1-1
GP-007360-03	Head (9C)	45	F-1-1
GP-007361-00	Head (12C)	45	F-1-1
GP-007361-01	Head (12C)	45	F-1-1
GP-007361-02	Head (12C)	45	F-1-1
GP-007361-03	Head (12C)	45	F-1-1
GP-007362-00	Head (12C)	45	F-1-1
GP-007362-01	Head (15C)	45	F-1-1
GP-007362-02	Head (15C)	45	F-1-1
GP-007362-03	Head (15C)	45	F-1-1
GP-007476-00	Noise Filter	115	L-2-7
GP-007511-00	Y-Driving Box	66	H2-2-5
GP-007511-00	Y-Driving Box	74	H3-2-5

R. Index

Part No.	Part Name	Page	Ref.No
18153SC-3123	Truss Screw (M4*L12)	130	O-1-7
18153SC-3123	Truss Screw (M4*L12)	131	O-2-2
18153SC-3123	Plus Screw (M4*L10)	138	Q1-3-13
18153SC-3123	Plus Screw (M4*L10)	146	Q3-3-15
18153SC-3123	Plus Screw (M4*L10)	150	Q4-3-15
18154SC-9134	PLUS SCREW (M3*L8)	114	L-1-20
19002SC-1330	TAPPING SCREW (4*L16-NO1)	107	K-4-21
20007BM-A001	Lamp Ass-Y "A"	125	N-1-12
20009EL-B001	LAMP (32W)	125	N-1-20
20009EL-WH09	Wheel Sensor Board 9C	53	G-2-7
20014ET-A001	Lamp Socket	125	N-1-14
20014SC-9124	Hex. Socket Screw(M4*L8)	125	N-1-13
20038PR-T121	WASHER (@8)	125	N-1-11
20042SC-9134	PLUS SCREW (M4*L6)	115	L-2-8
22002CW-UK01	Screw Bush "A"	136	Q1-1-2
22002CW-UK01	Screw Bush "A"	144	Q3-1-2
22002CW-UK01	Screw Bush "A"	148	Q4-1-2
22003CW-UK01	Location Block	136	Q1-1-3
22003CW-UK01	Location Block	144	Q3-1-3
22003CW-UK01	Location Block	148	Q4-1-3
22003PM-T121	Clip Bracket (L)	136	Q1-1-19
22003PM-T121	Clip Bracket (L)	140	Q2-1-9
22003PM-T121	Clip Bracket (L)	144	Q3-1-14
22003PM-T121	Clip Bracket (R)	148	Q4-1-24
22004PM-T121	Clip Bracket (R)	136	Q1-1-13
22004PM-T121	Clip Bracket (R)	140	Q2-1-8
22004PM-T121	Clip Bracket (R)	144	Q3-1-12
22004PM-T121	Clip Bracket (R)	148	Q4-1-14
22004PM-T121	Clip Bracket (R)	148	Q4-1-23
22005PR-T121	Clip	136	Q1-1-12
22005PR-T121	Clip	140	Q2-1-7
22005PR-T121	Clip	144	Q3-1-11
22005PR-T121	Clip	148	Q4-1-13
22005PR-T121	Clip	148	Q4-1-22
22006SC-7113	Hex.Socket Bolt (M3*L8)	23	C-3-20
22006SC-7113	Hex. Socket Bolt (M3*L8)	59	H1-3-9
22006SC-7113	Hex. Socket Bolt (M3*L8)	61	H1-5-2
22006SC-7113	Hex. Socket Bolt (M3*L8)	61	H1-5-4
22006SC-7113	Hex. Socket Bolt (M3*L8)	67	H2-3-9
22006SC-7113	Hex. Socket Bolt (M3*L8)	69	H2-5-2
22006SC-7113	Hex. Socket Bolt (M3*L8)	75	H3-3-9
22006SC-7113	Hex. Socket Bolt (M3*L8)	77	H3-5-3
22006SC-7113	Hex. Socket Bolt (M3*L8)	84	H4-3-9
22006SC-7113	Hex. Socket Bolt (M3*L8)	86	H4-5-3
22006SC-7113	Hex. Socket Bolt (M3*L8)	88	H4-6-35
22006SC-7113	Hex. Socket Bolt (M3*L8)	140	Q2-1-10
22007BR-UK01	Bearing Pin	136	Q1-1-7
22007BR-UK01	Bearing Pin	144	Q3-1-7
22007BR-UK01	Bearing Pin	148	Q4-1-7
22009BR-UK01	Needle Bearing (Taf51010)	136	Q1-1-8
22009BR-UK01	Needle Bearing (Taf51010)	144	Q3-1-8
22009BR-UK01	Needle Bearing (Taf51010)	148	Q4-1-8
22010PM-UK01	Tubular Frame Fixing Screw	146	Q3-3-16

Part No.	Part Name	Page	Ref.No
22017BM-UH16	Sqaure Frame (312*312) Ass'Y	141	Q2-2-10
22017BM-UH16	Sqaure Frame (312*312) Ass'Y	141	Q2-2-15
22038BM-UK01	Tubular Set	137	Q1-2-1
22038PM-UK01	Tubular (Inner) 45*44	137	Q1-2-2
22043PM-UK01	Tubular (Outer) 45*44	137	Q1-2-6
22044CW-UK01	Adjusting Bolt	137	Q1-2-7
22044CW-UK01	Adjusting Bolt	141	Q2-2-6
22044CW-UK01	Adjusting Bolt	141	Q2-2-16
22044CW-UK01	Adjusting Bolt	145	Q3-2-6
22044CW-UK01	Adjusting Bolt	149	Q4-2-6
22044CW-UK01	Adjusting Bolt	149	Q4-2-13
22045CW-UK01	Adjusting Bolt Guide	137	Q1-2-8
22045CW-UK01	Adjusting Bolt Guide	141	Q2-2-7
22045CW-UK01	Adjusting Bolt Guide	145	Q3-2-7
22045CW-UK01	Adjusting Bolt Guide	149	Q4-2-7
22046CW-UK01	Adjusting Nut	137	Q1-2-9
22046CW-UK01	Adjusting Nut	141	Q2-2-8
22046CW-UK01	Adjusting Nut	145	Q3-2-8
22046CW-UK01	Adjusting Nut	149	Q4-2-8
23019EL-A001	CODE Push (6NR-16)	79	H3-6-59
24004PR-UK01	Connecting Plate "F"	138	Q1-3-4
24004PR-UK01	Connecting Plate "F"	142	Q2-3-9
24004PR-UK01	Connecting Plate "F"	146	Q3-3-6
24004PR-UK01	Connecting Plate "F"	150	Q4-3-4
24004PR-UK02	Connecting Plate "E"	138	Q1-3-6
24004PR-UK02	Connecting Plate "E"	142	Q2-3-19
24007AD-UK01	Border Frame Sash L=575	138	Q1-3-3
24007AD-UK01	Border Frame Sash L=575	142	Q2-3-8
24007AD-UK01	Border Frame Sash L=575	146	Q3-3-3
24007AD-UK01	Border Frame Sash L=575	150	Q4-3-3
24008PR-UK02	Square Frame Fixiing Plate A	138	Q1-3-10
24008PR-UK02	Square Frame Fixing Plate A	142	Q2-3-20
24008PR-UK02	Square Frame Fixiing Plate A	146	Q3-3-10
24008PR-UK02	Square Frame Fixing Plate A	150	Q4-3-11
24011PR-T121	Connecting Plate "C"	138	Q1-3-7
24011PR-T121	Connecting Plate "C"	142	Q2-3-10
24011PR-T121	Connecting Plate "C"	146	Q3-3-8
24011PR-T121	Connecting Plate "C"	150	Q4-3-8
24011PR-UK02	Square Frame Fixiing Plate B	138	Q1-3-11
24011PR-UK02	Square Frame Fixing Plate B	142	Q2-3-21
24011PR-UK02	Square Frame Fixiing Plate B	146	Q3-3-12
24011PR-UK02	Square Frame Fixing Plate B	150	Q4-3-12
24016SF-T121	Felt	138	Q1-3-9
24016SF-T121	Felt	142	Q2-3-12
24016SF-T121	Felt	146	Q3-3-17
24016SF-T121	Felt	150	Q4-3-10
25009EL-UK06	Cable (25-09)	85	H4-4-33
25009EL-UK06	Cable (25-09)	88	H4-6-49
25013EL-UK02	X-Step Motor Driving Power 3	60	H1-4-35
25014EL-UK01	Cable (4Ht-14)	76	H3-4-35
25019EL-T121	Power Cable 2 (1Ht-19)	60	H1-4-36
25019EL-T121	Power Cable 2 (1Ht-19)	79	H3-6-52
25023EL-UK06	Cable (25-23)	29	D-3-18

Part No.	Part Name	Page	Ref.No
25029EL-UK01	C/C Motor Cable (2Ht-28)	50	F-4-15
25031EL-UK01	TO JOINT B/D CABLE (4HT-31)	126	N-2-13
25032EL-UK01	START STOP SWITCH (4HT-32)	126	N-2-12
25035EL-UK01	Cc Poten. Meter To J/B(4Ht-35) (UK1202)(UK1204)	50	F-4-13
25036EL-UK01	Cc Potentiometer Cable(4Ht-36)(UK1206)(UH1506C)	50	F-4-14
25037EL-UK01	Half Turn Cable (2Ht-36)	49	F-3-19
25038EL-UK06	Cable (25-38)	79	H3-6-53
25038EL-UK06	Cable (25-38)	88	H4-6-50
25039EL-UK06	Cable (25-39)	29	D-3-17
25040EL-T121	X-Original In Con. (1Ht-40)	61	H1-5-25
25041EL-UK01	X Original In (4Ht-41)	61	H1-5-26
25041EL-UK01	X Original In (4Ht-41)	79	H3-6-54
25041EL-UK01	X Original In (4Ht-41)	88	H4-6-51
25046EL-UK02	X-Original In Sensor (White)	61	H1-5-23
25047EL-UK02	X-Original In Sensor (Black)	61	H1-5-24
25052EL-UK01	LAST-SENSOR (BLACK) 4HT-52	70	H2-6-22
25052EL-UK01	LAST-SENSOR (BLACK) 4HT-52	79	H3-6-50
25052EL-UK01	Last-Sensor (Black) 4Ht-52	87	H4-6-15
25053EL-UK01	LAST-SENSOR (WHITE) 4HT-53	79	H3-6-51
25053EL-UK01	Last-Sensor (White) 4Ht-53	87	H4-6-16
25105ET-B001	Encoder Connector	24	C-4-13
25126EL-B001	Sensor Board To Wheel Earth	54	G-3-10
26006MC-8118	Stopper Screw (M2.6*L6)	17	B-4-13
28021SC-3123	Truss Screw (M3*L4)	12	A-2-16
29001EL-A001	MAIN POWER S/W (ABE53BF-30A)	115	L-2-15
32003ET-T121	Wick	15	B-2-2
32003ET-T121	Wick	17	B-4-18
32003ET-T121	Wick	17	B-4-20
32004PR-UK01	Lamp Socket Fixed Plate	125	N-1-15
32016PR-UH36	REFLECTING COVER	125	N-1-17
32021SP-T121	Needle Bar Hose Holder "B"	12	A-2-15
32025PR-UK01	Lamp Structure B	125	N-1-18
32040PR-T121	Bed Felt Cover	12	A-2-8
32043SF-T121	Front Bushing Felt	12	A-2-21
32045CW-T121	Oil Hose Pin	12	A-2-6
32046SP-T121	Holder For Oil Hose	12	A-2-14
32046SP-T121	HOLDER FOR OIL HOSE	14	B-1-8
32047RB-T121	Oil Rubber Cap	30	D-4-28
AS-000476-00	Tension Unit	52	G-1-19
AS-000476-01	Tension Unit	52	G-1-19
AS-000858-00	UPPER THREAD HOLDING SET	22	C-2-4
AS-001429-00	Picker Base Ass'Y	94	I-4-12
AS-001429-01	Picker Base Ass'Y	94	I-4-12
AS-001429-02	Picker Base Ass'Y	94	I-4-12
AS-002145-00	ARM SIDE COVER ASS'Y	17	B-4-1
AS-002145-01	ARM SIDE COVER ASS'Y	17	B-4-1
AS-002145-02	ARM SIDE COVER ASS'Y	17	B-4-1
AS-002145-03	ARM SIDE COVER ASS'Y	17	B-4-1
AS-002856-00	Y-Frame Assy (UH1506D)	57	H1-1-57
AS-002867-00	Y-Driving Box Assy	66	H2-2-34
AS-003154-00	PICKER SOLENOID	94	I-4-22
AS-003154-01	PICKER SOLENOID	94	I-4-22
AS-003447-00	Needle Bar Reciprocator A'ssy	17	B-4-6

R. Index

Part No.	Part Name	Page	Ref.No
AS-003951-00	Thread Control Device Ass'y	130	O-1-11
AS-004640-00	Color Change Motor Assy	49	F-3-26
BD-000144-00	XY Driver Board(220V)/(BD-000146-00(110V)	120	M-1-3
BD-000232-00	Thread Sensing Board	113	L-1-17
BD-000232-01	Thread Sensing Board	113	L-1-17
BD-000232-02	Thread Sensing Board	113	L-1-17
BD-000232-03	Thread Sensing Board	113	L-1-17
BD-000232-04	Thread Sensing Board	113	L-1-17
BD-000232-05	Thread Sensing Board	113	L-1-17
BD-000232-06	Thread Sensing Board	113	L-1-17
BD-000232-07	Thread Sensing Board	113	L-1-17
BD-000232-08	Thread Sensing Board	113	L-1-17
BD-000232-09	Thread Sensing Board	113	L-1-17
BD-000232-10	Thread Sensing Board	113	L-1-17
BD-000232-11	Thread Sensing Board	114	L-1-17
BD-000232-12	Thread Sensing Board	114	L-1-18
BD-000232-13	Thread Sensing Board	114	L-1-18
BD-000232-14	Thread Sensing Board	114	L-1-19
BD-000306-00	IO MC Board	120	M-1-8
BD-000306-00	Back plane Board	122	M-2-2
BD-000307-00	DDC Board	120	M-1-16
BD-000308-00	UNIT Board	120	M-1-26
BD-000310-00	Color Change Board	113	L-1-15
BD-000310-01	Color Change Board	113	L-1-15
BD-000310-02	Color Change Board	113	L-1-15
BD-000310-03	Color Change Board	113	L-1-15
BD-000310-04	Color Change Board	113	L-1-15
BD-000310-05	Color Change Board	113	L-1-15
BD-000310-06	Color Change Board	113	L-1-15
BD-000310-07	Color Change Board	113	L-1-15
BD-000310-08	Color Change Board	113	L-1-15
BD-000310-09	Color Change Board	113	L-1-15
BD-000310-10	Color Change Board	113	L-1-15
BD-000311-00	Main Drive (ASSY)(220V)/(BD-000312-00(110V)	120	M-1-1
BD-000343-00	IO LED Board	120	M-1-9
BD-000378-00	LAMP Board	121	M-1-37
BD-000383-00	DDC LED Board	120	M-1-17
BE-000023-00	Y-Driving Timing Belt	66	H2-2-18
BE-000023-00	Y-Driving Timing Belt	74	H3-2-18
CA-001730-00	EMEGUNCY S/W CABLE	126	N-2-14
CA-002982-00	Encoder Cable UH1204D	37	E-5-20
CA-002983-00	Encoder Cable UH1202D	43	E1-5-19
CA-002983-00	Encoder Cable UH1204D	43	E1-5-19
CA-002984-00	Encoder Cable UH1206D	37	E-5-20
CA-002985-00	Encoder Cable UH1206D	43	E1-5-19
CA-002986-00	Encoder Cable UH1202D	37	E-5-20
CA-002987-00	Encoder Cable UH1208D	37	E-5-20
CA-002988-00	Encoder Cable UH1208D	43	E1-5-19
EP-000029-00	SMPS	120	M-1-23
EP-000078-00	Transformer A'ssy	130	O-1-6
EP-000079-00	On / Off Switch	131	O-2-3
EP-000080-00	Push Switch (Start)	131	O-2-8
EP-000081-00	Push Switch (Stop)	131	O-2-9

Part No.	Part Name	Page	Ref.No
EP-000082-00	Switch (Select)	131	O-2-5
EP-000083-00	VR	131	O-2-7
EP-000095-00	PCB (DW-BW01)	130	O-1-8
EP-000140-00	Color Change Motor	50	F-4-1
EP-000141-00	Upper Thread Hook Motor Unit	90	I-1-1
EP-000141-00	Upper Thread Hook Motor Unit	96	I1-1-1
EP-000142-00	MAGNETIC SWITCH SET	115	L-2-9
EP-000149-00	Wiper Motor Driver	121	M-1-38
EP-000157-00	EMERGENCY SWITCH SET	126	N-2-11
GP-003757-00	Y-LM Guide Cover D	107	K-4-11
GP-004110-00	BODY FRONT COVER D	133	P-1-11
GP-004111-00	BODY FRONT COVER E	133	P-1-12
GP-004115-00	TABLE SUPPORT (C)	133	P-1-17
GP-004116-00	MOVABLE TABLE "A"	108	K-5-1
GP-004117-00	MOVABLE TABLE "B"	108	K-5-2
GP-004117-01	MOVABLE TABLE "B"	108	K-5-2
GP-004117-02	MOVABLE TABLE "B"	108	K-5-2
GP-004118-00	MOVABLE TABLE "C"	108	K-5-3
GP-004119-00	FIXED TABLE "A"	108	K-5-4
GP-004119-00	FIXED TABLE "A"	110	K-6-5
GP-004119-01	FIXED TABLE "A"	108	K-5-4
GP-004119-01	FIXED TABLE "A"	110	K-6-5
GP-004120-00	FIXED TABLE "C"	108	K-5-6
GP-004120-00	FIXED TABLE "C"	108	K-5-10
GP-004120-01	FIXED TABLE "C"	108	K-5-6
GP-004120-01	FIXED TABLE "C"	108	K-5-10
GP-004121-00	FIXED TABLE "D"	108	K-5-7
GP-004121-00	FIXED TABLE "E"	110	K-6-9
GP-004121-01	FIXED TABLE "D"	108	K-5-7
GP-004121-01	FIXED TABLE "E"	110	K-6-9
GP-004122-00	FIXED TABLE "F"	110	K-6-10
GP-004123-00	FIXED TABLE "H"	110	K-6-12
GP-004124-00	FIXED TABLE "I"	110	K-6-13
GP-004125-00	FIXED TABLE "J"	110	K-6-14
GP-004127-00	Y-LM Guide Cover A	108	K-5-16
GP-004127-00	Y-LM Guide Cover A	110	K-6-19
GP-004128-00	Y-LM Guide Cover B	110	K-6-21
GP-004128-01	Y-LM Guide Cover B	110	K-6-21
GP-004129-00	Y-LM Guide Cover C	108	K-5-18
GP-004129-00	Y-LM Guide Cover C	110	K-6-23
GP-004130-00	Y-LM Guide Cover D	108	K-5-20
GP-004130-00	Y-LM Guide Cover D	110	K-6-25
GP-004131-00	Y-LM Guide Cover E	108	K-5-22
GP-004131-00	Y-LM Guide Cover E	110	K-6-27
GP-004132-00	COUPLING COVER	108	K-5-24
GP-004132-00	COUPLING COVER B	110	K-6-30
GP-004134-00	SPOOL PLATE L=1680 UH1208D	101	J-1-1
GP-004135-00	THREAD ANGLE "A" L=1620 UH1208D	102	J-1-2
GP-004135-01	THREAD ANGLE "A" L=1620 UH1208D	102	J-1-2
GP-004136-00	THREAD ANGLE "B" L=1620 UH1208D	102	J-1-3
GP-004136-01	THREAD ANGLE "B" L=1620 UH1208D	102	J-1-3
GP-004137-00	THREAD ANGLE "C" L=1620 UH1208D	102	J-1-4
GP-004137-01	THREAD ANGLE "C" L=1620 UH1208D	102	J-1-4

Part No.	Part Name	Page	Ref.No
GP-004138-00	THREAD ANGLE "D" L=1620 UH1208D	102	J-1-5
GP-004138-01	THREAD ANGLE "D" L=1620 UH1208D	102	J-1-5
GP-004139-00	Rail Guide	31	D-5-1
GP-004142-00	X-FRAME(L=2135)	78	H3-6-1
GP-004142-01	X-FRAME(L=2135)	78	H3-6-1
GP-004142-02	X-FRAME(L=2135)	78	H3-6-1
GP-004143-00	X-LM RAIL "A" (THK SR15W- L580)	77	H3-5-1
GP-004144-00	LM Block Connecting Plate(L) (L=537)	77	H3-5-16
GP-004145-00	LM Block Connecting Plate(R) (L=537)	77	H3-5-20
GP-004146-00	X-FRAME COVER	78	H3-6-4
GP-004147-00	Cam Roller Guide Rail (L590)	59	H1-3-1
GP-004147-00	Cam Roller Guide Rail (L590)	84	H4-3-1
GP-004148-00	Y-LM Guide Frame L620	81	H4-1-1
GP-004148-01	Y-LM Guide Frame L620	81	H4-1-1
GP-004149-00	Bracket For X-Y Connecting	84	H4-3-4
GP-004149-01	Bracket For X-Y Connecting	84	H4-3-4
GP-004150-00	Y-LM Support Fixing Plate(A)	65	H2-1-56
GP-004150-00	Y-LM Support Fixing Plate(A)	73	H3-1-56
GP-004150-00	Bracket for Y-Sensor	82	H4-1-56
GP-004151-00	TOP SHAFT A [1897.5mm] UH1208D	35	E-3-19
GP-004152-00	TOP SHAFT B [2009.2mm] UH1208D	41	E1-3-19
GP-004153-00	LOW SHAFT A [1504mm] UH1208D	34	E-2-17
GP-004154-00	LOW SHAFT B [1702.5mm] UH1208D	40	E1-2-17
GP-004155-00	Mes Driving Shaft "A" L=1215.5 UH1208D	27	D-1-17
GP-004156-00	Upper Thread Driving Shaft A (L=1372) UH1208D	91	I-1-41
GP-004157-00	Upper Thread Driving Shaft B (L=1494) UH1208D	97	I1-1-41
GP-004159-00	Y-Driving Shaft UH1208D	66	H2-2-13
GP-004159-00	Y-Driving Shaft	74	H3-2-13
GP-004159-01	Y-Driving Shaft UH1208D	66	H2-2-13
GP-004159-01	Y-Driving Shaft UH1208D	74	H3-2-13
GP-004172-00	Tubular Frame	144	Q3-1-1
GP-004172-01	Tubular Frame	144	Q3-1-1
GP-004174-00	Front Border Frame Sash L=1744	146	Q3-3-1
GP-004175-00	Rear Border Frame Sash L=1744	146	Q3-3-2
GP-004272-00	X-FRAME SUPPORT BAR	78	H3-6-18
GP-004272-01	X-FRAME SUPPORT BAR	78	H3-6-18
GP-004896-00	FIXED TABLE "A"	106	K-3-2
GP-004896-01	FIXED TABLE "A"	106	K-3-2
GP-004897-00	FIXED TABLE "B"	106	K-3-3
GP-004897-01	FIXED TABLE "B"	106	K-3-3
GP-004898-00	FIXED TABLE "C"	106	K-3-4
GP-004898-00	FIXED TABLE "C"	107	K-4-6
GP-004898-01	FIXED TABLE "C"	106	K-3-4
GP-004898-01	FIXED TABLE "C"	107	K-4-6
GP-004899-00	FIXED TABLE "D"	106	K-3-5
GP-004899-01	FIXED TABLE "D"	106	K-3-5
GP-004900-00	FIXED TABLE "E"	106	K-3-6
GP-004900-01	FIXED TABLE "E"	106	K-3-6
GP-004901-00	MOVABLE TABLE	106	K-3-1
GP-004901-01	MOVABLE TABLE	106	K-3-1
GP-004902-00	MOVING TABLE FIXED PLATE B	104	K-1-2
GP-004903-00	Y-LM Guide Cover A	106	K-3-11
GP-004903-00	Y-LM GUIDE COVER A	107	K-4-8

R. Index

Part No.	Part Name	Page	Ref.No
AS-003951-00	Thread Control Device Ass'y	130	O-1-11
AS-004640-00	Color Change Motor Assy	49	F-3-26
BD-000144-00	XY Driver Board(220V)//BD-000146-00(110V)	120	M-1-3
BD-000232-00	Thread Sensing Board	113	L-1-17
BD-000232-01	Thread Sensing Board	113	L-1-17
BD-000232-02	Thread Sensing Board	113	L-1-17
BD-000232-03	Thread Sensing Board	113	L-1-17
BD-000232-04	Thread Sensing Board	113	L-1-17
BD-000232-05	Thread Sensing Board	113	L-1-17
BD-000232-06	Thread Sensing Board	113	L-1-17
BD-000232-07	Thread Sensing Board	113	L-1-17
BD-000232-08	Thread Sensing Board	113	L-1-17
BD-000232-09	Thread Sensing Board	113	L-1-17
BD-000232-10	Thread Sensing Board	113	L-1-17
BD-000232-11	Thread Sensing Board	114	L-1-17
BD-000232-12	Thread Sensing Board	114	L-1-18
BD-000232-13	Thread Sensing Board	114	L-1-18
BD-000232-14	Thread Sensing Board	114	L-1-19
BD-000306-00	IO MC Board	120	M-1-8
BD-000306-00	Back plane Board	122	M-2-2
BD-000307-00	DDC Board	120	M-1-16
BD-000308-00	UNIT Board	120	M-1-26
BD-000310-00	Color Change Board	113	L-1-15
BD-000310-01	Color Change Board	113	L-1-15
BD-000310-02	Color Change Board	113	L-1-15
BD-000310-03	Color Change Board	113	L-1-15
BD-000310-04	Color Change Board	113	L-1-15
BD-000310-05	Color Change Board	113	L-1-15
BD-000310-06	Color Change Board	113	L-1-15
BD-000310-07	Color Change Board	113	L-1-15
BD-000310-08	Color Change Board	113	L-1-15
BD-000310-09	Color Change Board	113	L-1-15
BD-000310-10	Color Change Board	113	L-1-15
BD-000310-11	Color Change Board	113	L-1-15
BD-000310-12	Color Change Board	113	L-1-15
BD-000310-13	Color Change Board	113	L-1-15
BD-000310-14	Color Change Board	113	L-1-15
BD-000311-00	Main Drive (ASSY)(220V)//BD-000312-00(110V)	120	M-1-1
BD-000343-00	IO LED Board	120	M-1-9
BD-000378-00	LAMP Board	121	M-1-37
BD-000383-00	DDC LED Board	120	M-1-17
BE-000023-00	Y-Driving Timing Belt	66	H2-2-18
BE-000023-00	Y-Driving Timing Belt	74	H3-2-18
CA-001730-00	EMEGUNCY S/W CABLE	126	N-2-14
CA-002982-00	Encoder Cable UH1204D	37	E-5-20
CA-002983-00	Encoder Cable UH1202D	43	E1-5-19
CA-002983-00	Encoder Cable UH1204D	43	E1-5-19
CA-002984-00	Encoder Cable UH1206D	37	E-5-20
CA-002985-00	Encoder Cable UH1206D	43	E1-5-19
CA-002986-00	Encoder Cable UH1202D	37	E-5-20
CA-002987-00	Encoder Cable UH1208D	37	E-5-20
CA-002988-00	Encoder Cable UH1208D	43	E1-5-19
EP-000029-00	SMPS	120	M-1-23

Part No.	Part Name	Page	Ref.No
EP-000078-00	Transformer A'ssy	130	O-1-6
EP-000079-00	On / Off Switch	131	O-2-3
EP-000080-00	Push Switch (Start)	131	O-2-8
EP-000081-00	Push Switch (Stop)	131	O-2-9
EP-000082-00	Switch (Select)	131	O-2-5
EP-000083-00	VR	131	O-2-7
EP-000095-00	PCB (DW-BW01)	130	O-1-8
EP-000140-00	Color Change Motor	50	F-4-1
EP-000141-00	Upper Thread Hook Motor Unit	90	I-1-1
EP-000141-00	Upper Thread Hook Motor Unit	96	I1-1-1
EP-000142-00	MAGNETIC SWITCH SET	115	L-2-9
EP-000149-00	Wiper Motor Driver	121	M-1-38
EP-000157-00	EMERGENCY SWITCH SET	126	N-2-11
GP-003757-00	Y-LM Guide Cover D	107	K-4-11
GP-004110-00	BODY FRONT COVER D	133	P-1-11
GP-004111-00	BODY FRONT COVER E	133	P-1-12
GP-004115-00	TABLE SUPPORT (C)	133	P-1-17
GP-004116-00	MOVABLE TABLE "A"	108	K-5-1
GP-004117-00	MOVABLE TABLE "B"	108	K-5-2
GP-004117-01	MOVABLE TABLE "B"	108	K-5-2
GP-004117-02	MOVABLE TABLE "B"	108	K-5-2
GP-004118-00	MOVABLE TABLE "C"	108	K-5-3
GP-004119-00	FIXED TABLE "A"	108	K-5-4
GP-004119-00	FIXED TABLE "A"	110	K-6-5
GP-004119-01	FIXED TABLE "A"	108	K-5-4
GP-004119-01	FIXED TABLE "A"	110	K-6-5
GP-004120-00	FIXED TABLE "C"	108	K-5-6
GP-004120-00	FIXED TABLE "C"	108	K-5-10
GP-004120-01	FIXED TABLE "C"	108	K-5-6
GP-004120-01	FIXED TABLE "C"	108	K-5-10
GP-004121-00	FIXED TABLE "D"	108	K-5-7
GP-004121-00	FIXED TABLE "E"	110	K-6-9
GP-004121-01	FIXED TABLE "D"	108	K-5-7
GP-004121-01	FIXED TABLE "E"	110	K-6-9
GP-004122-00	FIXED TABLE "F"	110	K-6-10
GP-004123-00	FIXED TABLE "H"	110	K-6-12
GP-004124-00	FIXED TABLE "I"	110	K-6-13
GP-004125-00	FIXED TABLE "J"	110	K-6-14
GP-004127-00	Y-LM Guide Cover A	108	K-5-16
GP-004127-00	Y-LM Guide Cover A	110	K-6-19
GP-004128-00	Y-LM Guide Cover B	110	K-6-21
GP-004128-01	Y-LM Guide Cover B	110	K-6-21
GP-004129-00	Y-LM Guide Cover C	108	K-5-18
GP-004129-00	Y-LM Guide Cover C	110	K-6-23
GP-004130-00	Y-LM Guide Cover D	108	K-5-20
GP-004130-00	Y-LM Guide Cover D	110	K-6-25
GP-004131-00	Y-LM Guide Cover E	108	K-5-22
GP-004131-00	Y-LM Guide Cover E	110	K-6-27
GP-004132-00	COUPLING COVER	108	K-5-24
GP-004132-00	COUPLING COVER B	110	K-6-30
GP-004134-00	SPOOL PLATE L=1680 UH1208D	101	J-1-1
GP-004135-00	THREAD ANGLE "A" L=1620 UH1208D	102	J-1-2
GP-004135-01	THREAD ANGLE "A" L=1620 UH1208D	102	J-1-2

Part No.	Part Name	Page	Ref.No
GP-004136-00	THREAD ANGLE "B" L=1620 UH1208D	102	J-1-3
GP-004136-01	THREAD ANGLE "B" L=1620 UH1208D	102	J-1-3
GP-004137-00	THREAD ANGLE "C" L=1620 UH1208D	102	J-1-4
GP-004137-01	THREAD ANGLE "C" L=1620 UH1208D	102	J-1-4
GP-004138-00	THREAD ANGLE "D" L=1620 UH1208D	102	J-1-5
GP-004138-01	THREAD ANGLE "D" L=1620 UH1208D	102	J-1-5
GP-004139-00	Rail Guide	31	D-5-1
GP-004142-00	X-FRAME(L=2135)	78	H3-6-1
GP-004142-01	X-FRAME(L=2135)	78	H3-6-1
GP-004142-02	X-FRAME(L=2135)	78	H3-6-1
GP-004143-00	X-LM RAIL "A" (THK SR15W- L580)	77	H3-5-1
GP-004144-00	LM Block Connecting Plate(L) (L=537)	77	H3-5-16
GP-004145-00	LM Block Connecting Plate(R) (L=537)	77	H3-5-20
GP-004146-00	X-FRAME COVER	78	H3-6-4
GP-004147-00	Cam Roller Guide Rail (L590)	59	H1-3-1
GP-004147-00	Cam Roller Guide Rail (L590)	84	H4-3-1
GP-004148-00	Y-LM Guide Frame L620	81	H4-1-1
GP-004148-01	Y-LM Guide Frame L620	81	H4-1-1
GP-004149-00	Bracket For X-Y Connecting	84	H4-3-4
GP-004149-01	Bracket For X-Y Connecting	84	H4-3-4
GP-004150-00	Y-LM Support Fixing Plate(A)	65	H2-1-56
GP-004150-00	Y-LM Support Fixing Plate(A)	73	H3-1-56
GP-004150-00	Bracket for Y-Sensor	82	H4-1-56
GP-004151-00	TOP SHAFT A [1897.5mm] UH1208D	35	E-3-19
GP-004152-00	TOP SHAFT B [2009.2mm] UH1208D	41	E1-3-19
GP-004153-00	LOW SHAFT A [1504mm] UH1208D	34	E-2-17
GP-004154-00	LOW SHAFT B [1702.5mm] UH1208D	40	E1-2-17
GP-004155-00	Mes Driving Shaft "A" L=1215.5 UH1208D	27	D-1-17
GP-004156-00	Upper Thread Driving Shaft A (L=1372) UH1208D	91	I-1-41
GP-004157-00	Upper Thread Driving Shaft B (L=1494) UH1208D	97	I1-1-41
GP-004159-00	Y-Driving Shaft UH1208D	66	H2-2-13
GP-004159-00	Y-Driving Shaft	74	H3-2-13
GP-004159-01	Y-Driving Shaft UH1208D	66	H2-2-13
GP-004159-01	Y-Driving Shaft UH1208D	74	H3-2-13
GP-004172-00	Tubular Frame	144	Q3-1-1
GP-004172-01	Tubular Frame	144	Q3-1-1
GP-004174-00	Front Border Frame Sash L=1744	146	Q3-3-1
GP-004175-00	Rear Border Frame Sash L=1744	146	Q3-3-2
GP-004272-00	X-FRAME SUPPORT BAR	78	H3-6-18
GP-004272-01	X-FRAME SUPPORT BAR	78	H3-6-18
GP-004896-00	FIXED TABLE "A"	106	K-3-2
GP-004896-01	FIXED TABLE "A"	106	K-3-2
GP-004897-00	FIXED TABLE "B"	106	K-3-3
GP-004897-01	FIXED TABLE "B"	106	K-3-3
GP-004898-00	FIXED TABLE "C"	106	K-3-4
GP-004898-00	FIXED TABLE "C"	107	K-4-6
GP-004898-01	FIXED TABLE "C"	106	K-3-4
GP-004898-01	FIXED TABLE "C"	107	K-4-6
GP-004899-00	FIXED TABLE "D"	106	K-3-5
GP-004899-01	FIXED TABLE "D"	106	K-3-5
GP-004900-00	FIXED TABLE "E"	106	K-3-6
GP-004900-01	FIXED TABLE "E"	106	K-3-6
GP-004901-00	MOVABLE TABLE	106	K-3-1

R. Index

Part No.	Part Name	Page	Ref.No
GP-004901-01	MOVABLE TABLE	106	K-3-1
GP-004902-00	MOVING TABLE FIXED PLATE B	104	K-1-2
GP-004903-00	Y-LM Guide Cover A	106	K-3-11
GP-004903-00	Y-LM GUIDE COVER A	107	K-4-8
GP-007512-00	Idle Shaft	66	H2-2-28
GP-007512-00	Idle Shaft	74	H3-2-28
GP-007512-01	Idle Shaft	66	H2-2-28
GP-007512-01	Idle Shaft	74	H3-2-28
GP-007513-00	Y-Driving Box Bracket	66	H2-2-29
GP-007513-00	Y-Driving Box Bracket	74	H3-2-29
GP-007514-00	Y-Driving Box Cover B	108	K-5-29
GP-007515-00	Y-Driving Box Driven Shaft	66	H2-2-19
GP-007515-00	Y-Driving Box Driven Shaft	74	H3-2-19
GP-007516-00	Y-Driving Shaft "B" UH1506D	66	H2-2-13
GP-007516-00	Y-Driving Shaft "B"	74	H3-2-13
GP-007517-00	Y-Driving Shaft "C" UH1506D	66	H2-2-12
GP-007517-00	Y-Driving Shaft "C"	74	H3-2-12
GP-007518-00	X-LM GUIDE FRAME L2635	70	H2-6-1
GP-007518-01	X-LM GUIDE FRAME L2635	70	H2-6-1
GP-007518-02	X-LM GUIDE FRAME L2635	70	H2-6-1
GP-007519-00	L/M Block Connecting Plate (L)	69	H2-5-9
GP-007520-00	Connecting Plate(R)	69	H2-5-7
GP-007523-00	X-Axis L/M Guide	69	H2-5-1
GP-007525-00	X-Cover	70	H2-6-4
GP-007526-00	Tubular Frame	140	Q2-1-1
GP-007532-00	FIXED TABLE "A"	107	K-4-1
GP-007532-01	FIXED TABLE "A"	107	K-4-1
GP-007532-02	FIXED TABLE "A"	107	K-4-1
GP-007533-00	FIXED TABLE "B"	107	K-4-2
GP-007533-01	FIXED TABLE "B"	107	K-4-2
GP-007534-00	FIXED TABLE "C"	107	K-4-3
GP-007534-01	FIXED TABLE "C"	107	K-4-3
GP-007534-02	FIXED TABLE "C"	107	K-4-3
GP-007535-00	FIXED TABLE "D"	107	K-4-4
GP-007535-00	Y-LM GUIDE COVER C	107	K-4-10
GP-007536-00	Y-LM GUIDE COVER B	107	K-4-9
GP-007537-00	COUPLING COVER	107	K-4-12
GP-007537-01	COUPLING COVER	107	K-4-12
GP-007852-00	BODY INSIDE COVER B	133	P-1-22
GP-007852-01	BODY INSIDE COVER B	133	P-1-22
GP-008540-00	Needle Bar Guide Rail (9C)	47	F-2-15
GP-008541-00	Needle Bar Guide Rail (12C)	47	F-2-15
GP-008542-00	Needle Bar Guide Rail (15C)	47	F-2-15
GP-008647-00	Operation Box Rotation Shaft	123	M-3-6
GP-008648-00	Operation Box Support Plate	123	M-3-11
GP-008651-00	Operation Box Base Block	123	M-3-13
GP-008651-01	Operation Box Base Block	123	M-3-13
GP-008769-00	Jump Driving Crank	23	C-3-9
GP-008769-01	Jump Driving Crank	23	C-3-9
GP-008788-00	Cable Cover A	125	N-1-1
GP-008789-00	Cable Cover B	125	N-1-2
GP-008789-01	Cable Cover B	125	N-1-2
GP-008790-00	BODY SIDE COVER	133	P-1-1

Part No.	Part Name	Page	Ref.No
GP-008793-00	Tubular Frame Rail Plate	70	H2-6-3
GP-008796-00	Perception Plate	69	H2-5-14
GP-008796-01	Perception Plate	69	H2-5-14
GP-008797-00	TABLE SUPPORT C	105	K-2-3
GP-008797-01	TABLE SUPPORT C	105	K-2-3
GP-008799-00	Table Support (R)	104	K-1-3
GP-008799-00	Table Support (R)	104	K-1-16
GP-008800-00	Table Support (L)	104	K-1-11
GP-008801-00	Rear Border Frame Sash L=1344	142	Q2-3-18
GP-008802-00	Front Border Frame Sash L=1344	142	Q2-3-7
GP-008893-00	BODY INSIDE COVER B	133	P-1-23
GP-008894-00	FIXED TABLE "B"	108	K-5-5
GP-008895-00	FIXED TABLE "H"	108	K-5-8
GP-008895-01	FIXED TABLE "H"	108	K-5-8
GP-008898-00	Y-LM GUIDE COVER C	108	K-5-25
GP-008899-00	Y-LM GUIDE COVER D	108	K-5-27
GP-008900-00	FIXED TABLE "I"	108	K-5-9
GP-009589-00	Oil Tank Ass'Y	14	B-1-1
GP-009590-00	Oil Tank Felt	14	B-1-2
GP-010074-00	LEVELING BASE ASS'Y	134	P-2-3
GP-010385-00	NEEDLE GUIDE PLATE(FLAT)	30	D-4-32
GP-010408-00	SCREW BUSH C	136	Q1-1-6
GP-010408-00	SCREW BUSH C	144	Q3-1-6
GP-010543-01	SMPS Fixing Stud (3-5-45)	120	M-1-27
GP-010695-00	TABLE SUPPORT B	105	K-2-7
GP-010695-01	TABLE SUPPORT B	105	K-2-7
GP-010770-00	Bracket For I/O s/w(A)	115	L-2-1
GP-011303-00	Color Change Cover	50	F-4-16
GP-011444-00	Mes Cam Driving Box (B)	27	D-1-1
GP-011445-00	Mes Cam Driving Box (A)	27	D-1-1
GP-011912-00	ARM SIDE COVER B	19	B-6-5
GP-011912-01	ARM SIDE COVER B	19	B-6-5
GP-011914-00	Take-Up Driving Lever "B"	15	B-2-8
GP-011915-00	Take-Up Lever Driving Cam	16	B-3-6
GP-011932-00	NEEDLE BAR DRIVING CAM	16	B-3-5
GP-011938-00	CAM BASE	16	B-3-1
GP-011938-01	CAM BASE	16	B-3-1
GP-011943-00	ARM	19	B-6-1
GP-012048-00	NEEDLE BAR DRIVING SHAFT BUSH	17	B-4-16
GP-012118-00	SMPS Radiator Sheet	120	M-1-25
GP-012800-00	Needle Plate Guide(L)	30	D-4-25
GP-012801-00	Needle Plate Guide(R)	30	D-4-26
GP-012897-00	MOTOR FIXING	37	E-5-5
GP-012897-00	MOTOR FIXING	43	E1-5-5
GP-013117-00	Needle Bar Driving Shaft	17	B-4-19
GP-013783-00	DDC Radiator	120	M-1-15
GP-013784-00	Driver Radiator	120	M-1-4
GP-014009-00	OP Support	123	M-3-2
GP-014009-01	OP Support	123	M-3-2
GP-014027-01	DDC Bracket	120	M-1-14
GP-014028-01	IO MC Bracket	120	M-1-13
GP-014029-01	SMPS Bracket	120	M-1-22
GP-014030-01	LAMP Bracket	120	M-1-36

Part No.	Part Name	Page	Ref.No
GP-014034-00	Front Cover (L)	121	M-1-41
GP-014036-00	Harness Cover	122	M-2-15
GP-014038-00	Side Cover	122	M-2-7
GP-014042-00	SMPS Fixture	120	M-1-29
GP-014047-00	Control Box	122	M-2-1
GP-014047-01	Connector PCB Cover	122	M-2-4
GP-014346-00	Rubber For Support Base	130	O-1-18
GP-014354-00	Bobbin Shaft	130	O-1-15
GP-014354-01	Bobbin Shaft	130	O-1-15
GP-014354-02	Bobbin Shaft	130	O-1-15
GP-014354-03	Bobbin Shaft	130	O-1-15
GP-014363-00	Spool Support Base	130	O-1-3
GP-014365-00	Spool Support Base Sponge	130	O-1-4
GP-014366-00	Spool Post	130	O-1-2
GP-014368-00	Antenna Bar	131	O-2-11
GP-014369-00	Antenna Bar Hanger	131	O-2-10
GP-014370-00	Tension Control Holder	130	O-1-10
GP-014548-00	DDC Sticker	121	M-1-46
GP-014549-00	IO MC Sticker	121	M-1-45
GP-014550-00	SMPS Sticker	121	M-1-47
GP-014677-00	VR Knob	131	O-2-6
GP-014678-00	Fuse Holder	131	O-2-4
GP-014783-00	Presser Foot Cam Boss	16	B-3-14
GP-014783-01	Presser Foot Cam Boss	16	B-3-14
GP-014783-02	Presser Foot Cam Boss	16	B-3-14
GP-014783-03	Presser Foot Cam Boss	16	B-3-14
GP-014783-04	Presser Foot Cam Boss	16	B-3-14
GP-014869-00	Cover	131	O-2-1
GP-014869-01	Cover	131	O-2-1
GP-014870-00	Base	130	O-1-1
GP-014871-00	Motor Bracket	130	O-1-14
GP-014939-00	Cam Spacer	16	B-3-11
GP-014993-00	BEAMBODY SET UH1506D-45	11	A-1-1
GP-014993-01	BEAMBODY SET UH1506D-45	11	A-1-1
GP-015085-00	UPPER THREAD HOOK SENSOR BASE	90	I-1-12
GP-015085-00	UPPER THREAD HOOK SENSOR BASE	96	I1-1-12
GP-015086-00	Motor Base	90	I-1-2
GP-015086-00	Motor Base	96	I1-1-2
GP-015653-00	SMPS Radiator	120	M-1-24
GP-015654-00	DDC Radiator Sheet	120	M-1-19
GP-016753-00	BODY INSIDE COVER A	133	P-1-19
GP-016756-00	BODY INSIDE COVER D	115	L-2-4
GP-016766-00	BEAMBODY SET UH1504D-45	11	A-1-1
GP-016766-01	BEAMBODY SET UH1504D-45	11	A-1-1
GP-016766-02	BEAMBODY SET UH1504D-45	11	A-1-1
GP-016767-00	BEAMBODY SET UH1208D-45	11	A-1-1
GP-016767-01	BEAMBODY SET UH1208D-45	11	A-1-1
GP-016768-00	BEAMBODY SET UH1512D-45	11	A-1-1
GP-016768-01	BEAMBODY SET UH1512D-45	11	A-1-1
GP-016768-02	BEAMBODY SET UH1512D-45	11	A-1-1
GP-016801-00	TOP SHAFT COVER B-1	127	N-3-7
GP-016802-00	TOP SHAFT COVER B-2	127	N-3-8
GP-016931-00	Hook Shaft Front Bushing	12	A-2-18

[illegible][illegible][illegible]