

PARTS BOOK




**Dual Function
Automatic Embroidery Machine**

SMT[®]

PME-080201

SUNSTAR PRECISION CO., LTD.

Machine Layout



- A1 Machine Body Ass'y(UH1504D)
- A2 Machine Body Ass'y(UH1506D)
- A3 Machine Body Ass'y(UH1208D)
- A4 Machine Body Ass'y(UH1512D)
- B1 Work Table(UH1504D)
- B2 Work Table(UH1506D)
- B3 Work Table(UH1208D)
- B4 Work Table(UH1512D)
- C Spool Stand
- D1 Main Drive System I
- D2 Main Drive System II
- E1 Bed I
- E2 Bed II
- E3 Bed III(UH1208D)
- F Thread Cutting Drive System
- G1 Arm I
- G2 Arm II
- G3 Arm III
- H Color Change Set
- I1 Wiper Set I
- I2 Wiper Set II
- J Head
- K Thread Tension Unit
- L1 X-Axis Drive System(UH1504D)
- L2 X-Axis Drive System I(UH1506D)
- L3 X-Axis Drive System II(UH1506D)
- L4 X-Axis Drive System(UH1208D)
- L5 X-Axis Drive System(UH1512D)
- M1 Y-Axis Drive System(UH1504D)
- M2 Y-Axis Drive System(UH1506D)
- M3 Y-Axis Drive System(UH1208D, UH1512D)
- N1 Tubular Frame(UH1504D)
- N2 Tubular Frame(UH1506D)
- N3 Tubular Frame(UH1508D)
- N4 Tubular Frame(UH1512D)
- O1 Boder Frame(UH1504D)
- O2 Boder Frame(UH1506D)
- O3 Boder Frame(UH1208D)
- O4 Boder Frame(UH1512D)
- P S/B Switch Unit
- Q1 Sub Control Unit & Lamp(UH1504D)
- Q2 Sub Control Unit & Lamp(UH1506D)
- Q3 Sub Control Unit & Lamp(UH1208D)
- Q4 Sub Control Unit & Lamp(UH1512D)
- R Control Box
- S Cable
- T Operation Box
- U Cable
- V Bobbin Winder



CONTENT

1. 조에 속한 파트는 개별 조립 시 제품의 파손 또는 재봉 불량 발생될 수 있어 해당 파트에 대한 주문 시에는 조 품목으로만 구입이 가능합니다.
2. 본 책자는Parts Book으로 제작되었으므로 매뉴얼로 사용 불가합니다.

1. The parts classified as ass'y items may cause damage to the machine or bad sewing when they are separately assembled.
Hence, when they are ordered, they can be purchased as ass'y items only.
2. This is a parts book. It cannot be used as a manual.

A1	Machine Body Ass'y (UH1504D)	7
A2	Machine Body Ass'y (UH1506D)	9
A3	Machine Body Ass'y (UH1208D)	11
A4	Machine Body Ass'y (UH1512D)	13
B1	Work Table (UH1504D)	15
B2	Work Table (UH1506D)	19
B3	Work Table (UH1208D)	21
B4	Work Table (UH1512D)	25
C	Spool Stand	29
D1	Main Drive System I	31
D2	Main Drive System II	35
E1	Bed I	39
E2	Bed II	41
E3	Bed III (UH1208D, UH1512D)	43
F	Thread Cutting Drive System	45
G1	Arm I	47
G2	Arm II	51
G3	Arm III	53
H	Color Change Set	55
I1	Wiper Set I	57
I2	Wiper Set II	61
J	Head	65
K	Thread Tension Unit	69
L1	X-Axis Drive System (UH1504D)	71
L2	X-Axis Drive Set (UH1506D)	73




CONTENT

L3	X-Axis Drive System (UH1208D)	81
L4	X-Axis Drive System (UH1208D)	83
L5	X-Axis Drive System (UH1512D)	85
M1	Y-Axis Drive System (UH1504D)	89
M2	Y-Axis Drive System (UH1506D, UH1508D)	91
M3	Y-Axis Drive System (UH1512D)	95
N1	Tubular Frame (UH1504D)	101
N2	Tubular Frame (UH1506D)	103
N3	Tubular Frame (UH1208D)	105
N4	Tubular Frame (UH1512D)	107
O1	Border Frame (UH1504D)	109
O2	Border Frame (UH1506D)	111
O3	Border Frame (UH1208D)	113
O4	Border Frame (UH1512D)	115
P	S/B Switch Unit	117
Q1	Sub-Control Unit & Lamp (UH1504D)	119
Q2	Sub-Control Unit & Lamp (UH1506D)	121
Q3	Sub-Control Unit & Lamp (UH1208D)	123
Q4	Sub-Control Unit & Lamp (UH1512D)	125
R	Main Controller	127
S	Main Controller Cable	129
T	Operation Unit	131
U	Operation Unit Cable	135
V	Bobbin Winder	137

A1


Machine Body Ass'y (UH1504D)



[illegible]

A2


Machine Body Ass'y (UH1506D)



[illegible]

A3


Machine Body Ass'y (UH1208D)



[illegible]


A4

Machine Body Ass'y (UH1512D)



B1

Work Table (UH1504D)




Ref.No	Part No.	Part Names	Q'ty
B1001	GP-004901-01	MOVABLE TABLE	2
B1002	GP-004896-01	FIXED TABLE "A"	1
B1003	GP-004897-01	FIXED TABLE "B"	1
B1004	GP-004898-01	FIXED TABLE "C"	1
B1005	GP-004899-01	FIXED TABLE "D"	1
B1006	GP-004900-01	FIXED TABLE "E"	1
B1007	GP-004907-00	TABLE SUPPORT A	4
B1008	GP-004908-00	TABLE SUPPORT B	8
B1009	GP-008797-00	TABLE SUPPORT C	10
B1010	16009SC-4113	HEX.SOCKET BOLT(M10*L25)	54
B1011	16029SW-4115	SPRING WASHER (10@)	54
B1012	16009SC-8330	TAPPING SCREW (M6*L20)	74
B1013	16018PR-UK01	MES CAM DRIVING BOX COVER	2
B1014	02030SC-T121	BED COVER SCREW(9/64" 40)	8
B1015	05001400UH60	THREAD CUTTING BOX COVER B	1
B1016	02030SC-T121	BED COVER SCREW(9/64" 40)	4
B1017	GP-004903-00	Y-LM Guide Cover A	1
B1018	08101SC-8329	TAPPING SCREW (M3*L16)	4
B1019	GP-004904-00	Y-LM Guide Cover B	1
B1020	08101SC-8329	TAPPING SCREW (M3*L16)	6
B1021	GP-004905-00	Y-LM Guide Cover C	1
B1022	08101SC-8329	TAPPING SCREW (M3*L16)	4
B1023	GP-004906-00	Y-LM Guide Cover D	1
B1024	08101SC-8329	TAPPING SCREW (M3*L16)	6
B1025	GP-004910-00	Y-MOTOR COVER	2
B1026	08101SC-8329	TAPPING SCREW (M3*L16)	8
B1027	05002000UH60	MOVING TABLE FIXED PLATE A	4
B1028	GP-004902-00	MOVING TABLE FIXED PLATE B	4
B1029	08062SC-4113	HEX. SOCKET BOLT (M5*L20)	16
B1030	16019SW-4115	SPRING WASHER (@5)	16
B1031	16018SW-1111	WASHER (@5)	16
B1032	05001500UK40	ANGLE SUPPORT	8
B1033	08076SC-4113	HEX. SOCKET BOLT (M5*L12)	16
B1034	16019SW-4115	SPRING WASHER (@5)	16
B1035	16018SW-1111	WASHER (@5)	16
B1036	05010400U000	TABLE SUPPORTER (B2) L=402	2
B1037	05010400U000	TABLE SUPPORTER (B2) L=402	2
B1038	08076SC-4113	HEX. SOCKET BOLT (M5*L12)	16
B1039	16019SW-4115	SPRING WASHER (@5)	16
B1040	16018SW-1111	WASHER (@5)	16

Ref. No	Part No.	Part Names	Q'ty
B1041	05001700U000	TABLE SUPPORT PLATE	32
B1042	05002400UH60	OP Holder Support Cover (A)	1
B1043	GP-004909-01	OP Holder Support Cover (B)	1
B1044	08101SC-8329	TAPPING SCREW (M3*L16)	4
B1045	16052AD-UK01	TABLE SUPPORT GUIDE	4
B1046	02015SC-7113	Hex.Socket Bolt(M4*L10)	8
B1047	02028SW-9115	Spring Washer (@4)	8
B1048	05009SW-1111	Washer (@4-L)	8
B1049	17062SC-UK01	Table Support Stopper Screw	4
B1050	05001300U000	TABLE SUPPORT L=263	4
B1051	16061PR-UK01	TABLE SUPPORT PLATE (A)	4
B1052	17012SC-8329	Hex. Socket Set Screw(M4*L16)	8
B1053	16058AD-UK01	TABLE SUPPORT PLATE (B)	4
B1054	15089SC-7119	C.S Screw (M4*L12)	8
B1055	17063SC-UK01	Table Support Stopper Screw	4
B1056	16065PR-UK01	CLAMP PLATE	4
B1057	16009SC-8330	Tapping Screw (M6*L20)	12
B1058	16067ET-UK01	TABLE TOGGLE CLAMP	12
B1059	16009SC-8330	Tapping Screw (M6*L20)	48
B1060	16016PR-UK01	GEAR COVER	3
B1061	02030SC-T121	BED COVER SCREW(9/64" 40)	6
B1062	05008100UK40	TABLE FIXING BLOCK	10
B1063	04030MC-7113	HEX.SOCKET BOLT (M4*L30)	20
B1064	18015SW-3111	WASHER (4@)	20
B1065	17085PM-UK01	POSITIONING BLOCK	8
B1066	02015SC-4113	HEX.SOCKET BOLT(M4*L10)	16
B1067	16063PM-UK01	TABLE HOLDING BLOCK	4
B1068	16009SC-8330	TAPPING SCREW (M6*L20)	8
B1069	GP-008800-00	Table Support (L)	1
B1070	03016SC-4113	CAP FRAME SET SCREW	2
B1071	16019SW-4115	SPRING WASHER (@5)	2
B1072	16018SW-1111	WASHER (@5)	2
B1073	16009SC-8330	TAPPING SCREW (M6*L20)	2
B1074	GP-008799-00	Table Support (R)	1
B1075	03016SC-4113	CAP FRAME SET SCREW	2
B1076	16019SW-4115	SPRING WASHER (@5)	2
B1077	16018SW-1111	WASHER (@5)	2
B1078	16009SC-8330	TAPPING SCREW (M6*L20)	2
B1079	16005RB-A001	Table Support End Cap(L)	28
B1080	GP-008800-00	Table Support (L)	2


B1

Work Table (UH1504D)



B2

Work Table (UH1506D)




Ref.No	Part No.	Part Names	Q'ty
B2001	GP-007532-02	FIXED TABLE "A"	1
B2002	GP-007533-01	FIXED TABLE "B"	1
B2003	GP-007534-02	FIXED TABLE "C"	1
B2004	GP-007535-00	FIXED TABLE "D"	1
B2008	08000100UH60	Movable Table	2
B2009	08101SC-8329	TAPPING SCREW (M3*L16)	68
B2010	GP-004903-00	Y-LM GUIDE COVER A	1
B2011	GP-007536-00	Y-LM GUIDE COVER B	1
B2012	GP-007535-00	Y-LM GUIDE COVER C	1
B2014	GP-007537-01	COUPLING COVER	2
B2015	05002400UH60	OP Holder Support Cover (A)	1
B2016	05002500UH60	OP Holder Support Cover (B)	1
B2017	16018PR-UK01	MES CAM DRIVING BOX COVER	2
B2018	05001400UH60	THREAD CUTTING BOX COVER B	1
B2019	02030SC-T121	BED COVER SCREW(9/64" 40)	8
B2020	02015SC-7113	HEX.SOCKET BOLT(M4*L10)	8
B2021	02028SW-9115	SPRING WASHER (@4)	8
B2022	05009SW-1111	WASHER (@4-L)	8
B2023	16052AD-UK01	TABLE SUPPORT GUIDE	4
B2024	17062SC-UK01	TABLE SUPPORT STOPPER SCREW	4
B2025	GP-008798-00	TABLE SUPPORT BAR GUIDE	4
B2026	17063SC-UK01	TABLE SUPPORT STOPPER SCREW	4
B2027	16061PR-UK01	TABLE SUPPORT PLATE (A)	4
B2028	16058AD-UK01	TABLE SUPPORT PLATE (B)	4
B2029	15089SC-7119	C.S SCREW (M4*L10)	8
B2030	17012SC-8329	HEX. SOCKET SET SCREW(M4*L16)	8
B2031	05000900UH60	TABLE SUPPORT A	4
B2032	GP-009964-00	TABLE SUPPORT B(L=317.5)	9
B2033	GP-008797-00	TABLE SUPPORT C	2
B2034	05001200UH60	TABLE SUPPORT D	4
B2035	05001300UH60	TABLE SUPPORT E	2
B2036	05010400U000	TABLE SUPPORTER (B2) L=402	2
B2037	05010200U000	TABLE SUPPORTER (A2)L=402	2
B2038	16009SC-8330	TAPPING SCREW (M6*L20)	12
B2039	05001500UK40	ANGLE SUPPORT	8
B2040	08076SC-7113	HEX. SOCKET BOLT (M5*L12)	16
B2041	18048SW-3115	SPRING WASHER (@5)	16
B2042	16018SW-1111	WASHER (@5)	16
B2043	16063PM-UK01	TABLE HOLDING BLOCK	7
B2044	16009SC-8330	TAPPING SCREW (M6*L20)	14

Ref. No	Part No.	Part Names	Q'ty
B2045	16067ET-UK01	TABLE TOGGLE CLAMP	8
B2046	19002SC-1330	TAPPING SCREW (4*L16-NO1)	32
B2047	16065PR-UK01	CLAMP PLATE	4
B2048	16009SC-8330	TAPPING SCREW (M6*L20)	12
B2049	16009SC-8330	TAPPING SCREW (M6*L20)	54
B2050	14002SC-7113	HEX.SOCKET BOLT (M6*L15)	54
B2051	16020PR-UK01	FRONT TABLE SUPPORT (L)	1
B2052	16025PR-UK01	FRONT TABLE SUPPORT (R)	1
B2053	08076SC-7113	HEX. SOCKET BOLT (M5*L12)	4
B2054	18048SW-3115	SPRING WASHER (@5)	4
B2055	16018SW-1111	WASHER (@5)	4
B2056	16009SC-8330	TAPPING SCREW (M6*L20)	4
B2057	05002000UH60	MOVING TABLE FIXED PLATE A	4
B2058	08062SC-7113	HEX. SOCKET BOLT (M5*L20)	16
B2059	18048SW-3115	SPRING WASHER (@5)	16
B2060	16018SW-1111	WASHER (@5)	16
B2061	17085PM-UK01	POSITIONING BLOCK	8
B2062	02015SC-7113	HEX.SOCKET BOLT(M4*L10)	16
B2063	GP-004133-00	MOVING TABLE FIXED PLATE B	4
B2064	05008100UK40	TABLE FIXING BLOCK	10
B2065	05014SC-7113	HEX. SOCKET BOLT (M4*L25)	20
B2066	17073PR-UK01	TABLE SUPPORT ANGLE "F"	3
B2067	08076SC-7113	HEX. SOCKET BOLT (M5*L12)	6
B2068	18048SW-3115	SPRING WASHER (@5)	6
B2069	16018SW-1111	WASHER (@5)	6
B2070	05014SC-7113	HEX. SOCKET BOLT (M4*L25)	6
B2071	GP-003757-00	Table Support End Cap(L)	44
B2072	02030SC-T121	Bed Cover Screw(9/64" 40)	6
B2073	16016PR-UK01	Gear Cover	3
B2074	05001700U000	Table Support Plate	10
B2075	18015SW-3111	WASHER(4@)	14
B2076	GP-004898-01	FIXED TABLE "C"	1
B2077	GP-008800-00	Tsble Rear Support(R)	1
B2078	GP-008799-00	Tsble Rear Support(L)	1
B2079	08076SC-7113	HEX. SOCKET BOLT (M5*L12)	4
B2080	18048SW-3115	SPRING WASHER (@5)	4
B2081	16018SW-1111	WASHER (@5)	4
B2082	16009SC-8330	TAPPING SCREW (M6*L20)	4
B2083	GP-003757-00	Y-LM Guide Cover D	1
B2084	GP-009964-00	TABLE SUPPORT B(L=317.5)	9

B3

Work Table (UH1208D)




Ref.No	Part No.	Part Names	Q'ty
B3001	GP-004116-00	MOVABLE TABLE "A"	2
B3002	GP-004117-02	MOVABLE TABLE "B"	2
B3003	GP-004118-00	MOVABLE TABLE "C"	2
B3004	GP-004119-01	FIXED TABLE "A"	1
B3005	GP-008894-00	FIXED TABLE "B"	1
B3006	GP-004120-01	FIXED TABLE "C"	1
B3007	GP-004121-01	FIXED TABLE "D"	1
B3011	GP-008895-01	FIXED TABLE "H"	1
B3012	GP-008900-00	FIXED TABLE "I"	1
B3015	GP-008797-00	TABLE SUPPORT C(197.5)	17
B3018	16009SC-4113	HEX.SOCKET BOLT(M10*L25)	54
B3019	16029SW-4115	SPRING WASHER (10@)	54
B3020	16009SC-8330	TAPPING SCREW (M6*L20)	74
B3021	16018PR-UK01	MES CAM DRIVING BOX COVER	2
B3022	02030SC-T121	BED COVER SCREW(9/64" 40)	8
B3023	05001400UH60	THREAD CUTTING BOX COVER B	1
B3024	02030SC-T121	BED COVER SCREW(9/64" 40)	4
B3025	GP-004127-00	Y-LM Guide Cover A	1
B3026	08101SC-8329	TAPPING SCREW (M3*L16)	10
B3029	GP-004129-00	Y-LM Guide Cover C	1
B3030	08101SC-8329	TAPPING SCREW (M3*L16)	11
B3031	GP-004130-00	Y-LM Guide Cover D	1
B3032	08101SC-8329	TAPPING SCREW (M3*L16)	11
B3033	GP-004131-00	Y-LM Guide Cover E	1
B3034	08101SC-8329	TAPPING SCREW (M3*L16)	10
B3036	GP-004132-00	COUPLING COVER	2
B3040	05002000UH60	MOVING TABLE FIXED PLATE A	4
B3041	GP-004133-00	MOVING TABLE FIXED PLATE B	4
B3042	08062SC-4113	HEX. SOCKET BOLT (M5*L20)	8
B3043	16019SW-4115	SPRING WASHER (@5)	8
B3044	16018SW-1111	WASHER (@5)	8
B3045	05001500UK40	ANGLE SUPPORT	8
B3046	08076SC-4113	HEX. SOCKET BOLT (M5*L12)	16
B3047	16019SW-4115	SPRING WASHER (@5)	16
B3048	16018SW-1111	WASHER (@5)	16
B3049	05010400U000	TABLE SUPPORTER (B2) L=402	2
B3050	05010200U000	TABLE SUPPORTER (A2) L=402	2
B3051	08076SC-4113	HEX. SOCKET BOLT (M5*L12)	16
B3052	16019SW-4115	SPRING WASHER (@5)	16
B3053	16018SW-1111	WASHER (@5)	16

Ref. No	Part No.	Part Names	Q'ty
B3055	05002400UH60	OP Holder Support Cover (A)	1
B3056	05002500UH60	OP Holder Support Cover (B)	1
B3057	08101SC-8329	TAPPING SCREW (M3*L16)	4
B3058	GP-008897-00	TABLE SUPPORT BAR GUIDE(L=594.5)	4
B3059	02015SC-7113	Hex.Socket Bolt(M4*L10)	8
B3060	02028SW-9115	Spring Washer (@4)	8
B3061	05009SW-1111	Washer (@4-L)	8
B3062	17062SC-UK01	Table Support Stopper Screw	4
B3063	05001300U000	TABLE SUPPORT L=263	6
B3064	16061PR-UK01	TABLE SUPPORT PLATE (A)	4
B3065	17012SC-8329	Hex. Socket Set Screw(M4*L16)	8
B3066	16058AD-UK01	TABLE SUPPORT PLATE (B)	4
B3067	15089SC-7119	C.S Screw (M4*L12)	8
B3068	17063SC-UK01	Table Support Stopper Screw	4
B3069	16065PR-UK01	CLAMP PLATE	4
B3070	16009SC-8330	Tapping Screw (M6*L20)	12
B3071	16067ET-UK01	TABLE TOGGLE CLAMP	12
B3072	16009SC-8330	Tapping Screw (M6*L20)	48
B3073	16016PR-UK01	GEAR COVER	3
B3074	02030SC-T121	BED COVER SCREW(9/64" 40)	6
B3075	05008100UK40	TABLE FIXING BLOCK	10
B3076	04030MC-7113	HEX.SOCKET BOLT (M4*L30)	20
B3077	18015SW-3111	WASHER (4@)	20
B3078	17085PM-UK01	POSITIONING BLOCK	8
B3079	02015SC-4113	HEX.SOCKET BOLT(M4*L10)	16
B3080	16063PM-UK01	TABLE HOLDING BLOCK	4
B3081	16009SC-8330	TAPPING SCREW (M6*L20)	8
B3082	16020PR-UK01	FRONT TABLE SUPPORT (L)	1
B3083	03016SC-4113	CAP FRAME SET SCREW	2
B3084	16019SW-4115	SPRING WASHER (@5)	2
B3085	16018SW-1111	WASHER (@5)	2
B3086	16009SC-8330	TAPPING SCREW (M6*L20)	2
B3087	16025PR-UK01	FRONT TABLE SUPPORT (R)	1
B3088	03016SC-4113	CAP FRAME SET SCREW	2
B3089	16019SW-4115	SPRING WASHER (@5)	2
B3090	16018SW-1111	WASHER (@5)	2
B3091	16009SC-8330	TAPPING SCREW (M6*L20)	2
B3092	17073PR-UK01	Table Support Angle "F"	4
B3093	08076SC-7113	Hex. Socket Bolt (M5*L12)	2
B3094	18048SW-3115	Spring Washer (@5)	12


B3

Work Table (UH1208D)



B4

Work Table (UH1512D)




Ref.No	Part No.	Part Names	Q'ty
B4001	GP-005174-00	MOVABLE TABLE "A"	2
B4002	GP-005175-00	MOVABLE TABLE "B"	2
B4003	GP-005176-00	MOVABLE TABLE "C"	2
B4004	GP-005177-00	MOVABLE TABLE "D"	2
B4005	GP-004119-00	FIXED TABLE "A"	1
B4006	05000200NH60	FIXED TABLE "B"	1
B4007	GP-005058-01	FIXED TABLE "C"	2
B4008	GP-005059-00	FIXED TABLE "D"	2
B4009	GP-004121-00	FIXED TABLE "E"	1
B4010	GP-004122-00	FIXED TABLE "F"	1
B4011	05000700NH60	FIXED TABLE "G"	1
B4012	GP-004123-00	FIXED TABLE "H"	1
B4013	GP-004124-00	FIXED TABLE "I"	1
B4014	GP-004125-00	FIXED TABLE "J"	1
B4023	16018PR-UK01	MES CAM DRIVING BOX COVER	2
B4024	02030SC-T121	BED COVER SCREW(9/64" 40)	8
B4025	05001400UH60	THREAD CUTTING BOX COVER B	1
B4026	02030SC-T121	BED COVER SCREW(9/64" 40)	4
B4027	GP-004127-00	Y-LM Guide Cover A	1
B4028	08101SC-8329	TAPPING SCREW (M3*L16)	10
B4029	GP-004128-00	Y-LM Guide Cover B	4
B4030	08101SC-8329	TAPPING SCREW (M3*L16)	64
B4031	GP-004129-00	Y-LM Guide Cover C	1
B4032	08101SC-8329	TAPPING SCREW (M3*L16)	11
B4033	GP-004130-00	Y-LM Guide Cover D	1
B4034	08101SC-8329	TAPPING SCREW (M3*L16)	11
B4035	GP-004131-00	Y-LM Guide Cover E	1
B4036	08101SC-8329	TAPPING SCREW (M3*L16)	10
B4037	05001800UH60	COUPLING COVER A	2
B4038	GP-004132-00	COUPLING COVER B	1
B4039	05000120UH80	Y-MOTOR COUPLING COVER R	2
B4040	05000110UH80	Y-MOTOR COUPLING COVER L	2
B4041	08101SC-8329	TAPPING SCREW (M3*L16)	16
B4042	05002000UH60	MOVING TABLE FIXED PLATE A	4
B4043	GP-004133-00	MOVING TABLE FIXED PLATE B	4
B4044	08062SC-4113	HEX. SOCKET BOLT (M5*L20)	8
B4045	16019SW-4115	SPRING WASHER (@5)	8
B4046	16018SW-1111	WASHER (@5)	8
B4047	05001500UK40	ANGLE SUPPORT	8
B4048	08076SC-4113	HEX. SOCKET BOLT (M5*L12)	16

Ref. No	Part No.	Part Names	Q'ty
B4049	16019SW-4115	SPRING WASHER (@5)	16
B4050	16018SW-1111	WASHER (@5)	16
B4051	05010400U000	TABLE SUPPORTER (B2) L=402	2
B4052	05010200U000	TABLE SUPPORTER (A2) L=402	2
B4053	08076SC-4113	HEX. SOCKET BOLT (M5*L12)	16
B4054	16019SW-4115	SPRING WASHER (@5)	16
B4055	16018SW-1111	WASHER (@5)	16
B4057	05002400UH60	OP Holder Support Cover (A)	1
B4058	05002500UH60	OP Holder Support Cover (B)	1
B4059	08101SC-8329	TAPPING SCREW (M3*L16)	4
B4060	GP-008897-00	TABLE SUPPORT GUIDE	4
B4061	02015SC-7113	Hex.Socket Bolt(M4*L10)	8
B4062	02028SW-9115	Spring Washer (@4)	8
B4063	05009SW-1111	Washer (@4-L)	8
B4064	17062SC-UK01	Table Support Stopper Screw	4
B4065	05001300U000	TABLE SUPPORT L=263	4
B4066	16061PR-UK01	TABLE SUPPORT PLATE (A)	4
B4067	17012SC-8329	Hex. Socket Set Screw(M4*L16)	8
B4068	16058AD-UK01	TABLE SUPPORT PLATE (B)	4
B4069	15089SC-7119	C.S Screw (M4*L12)	8
B4070	17063SC-UK01	Table Support Stopper Screw	4
B4071	16065PR-UK01	CLAMP PLATE	4
B4072	16009SC-8330	Tapping Screw (M6*L20)	12
B4073	16067ET-UK01	TABLE TOGGLE CLAMP	12
B4074	16009SC-8330	Tapping Screw (M6*L20)	48
B4075	16016PR-UK01	GEAR COVER	3
B4076	02030SC-T121	BED COVER SCREW(9/64" 40)	6
B4077	05008100UK40	TABLE FIXING BLOCK	10
B4078	04030MC-7113	HEX.SOCKET BOLT (M4*L30)	20
B4079	18015SW-3111	WASHER (4@)	20
B4080	17085PM-UK01	POSITIONING BLOCK	8
B4081	02015SC-4113	HEX.SOCKET BOLT(M4*L10)	16
B4082	16063PM-UK01	TABLE HOLDING BLOCK	4
B4083	16009SC-8330	TAPPING SCREW (M6*L20)	8
B4084	16020PR-UK01	FRONT TABLE SUPPORT (L)	1
B4085	03016SC-4113	CAP FRAME SET SCREW	2
B4086	16019SW-4115	SPRING WASHER (@5)	2
B4087	16018SW-1111	WASHER (@5)	2
B4088	16009SC-8330	TAPPING SCREW (M6*L20)	2
B4089	16025PR-UK01	FRONT TABLE SUPPORT (R)	1


B4

Work Table (UH1512D)




C

Spool Stand



D1

Main Drive System I




Ref.No	Part No.	Part Names	Q'ty
D1001	SFAM-600-300	MAIN MOTOR	1
D1002	15030SC-7113	HEX. SOCKET BOLT (M5*L30)	4
D1003	18048SW-3115	SPRING WASHER (5@)	4
D1004	18049SW-3111	WASHER (@5)	4
D1005	GP-012897-00	MOTOR FIXING	1
D1006	14046SC-7113	HEX.SOCKET BOLT (M6*L30)	4
D1007	03026SW-9115	SPRING WASHER (@6)	4
D1008	08057SW-1111	WASHER (@6)	4
D1009	03010800UH80	MAIN MOTOR PULLEY	1
D1010	04014SC-4517	HEX.SOCKET SET SCREW(M5*L5)	2
D1011	03100700UH80	MAIN DRIVING BELT 200J	1
D1012	03101300UH80	UPPER SHAFT SUPPORT BRACKET(L)	1
D1013	16009SC-4113	HEX.SOCKET BOLT(M10*L25)	2
D1014	01008SW-9115	SPRING WASHER(@10)	2
D1015	01007SW-1111	WASHER(@10)	2
D1016	08091SC-7113	HEX. SOCKET BOLT (M6*L20)	2
D1017	03026SW-9115	SPRING WASHER (@6)	2
D1018	08057SW-1111	WASHER (@6)	2
D1019	03010SR-4013	C-RING (@47)	2
D1020	03101400U000	UPPER SHAFT SUPPORT COVER	2
D1021	05007SC-7113	HEX. SOCKET BOLT (M3*L5)	6
D1022	01001100H000	BALL BEARING(6005ZZ)	2
D1023	03005210H000	COLLAR "A"	2
D1024	14060AF-4517	HEX.SOCKET SCREW(M6*L6)	2
D1025	03000120U000	TOP SHAFT TIMMING PULLEY	1
D1026	14060AF-4517	HEX.SOCKET SCREW(M6*L6)	4
D1027	13032GA-UK06	INDEX SHAFT GEAR UK06	1
D1028	04012AF-A001	HOOK SHAFT BUSH SCREW (15/64)	2
D1029	04027BR-A001	NEEDLE BEARING (HMK1515)	1
D1030	03704900A000	CAM SHAFT COLLAR	2
D1031	04016AF-A001	CAM COLLAR SCREW	4
D1032	13041SH-UK01	MIDDLE SHAFT	1
D1033	13034GA-UK06	MIDDLE SHAFT GEAR UK06	1
	13036BR-UK01	MIDDLE SHAFT GEAR NEEDLE BEARING(@10-@19)NNB	4
D1034	12019BR-T121	FIBER WASHER R-TW1020	4
D1035	13038CW-UK01	COLLAR	2
D1036	03022SC-4517	HEX. SOCKET SET SCREW(M4*L5)	4
D1037	08053PR-A001	LEVER WASHER	4
D1038	02023SC-7113	HEX.SOCKET BOLT(M4*L8)	2
D1039	18014SW-3115	SPRING WASHER (@4-NO2)	2

Ref. No	Part No.	Part Names	Q'ty
D1040	18015SW-3111	WASHER (4@)	2
D1041	13032GA-UK06	INDEX SHAFT GEAR UK06	1
D1042	04012AF-A001	HOOK SHAFT BUSH SCREW (15/64)	2
D1043	04026BR-A001	BALL BEARING 6003Z	1
D1044	01102000B000	COLLAR"B"	1
D1045	04016AF-A001	CAM COLLAR SCREW	2
D1046	04039PR-A001	BEARING COVER	1
D1047	13061SC-8119	PLUS SCREW (M3*L10)	3
D1048	03012000U000	LOW SHAFT SUPPORT BRACKET(L)	1
D1049	01029BR-A001	BALL BEARING 6004Z	2
D1050	08091SC-7113	HEX. SOCKET BOLT (M6*L20)	4
D1051	03026SW-9115	SPRING WASHER (@6)	4
D1052	08057SW-1111	WASHER (@6)	4
D1053	14058CW-A001	COLLAR "A"	1
D1054	14060AF-4517	HEX.SOCKET SCREW(M6*L6)	2
D1055	03000130U000	INDEX TIMMING PULLEY	1
D1056	14061AF-4517	HEX.SOCKET SCREW(M8*L8)	4
D1057	13053PR-UK01	ANGLE PLATE BASE	1
D1058	13061SC-8119	PLUS SCREW (M3*L10)	3
D1059	14006SC-7113	HEX.SOCKET SET SCREW(M8*L15)	1
D1060	15095SW-3115	SPRING WAHSER(@8)	1
D1061	04029SW-A001	STUD BOLT WASHER(S) (@8)	1
D1062	13054ET-UK01	ANGLE DISK(L)	1
D1063	03012200U000	INDICATOR	1
D1064	02015SC-7113	HEX.SOCKET BOLT(M4*L8)	2
D1065	18014SW-3115	SPRING WASHER (@4-NO2)	2
D1066	18015SW-3111	WASHER (4@)	2
D1067	03000300U000	IDLER	1
	13026BR-T121	NEEDLE BEARING (6002Z)	2
D1068	13120CW-UK01	IDLER SHAFT	1
D1069	13106PR-UK01	IDLER SPACER	1
D1070	14060AF-4517	HEX.SOCKET SCREW(M6*L6)	2
D1071	13107CW-UK01	COLLAR	1
D1072	14060AF-4517	HEX.SOCKET SCREW(M6*L6)	2
D1073	08027BR-A001	THRUST BEARING (NTB 1528)	2
D1074	08028BR-A001	THRUST WASHER (AS 1528)	4
D1075	03010800UH00	TOP SHAFT PULLEY	1
D1076	14060AF-4517	HEX.SOCKET SCREW(M6*L6)	4
D1077	03000900U000	TENSION ADJUSTING BLOCK	1
D1078	08062SC-7113	HEX. SOCKET BOLT (M5*L20)	2


D1

Main Drive System I



D2

Main Drive System II




Ref.No	Part No.	Part Names	Q'ty
D2001	SFAM-600-300	MAIN MOTOR	1
D2002	15030SC-7113	HEX. SOCKET BOLT (M5*L30)	4
D2003	18048SW-3115	SPRING WASHER (5@)	4
D2004	18049SW-3111	WASHER (@5)	4
D2005	GP-012897-00	MOTOR FIXING	1
D2006	14046SC-7113	HEX.SOCKET BOLT (M6*L30)	4
D2007	03026SW-9115	SPRING WASHER (@6)	4
D2008	08057SW-1111	WASHER (@6)	4
D2009	03010800UH80	MAIN MOTOR PULLEY	1
D2010	04014SC-4517	HEX.SOCKET SET SCREW(M5*L5)	2
D2011	03100700UH80	MAIN DRIVING BELT 200J	1
D2012	03101400UH80	UPPER SHAFT SUPPORT BRACKET (R)	1
D2013	16009SC-4113	HEX.SOCKET BOLT(M10*L25)	2
D2014	01008SW-9115	SPRING WASHER(@10)	2
D2015	01007SW-1111	WASHER(@10)	2
D2016	08091SC-7113	HEX. SOCKET BOLT (M6*L20)	2
D2017	03026SW-9115	SPRING WASHER (@6)	2
D2018	08057SW-1111	WASHER (@6)	2
D2019	03010SR-4013	C-RING (@47)	2
D2020	03101400U000	UPPER SHAFT SUPPORT COVER	2
D2021	05007SC-7113	HEX. SOCKET BOLT (M3*L5)	6
D2022	01001100H000	BALL BEARING(6005ZZ)	2
D2023	03005210H000	COLLAR "A"	2
D2024	14060AF-4517	HEX.SOCKET SCREW(M6*L6)	2
D2025	03000120U000	TOP SHAFT TIMMING PULLEY	1
D2026	14060AF-4517	HEX.SOCKET SCREW(M6*L6)	4
D2027	13032GA-UK06	INDEX SHAFT GEAR UK06	1
D2028	04012AF-A001	HOOK SHAFT BUSH SCREW (15/64)	2
D2029	04027BR-A001	NEEDLE BEARING (HMK1515)	1
D2030	03704900A000	CAM SHAFT COLLAR	2
D2031	04016AF-A001	CAM COLLAR SCREW	4
D2032	13041SH-UK01	MIDDLE SHAFT	1
D2033	13034GA-UK06	MIDDLE SHAFT GEAR UK06	1
	13036BR-UK01	MIDDLE SHAFT GEAR NEEDLE BEARING(@10-@19)NNB	4
D2034	12019BR-T121	FIBER WASHER R-TW1020	4
D2035	13038CW-UK01	COLLAR	2
D2036	03022SC-4517	HEX. SOCKET SET SCREW(M4*L5)	4
D2037	08053PR-A001	LEVER WASHER	4
D2038	02023SC-7113	HEX.SOCKET BOLT (M4*L8)	2
D2039	18014SW-3115	SPRING WASHER (@4-NO2)	2

Ref. No	Part No.	Part Names	Q'ty
D2040	18015SW-3111	WASHER (4@)	2
D2041	13032GA-UK06	INDEX SHAFT GEAR UK06	1
D2042	04012AF-A001	HOOK SHAFT BUSH SCREW (15/64)	2
D2043	04026BR-A001	BALL BEARING 6003Z	1
D2044	01102000B000	COLLAR"B"	1
D2045	14060AF-4517	HEX.SOCKET SCREW(M6*L6)	2
D2046	04039PR-A001	BEARING COVER	1
D2047	13061SC-8119	PLUS SCREW (M3*L10)	3
D2048	03012000UH60	LOW SHAFT SUPPORT BRACKET (R)	1
D2049	01029BR-A001	BALL BEARING 6004Z	2
D2050	08091SC-7113	HEX. SOCKET BOLT (M6*L20)	4
D2051	03026SW-9115	SPRING WASHER (@6)	4
D2052	08057SW-1111	WASHER (@6)	4
D2053	14058CW-A001	COLLAR "A"	1
D2054	14060AF-4517	HEX.SOCKET SCREW(M6*L6)	2
D2055	03000130U000	INDEX TIMMING PULLEY	1
D2056	14061AF-4517	HEX.SOCKET SCREW(M8*L8)	4
D2057	13053PR-UK01	ANGLE PLATE BASE	1
D2058	13061SC-8119	PLUS SCREW (M3*L10)	3
D2059	14006SC-7113	HEX.SOCKET SET SCREW(M8*L15)	1
D2060	15095SW-3115	SPRING WAHSER(@8)	1
D2061	04029SW-A001	STUD BOLT WASHER(S) (@8)	1
D2062	03100100U000	ANGLE DISK (R)	1
D2063	03012200U000	INDICATOR	1
D2064	02015SC-7113	HEX.SOCKET BOLT(M4*L8)	2
D2065	18014SW-3115	SPRING WASHER (@4-NO2)	2
D2066	18015SW-3111	WASHER (4@)	2
D2067	03000300U000	IDLER	1
	13026BR-T121	NEEDLE BEARING (6002Z)	2
D2068	13120CW-UK01	IDLER SHAFT	1
D2069	13106PR-UK01	IDLER SPACER	1
D2070	14060AF-4517	HEX.SOCKET SCREW(M6*L6)	2
D2071	13107CW-UK01	COLLAR	1
D2072	14060AF-4517	HEX.SOCKET SCREW(M6*L6)	2
D2073	08027BR-A001	THRUST BEARING (NTB 1528)	2
D2074	08028BR-A001	THRUST WASHER (AS 1528)	4
D2075	03010800UH00	TOP SHAFT PULLEY	1
D2076	14060AF-4517	HEX.SOCKET SCREW(M6*L6)	4
D2077	03000900U000	TENSION ADJUSTING BLOCK	1
D2078	08062SC-7113	HEX. SOCKET BOLT (M5*L20)	2


D2

Main Drive System II




E1

Bed I




[illegible]



E3


Bed III (UH1208D,UH1512D)



[illegible]


F

Thread Cutting Drive System



G1

Arm I




Ref.No	Part No.	Part Name	Q'ty
G1001	03300020U000	Arm	6
G1002	03003SC-4113	Hex. Socket Bolt	18
G1003	15095SW-3115	Spring Washer (@8)	18
G1004	04029SW-A001	Stud Bolt Washer(S) (@8)	18
G1005	GP-005992-00	Cam Base	6
G1006	03007SC-A001	Cam Base Screw	18
G1007	03300210H000	Needle Cage	6
G1008	03303000H000	Connecting Rod	6
G1009	GP-005990-00	NEEDLE BAR DRIVING CAM	6
G1010	03303100H000	Bearing Case A @20	6
G1011	01001100H000	Ball Bearing (6005Zz)	6
G1012	02031SC-7113	Hex. Socket Screw(M5*L10)	6
G1013	02030SW-B001	Washer (5@)	36
G1014	03000110H000	Cam Tightening Collar (@20)	6
G1015	03016SC-4113	Hex. Socket Bolt (M5*L15)	6
G1016	03313200H000	NEEDLE BAR DRIVE LEVER	6
G1017	03303200H000	NEEDLE BAR DRIVING LEVER	6
G1018	03307200A000	Needle Driving Lever Bushing	6
G1019	03307300A000	Needle Driving Lever Bushing	6
G1020	32003ET-T121	Wick	6
G1021	03301800U000	NEEDLE BAR DRIVE PIN	6
G1022	32003ET-T121	Wick	6
G1023	01301600H000	Hook Oil Supply Nipple	12
G1024	03020SC-A001	Drive Pin Screw 11/64-N40-L8	6
G1025	01101300A000	Hook Shaft Collar	12
G1026	04012AF-A001	Hook Shaft Bush Screw	6
G1027	03023SC-A001	Connecting Rod Stud	6
G1028	32003ET-T121	Wick	6
G1029	03025SW-1211	Washer (@6)	6
G1030	03026SW-9115	Spring Washer (@6)	6
G1031	03027SN-A001	Stud Nut	6
G1032	03303300H000	Lever Pin	6
G1033	32003ET-T121	Wick	6
G1034	02015SC-7113	Screw(M4*L10)	6
G1035	03003200A000	Needle Bar Drive Rink	6
G1036	03034SW-A001	Reciprocator Washer	6
G1037	03600100I000	Needle Bar Driving Shaft Driver	6
G1038	03047PM-CT01	Stopper-A'ssy	6
G1039	26006MC-8118	Stopper Screw (M2.6*L6)	12
G1040	03600000I000	Needle Bar Reciprocator A'ssy	6

Ref. No	Part No.	Part Name	Q'ty
G1041	03600200I000	Needle Bar Reciprocator	6
G1042	03045SP-B001	Jump Spring	6
G1043	03046CW-B001	Jump Spring Guide	6
G1044	03048SW-A001	Reciprocator Washer	6
G1045	03304710A000	NEEDLE BAR DRIVING SHAFT BUSH	6
G1046	09005SC-3123	Truss Screw (M3*L6)	6
G1047	03033CW-A001	Driver Pin	6
G1048	32003ET-T121	Wick	6
G1049	03020SC-A001	Drive Pin Screw 11/64-N40-L8	6
G1050	03007900H000	Needle Bar Driving Shaft	6
G1051	32003ET-T121	Wick	6
G1052	03020SC-A001	Drive Pin Screw 11/64-N40-L8	6
G1053	03008000H000	Ball Bearing 6800	6
G1054	03008100K000	Needle Bar Drive Bearing Bush	6
G1056	03302600I000	Arm Bearing Guide Plate	6
G1057	05062SC-A001	Bolt (9/64" n=40)	12
G1058	03056CL-B001	Head Rail Holder	6
G1059	03057SC-A001	Head Rail Holder Screw	6
G1060	GP-014102-01	PRESSER FOOT DRIVING CAM	6
G1061	03301000I000	Csm Spacer	6
G1062	SC-000284-00	SCREW FOR DRIVING LEVER	18
G1063	WS-000082-00	PRESSER FOOT DRIVING CAMWASHER	18
G1064	GP-005993-00	Presser Foot Driving Lever (A) Assy'	6
G1065	AS-002151-00	Presser Foot Driving Roller Hinge Pin Assy'	6
G1066	15029SN-3211	Nut (@4)	6
G1067	18015SW-3111	Washer (@4)	6
G1068	03800300I000	Presser Foot Driving Lever Pin (C)	6
G1069	03031SN-A001	Nut (11/64" n=40)	6
G1070	18048SW-3115	Washer	6
G1071	PN-000165-00	Presser Foot Driving Lever Pin (A)	6
G1072	14060AF-4517	Hex. Socket Bolt (M6*L6)	6
G1073	02004BR-T121	Hook Shaft Bearing Washer	6
G1074	03800500I000	Presser Foot Driving Lever Bracket (A)	6
G1075	09007SC-7113	Hex. Socket Bolt (M3*L12)	18
G1076	11019SW-9115	Washer (@3)	18
G1077	03800600I000	Presser Foot Drving Lever Connecting Link	6
G1078	03034SW-A001	Washer	12
G1079	GP-006079-00	Presser Foot Driving Lever (B) Assy'	6
G1081	15029SN-3211	Nut (@4)	6
G1082	18015SW-3111	Washer (@4)	6


G1

Arm I




G2

Arm II




G3


Arm III



H


Color Change Set






Ref.No	Part No.	Part Names	Q'ty
I1001	03500110H000	Upper Thread Catcher Base	3
I1002	03500210H000	Upper Thread Hook Base Cover	3
I1003	03005MC-3123	Plus Screw (M3*L5)	18
I1004	03500500H000	Upper Catcher Driving Lever	3
I1005	03500600H000	Driving Lever Pin	3
I1006	03500700H000	Driving Lever Pin Collar	3
I1007	04014SC-4517	Hex.Socket Set Screw(M5*L5)	6
I1008	03500800H000	Driving Lever Pin Washer	9
I1009	03500900H000	Clutch Block	3
I1010	03501000H000	Clutch Stud Screw	3
I1011	03501100H000	Clutch Spring	3
I1012	03501200H000	Clutch Dial	3
I1013	11029SC-4113	Hex. Socket Bolt (M4*L20)	6
I1014	03002700H000	Return Spring	3
I1015	03002800H000	Return Spring Stopper Washer	3
I1016	03002900H000	Return Spring Fix Pin Washer	3
I1017	03003000H000	Return Spring Fix Pin	3
I1018	02015SC-7113	Hex.Socket Bolt(M4*L10)	3
I1019	03003100H000	Upper Thread Hook Motor Unit	1
I1020	03003210H000	Motor Base	1
I1021	06025MC-7113	Hex.Socket Bolt(M6*L25)	4
I1022	16014SW-4115	Spring Washer (@6)	4
I1023	08057SW-1111	Washer (@6)	4
I1024	03003300H000	Cam Shaft Fixing Block	4
I1025	05008MC-4517	Hex.Socket Bolt(M5*L8)	2
I1026	GP-005184-01	SENSOR SENSING ADJUSTING RING	1
I1027	04014SC-4517	Hex.Socket Set Screw(M5*L5)	2
I1028	03003500H000	Motor Driving Cam Shaft	1
I1029	04014SC-4517	Hex.Socket Set Screw(M5*L5)	1
I1030	GP-005180-00	UPPER THREAD HOOK SENSOR BASE	1
I1031	07035SC-7113	Bracket Screw (M3*L6)	2
I1032	15-027A-2070	SENSOR	1
I1035	03003910H000	Upper Thread Driving Plate	1
I1036	03004000H000	Stud Bolt Washer	1
I1037	03004200HE00	Motor Driving Connect Plate	1
I1038	03004400H000	Motor Driving Connect Bearing	2
I1039	03008300H000	Connecting Plate Stud Screw A	1
I1040	03004500H000	Connecting Plate Pin Washer	1
I1041	03004700H000	Connecting Plate Stud Screw	1
I1042	13042SN-1111	Hex.Nut (M6*T5-R)	1

Ref. No	Part No.	Part Names	Q'ty
I1043	03004800H000	Connecting Plate Knuckle	1
I1044	04032SN-A001	Hex. Nut (M8-No2)	1
I1045	02023SC-7113	Hex.Socket Bolt (M4*L8)	6
I1046	18015SW-3111	Washer (4@)	6
I1047	18014SW-3115	Spring Washer (@4-No2)	6
I1048	08600005B000	Upper Thread Presser Base Set	3
I1049	09030PR-A002	Upper Thread Presser Base 9C	3
	09026PR-AB00	Upper Thread Presser Base 12C	
	09052PR-T151	Upper Thread Presser Base 15C	
I1050	09031ET-A002	Velcro (9C)	3
	09027ET-AB00	Velcro (12C)	
	09027ET-T151	Velcro (15C)	
I1051	09033PR-A002	Presser Base Cover (9C)	3
	09029PR-AB00	Presser Base Cover (12C)	
	09029PR-T151	Presser Base Cover (15C)	
I1052	07018SC-8118	Plus Screw (M3*L8)	6
I1053	09038CW-A001	Thread Presser Space	6
I1054	09040PR-A001	Bracket (L)	3
I1055	09041PR-A001	Bracket (R)	3
I1056	06010SC-8118	Plus Screw (M3*L4)	6
I1057	02009SC-A001	Side Cover Screw	6
I1058	09044PR-A001	Upper Thread Holder Disk Set	6
I1059	GP-004937-00	Upper Thread Driving Shaft A(L=575)	1
	03007010UH60	Upper Thread Driving Shaft A(L=976)	
	GP-004156-00	Upper Thread Driving Shaft A (L=1372)	
	03007000UH60	Upper Thread Driving Shaft A(L=2175)	
I1060	12001900U060	Upper Thread Hook Motor Cover	1
I1061	02023SC-7113	Hex.Socket Bolt (M4*L16)	2
I1062	18014SW-3115	SPRING WASHER (4@)	2
I1063	18015SW-3111	Washer (4@)	2
I1064	03008600H000	Motor Cover Fixing Bracket	2
I1065	02023SC-7113	Hex.Socket Bolt (M4*L8)	2
I1066	18014SW-3115	Spring Washer (@4-No2)	2
I1067	18015SW-3111	Washer (4@)	2
I1068	03002610H000	Return Spring Stopper	6
I1069	05008SC-4113	Hex.Socket Bolt (M4*L16)	6
I1070	13061SC-8119	Plus Screw (M3*L10)	1
I1071	03003810H000	Stud Bolt For Driving Plate	1
I1072	03004110H000	DRIVING PLATE BLOCK B	2
I1073	18047SC-7113	HEX/ SOCKET BOLT (M5*L15)	2






Ref.No	Part No.	Part Names	Q'ty
I2001	03500110H000	Upper Thread Catcher Base	3
I2002	03500210H000	Upper Thread Hook Base Cover	3
I2003	03005MC-3123	Plus Screw (M3*L5)	18
I2004	03500500H000	Upper Catcher Driving Lever	3
I2005	03500600H000	Driving Lever Pin	3
I2006	03500700H000	Driving Lever Pin Collar	3
I2007	04014SC-4517	Hex.Socket Set Screw(M5*L5)	6
I2008	03500800H000	Driving Lever Pin Washer	9
I2009	03500900H000	Clutch Block	3
I2010	03501000H000	Clutch Stud Screw	3
I2011	03501100H000	Clutch Spring	3
I2012	03501200H000	Clutch Dial	3
I2013	11029SC-4113	Hex. Socket Bolt (M4*L20)	6
I2014	03002700H000	Return Spring	3
I2015	03002800H000	Return Spring Stopper Washer	3
I2016	03002900H000	Return Spring Fix Pin Washer	3
I2017	03003000H000	Return Spring Fix Pin	3
I2018	02015SC-7113	Hex.Socket Bolt(M4*L10)	3
I2019	03003100H000	Upper Thread Hook Motor Unit	1
I2020	03003210H000	Motor Base	1
I2021	06025MC-7113	Hex.Socket Bolt(M6*L25)	4
I2022	16014SW-4115	Spring Washer (@6)	4
I2023	08057SW-1111	Washer (@6)	4
I2024	03003300H000	Cam Shaft Fixing Block	4
I2025	05008MC-4517	Hex.Socket Bolt(M5*L8)	2
I2026	GP-005184-01	SENSOR SENSING ADJUSTING RING	2
I2027	04014SC-4517	Hex.Socket Set Screw(M5*L5)	2
I2028	03003500H000	Motor Driving Cam Shaft	1
I2029	04014SC-4517	Hex.Socket Set Screw(M5*L5)	1
I2030	GP-005180-00	UPPER THREAD HOOK SENSOR BASE	1
I2031	07035SC-7113	Bracket Screw (M3*L6)	2
I2032	15-027A-2070	SENSOR	1
I2035	03003910H000	Upper Thread Driving Plate	1
I2036	03004000H000	Stud Bolt Washer	1
I2037	03004200HE00	Motor Driving Connect Plate	1
I2038	03004400H000	Motor Driving Connect Bearing	2
I2039	03008300H000	Connecting Plate Stud Screw A	1
I2040	03004500H000	Connecting Plate Pin Washer	1
I2041	03004700H000	Connecting Plate Stud Screw	1
I2042	13042SN-1111	Hex.Nut (M6*T5-R)	1

Ref. No	Part No.	Part Names	Q'ty
I2043	03004800H000	Connecting Plate Knuckle	1
I2044	04032SN-A001	Hex. Nut (M8-No2)	1
I2045	02023SC-7113	Hex.Socket Bolt (M4*L8)	6
I2046	18015SW-3111	Washer (4@)	6
I2047	18014SW-3115	Spring Washer (@4-No2)	6
I2048	08600005B000	Upper Thread Presser Base Set	3
I2049	09030PR-A002	Upper Thread Presser Base 9C	3
	09026PR-AB00	Upper Thread Presser Base 12C	
	09052PR-T151	Upper Thread Presser Base 15C	
I2050	09031ET-A002	Velcro (9C)	3
	09027ET-AB00	Velcro (12C)	
	09027ET-T151	Velcro (15C)	
I2051	09033PR-A002	Presser Base Cover (9C)	3
	09029PR-AB00	Presser Base Cover (12C)	
	09029PR-T151	Presser Base Cover (15C)	
I2052	07018SC-8118	Plus Screw (M3*L8)	6
I2053	09038CW-A001	Thread Presser Space	6
I2054	09040PR-A001	Bracket (L)	3
I2055	09041PR-A001	Bracket (R)	3
I2056	06010SC-8118	Plus Screw (M3*L4)	6
I2057	02009SC-A001	Side Cover Screw	6
I2058	09044PR-A001	Upper Thread Holder Disk Set	6
I2059	GP-004938-00	Upper Thread Driving Shaft B(L=649)	1
	03007110UH60	Upper Thread Driving Shaft B(L=1094)	
	GP-004157-00	Upper Thread Driving Shaft B (L=1494)	
	GP-005076-00	Upper Thread Driving Shaft B(L=2295)	
I2060	12001900U060	Upper Thread Hook Motor Cover	1
I2061	02023SC-7113	Hex.Socket Bolt (M4*L16)	2
I2062	18014SW-3115	SPRING WASHER (4@)	2
I2063	18015SW-3111	Washer (4@)	2
I2064	03008600H000	Motor Cover Fixing Bracket	2
I2065	02023SC-7113	Hex.Socket Bolt (M4*L8)	2
I2066	18014SW-3115	Spring Washer (@4-No2)	2
I2067	18015SW-3111	Washer (4@)	2
I2068	03002610H000	Return Spring Stopper	6
I2069	05008SC-4113	Hex.Socket Bolt (M4*L16)	6
I2070	13061SC-8119	Plus Screw (M3*L10)	1
I2071	03003810H000	Stud Bolt For Driving Plate	1
I2072	03004110H000	DRIVING PLATE BLOCK B	2
I2073	18047SC-7113	HEX/ SOCKET BOLT (M5*L15)	2

J

Head




Ref.No	Part No.	Part Names	Q'ty
J - 001	GP - 007360 - 01	Head (9C)	6
	GP - 007361 - 01	Head (12C)	
	GP - 007362 - 01	Head (15C)	
J - 002	05008SC - 4113	Hex.Socket Bolt (M4*L16)	24
J - 003	06003SW - 2111	Washer (@4)	24
J - 004	08201303I000	Head Rail 9C	6
J - 005	04023MC - 4113	Hex. Socket Bolt (M4*L23)	24
J - 006	05015CW - A001	Head Base Pin(@5*L15)	12
J - 007	03022SC - 4517	Hex. Socket Set Screw(M4*L5)	12
J - 008	05018CW - A001	Needle Bar	54
J - 009	05019SC - A001	Needle Bar Cover Screw (M5*L6)	54
J - 010	08200700H000	Needle Bar Felt	36
J - 011	05023RB - A001	Needle Bar Cushion Rubber "A"	36
J - 012	05024RB - A001	Needle Bar Cushion Rubber "B"	54
J - 013	11101200T000	Upper Dead Point Stopper	54
J - 014	05026SC - 4113	Stopper Screw (9/64 - 11.5)	54
J - 015	08201400H000	Needle Bar Holder	54
J - 016	05028SC - 4113	Holder Screw (9/64 - L8)	54
J - 017	05021PM - H001	Presser Foot Spring Guide	108
J - 018	08201000I000	Needle Bar Return Spring	54
J - 019	08200500I000	PRESSER FOOT	54
	GP - 006119 - 00	PRESSER FOOT (L) (Option)	
J - 020	08200900I000	Presser Foot Holder A'ssy	54
J - 021	05026SC - H001	Presser Foot Bolt	54
J - 022	GP - 007216 - 00	Needle Bar Return Spring	54
J - 023	08201200H000	Presser Foot Cushion Rubber A	54
J - 024	08201600H000	NEEDLE FIXED HOLDER	54
J - 025	05363SC - A001	Needle Fixed Screw (A/S)	54
J - 026	05037DB - A001	Needle (Db- K5 - #11)	54
J - 027	GP - 008540 - 00	Needle Bar Guide Rail (9C)	6
	GP - 008541 - 00	Needle Bar Guide Rail (12C)	
	GP - 008542 - 00	Needle Bar Guide Rail (15C)	
J - 028	05041SC - A001	Bolt (9/64 n=40)	30
J - 029	10200103B000	Head Face Plate (U) 9C	6
J - 030	10200100H000	Thread Guide Bush "A - 1"	54
J - 031	10300003A000	Thread Guide (M) Set (9C)	6
	10300004A000	Thread Guide (M) Set (12C)	
	10300005A000	Thread Guide (M) Set (15C)	
J - 032	GP - 033547 - 00	Thread Guide (M) (9C)	6
	GP - 033548 - 00	Thread Guide (M) (12C)	
	GP - 033549 - 00	Thread Guide (M) (15C)	

Ref. No	Part No.	Part Names	Q'ty
J - 033	05452CM - A001	Eyelet "A"	54
J - 034	05483CM - A001	Eyelet "B" (9C)	36
	10110000A000	Eyelet "B" (12C)	54
	05483CM - A001	Eyelet "B" (15C)	72
J - 035	05062SC - A001	Thread Guide (M) Screw (9/64 n=40)	6
J - 036	05070SC - 3123	Head Face Plate (U) Screw	24
J - 037	12001703I000	Head Face Plate(L) (9C)	6
	12001704I000	Head Face Plate(L) (12C)	
J - 038	11012PR - B001	Thread Guide	54
J - 039	09005SC - 3123	Truss Bolt (M3*L5)	54
J - 040	10900003I000	Thread Holding Device A'ssy	6
J - 041	05070SC - 3123	Truss Bolt 9/64 n=40	12
J - 042	07005BM - B002	Take-Up Lever Set	54
J - 043	08200503A000	Take-Up Lever Shaft (9C)	6
J - 044	08203000A000	Take-Up Lever Shaft Bush(L)	6
J - 045	08200800A000	Take-Up Lever Shaft Bush(R)	6
J - 046	07009SC - 4517	Hex. Socket Bolt(M5*L6)	12
J - 047	02015SC - 7113	Hex.Socket Bolt(M4*L8)	24
J - 048	08004900A000	Color Change Bracket "B"	5
J - 049	11047PR - A002	Cable Support "B"	6
J - 050	02023SC - 7113	Hex.Socket Bolt(M4*L5)	12
J - 051	05022SW - A001	Spring Shoe Washer	54
J - 052	05070SC - 3123	Head Face Plate (U) Screw	12
J - 053	09000200H000	TOP SHAFT COVER BRACKET (L)	2
J - 054	08004700A000	Color Change Bracket "A"	2
J - 055	13048SC - A001	Bracket "A" Screw	4
J - 056	01001400UK00	Top Shaft Cover (L)	1
J - 057	02015SC - 7113	Hex.Socket Bolt(M4*L10)	2
J - 058	02023SC - 7113	Hex.Socket Bolt(M4*L8)	2
J - 059	18014SW - 3115	Spring Washer (@4 - NO2)	4
J - 060	18015SW - 3111	Washer (4@)	4
J - 061	02023ET - A001	Top Shaft Cover Magnet	12
J - 062	09000303UH00	Top Shaft Cover "A - 1" (9C)	1
	09000304UH00	Top Shaft Cover "A - 1" (12C)	
	09000305UH00	Top Shaft Cover "A - 1" (15C)	
J - 063	09000203UH60	Top Shaft Cover "A - 2" (9C)	1
	09000204UH60	Top Shaft Cover "A - 2" (12C)	
	09000205UH60	Top Shaft Cover "A - 2" (15C)	
	09000203UH00	Top Shaft Cover "A - 2" (9C)	
J - 064	09000203UH00	Top Shaft Cover "A - 3" (9C)	1
	09000204UH00	Top Shaft Cover "A - 3" (12C)	
	09000205UH00	Top Shaft Cover "A - 3" (15C)	


J

Head



K


Thread Tension Unit



[illegible]

L1

X Axis Drive System (UH1504D)




Ref.No	Part No.	PartNames	Q'ty
L1001	GP-004929-03	X-FRAME	2
L1002	GP-004918-00	X-Lm Guide (Sr15W,L1480)	2
L1003	22006SC-7113	Hex. Socket Bolt (M3*L8)	42
L1004	15034SC-4113	Hex. Socket Boit (M4*L45)	4
L1005	18015SW-3111	Washer (@4)	40
L1006	15062SF-T121	Felt	6
L1007	GP-005047-00	Tubular Frame Rail Plate	2
L1008	GP-004917-00	Connecting Plate(L)	2
L1009	22006SC-7113	Hex. Socket Bolt (M3*L8)	16
L1010	11019SW-9115	Spring Washer (3@)	32
L1011	08011SW-1111	Spring Washer (@3-S)	32
L1012	GP-004916-00	Connecting Plate(R)	2
L1013	15015PR-UK02	Connecting Plate	2
L1014	GP-004922-00	Lm Block Connecting Plate(L)	2
L1015	02023SC-7113	Hex. Socket Bolt (M4*L8)	36
L1016	02028SW-9115	Spring Washer (@4)	44
L1017	GP-004921-00	Lm Block Connecting Plate(R)	2
L1018	14020PR-UK01	Space	4
L1019	14048AD-UK01	Belt Bracket (A)	2
L1020	14045AD-UK01	Belt Bracket (B)	4
L1021	14049AD-UK01	Belt Bracket (C)	2
L1022	12048BT-T121	X-Axis Timing Belt	2
L1023	14051PR-UK01	Fixing Plate	8
L1024	14052PR-UK01	Fixing Plate Holder	8
L1025	GP-004919-00	LM Block Driving Plate(L)	4
L1026	GP-004920-00	LM Block Driving Plate(R)	4
L1027	12017PU-T121	Timing Pulley "A"	4
	12018BR-T121	Neddle Bearing Hk1010(Ina)	8
L1028	12019BR-T121	Fiber Washer R-Tw1020	8
L1029	03106000U000	Timing Pulley Driving Pin	4
L1030	15048SC-4119	Plus Screw (M5*L12)	4
L1031	08044SR-4013	E-Ring (@8)	4
L1032	04014SC-4517	Hex.Socket Set Screw(M5*L5)	8
L1033	14065AD-UK01	Motor Fixing Shaft (A)	8
L1034	15053SC-4119	Plus Screw (M5*L30)	8
L1035	14067AD-UK01	Motor Fixing Shaft (B)	4
L1036	15055SC-4119	Plus Screw (M5*L35)	4
L1037	08076SC-7113	Hex. Socket Bolt (M5*L12)	24
L1038	18048SW-3115	Spring Washer (@5)	24
L1039	05100100T000	X-Motor (103H7126-2851)	4

Ref. No	Part No.	Part Names	Q'ty
L1040	15059PR-UK02	X-Motor Space	16
L1041	16018SW-1111	Washer (@5)	16
L1042	15060PR-UK02	X-Motor Base(L)	2
L1043	15061PR-UK02	X-Motor Base(R)	2
L1044	15077BR-A001	Ball Bearing (698Zz)	4
L1045	03000100U020	X-Motor Fixing Block	4
L1046	14063PU-UK01	Timing Pulley "B"	4
L1047	03071SC-7113	HEX. SOCKET BOLT (M3*L10)	32
L1048	GP-004923-00	Perception Plate	2
L1049	15044EL-T121	Bid (S)	4
L1050	15045EL-UK01	Bid (L)	2
L1051	25013EL-UK02	X-Step Motor Driving Power 3	2
L1052	25019EL-T121	Power Cable 2 (1Ht-19)	2
L1053	02101300U040	X-Step Motor Driving Power	2
L1054	08102300B000	Half Turn Sensor (Gp1S51V)	4
L1055	06010SC-8118	Plus Screw(M3*L4)	8
L1056	25046EL-UK02	X-Original In Sensor (White)	2
L1057	25047EL-UK02	X-Original In Sensor (Black)	2
L1058	25040EL-T121	X-Original In Con. (1Ht-40)	2
L1059	25041EL-UK01	X Original In (4Ht-41)	2
L1060	15082PR-W121	FIXING PLATE FOR BUSHING	2
L1061	02023SC-7113	HEX.SOCKET BOLT (M4*L8)	8
L1062	15087PR-UK02	Cable Plate For Bushing	2
L1063	GP-004924-00	X-Frame Cover	2
L1064	15042SC-3123	Truss Screw (M4*L6)	16
L1065	18153SC-3123	Plus Screw (M4*L10)	4
L1066	GP-005106-00	X-FRAME SIDE COVER L	2
L1067	GP-005107-00	X-FRAME SIDE COVER R	2
L1068	15042SC-3123	TRUSS SCREW (M4*L6)	8
L1069	GP-005104-00	X-Frame Side Cover Holder (L)	2
L1070	GP-005105-00	X-Frame Side Cover Holder (R)	2
L1071	02004SC-4113	HEX. SOCKET BOLT (M4*L8)	16
L1072	18014SW-3115	SPRING WASHER (@4-NO2)	16
L1073	18015SW-3111	WASHER (4@)	16


L2

X-Axis Drive Set(UH1506D)



L3

X Axis Drive System (UH1208D)




Ref.No	Part No.	PartNames	Q'ty
L3001	GP-004142-02	X-FRAME(L=2135)	2
L3002	GP-004143-00	X-LM RAIL "A" (THK SR15W- L580)	4
L3003	03200600UH00	X-LM RAIL "B" (THK SR15W- L690)	2
L3004	22006SC-7113	Hex. Socket Bolt (M3*L8)	88
L3005	15044EL-T121	Bid (S)	4
L3006	25014EL-UK01	Calble (4Ht-14)	2
L3007	15062SF-T121	Felt	12
L3008	03200700UH00	Tubular Frame Rail Plate	1
L3009	15007PR-UK02	CONNECTING PLATE(L)	2
L3010	02015SC-4113	HEX.SOCKET BOLT(M4*L10)	4
L3011	18014SW-3115	Spring Washer (@4-No2)	4
L3012	18015SW-3111	WASHER (4@)	4
L3013	15011PR-UK02	CONNECTING PLATE(R)	2
L3014	02015SC-4113	HEX.SOCKET BOLT(M4*L10)	4
L3015	18014SW-3115	SPRING WASHER (@4-NO2)	4
L3016	18015SW-3111	WASHER (4@)	4
L3017	15015PR-UK02	Connecting Plate	8
L3018	02015SC-4113	HEX.SOCKET BOLT(M4*L10)	32
L3019	18014SW-3115	Spring Washer (@4-No2)	32
L3020	18015SW-3111	WASHER (4@)	32
L3021	GP-004144-00	LM Block Connecting Plate(L) (L=537)	2
L3022	02004SC-4113	HEX. SOCKET BOLT (M4*L8)	8
L3023	18014SW-3115	SPRING WASHER (@4-NO2)	8
L3024	18015SW-3111	WASHER (4@)	8
L3025	GP-004145-00	LM Block Connecting Plate(R) (L=537)	2
L3026	02004SC-4113	HEX. SOCKET BOLT (M4*L8)	8
L3027	18014SW-3115	SPRING WASHER (@4-NO2)	8
L3028	18015SW-3111	WASHER (4@)	8
L3029	14020PR-UK01	SPACE	4
L3030	14045AD-UK01	BELT BRACKET (B)	4
L3031	15034SC-4113	HEX. SOCKET BOIT (M4*L45)	4
L3032	05009SW-1111	WASHER (@4-L)	4
L3033	14048AD-UK01	BELT BRACKET (A)	2
L3034	14049AD-UK01	BELT BRACKET (C)	2
L3035	03201100UH00	X Timing Belt (015-AT5-0299)	4
L3036	14051PR-UK01	FIXING PLATE	8
L3037	14052PR-UK01	FIXING PLATE HOLDER	8
L3038	13020SC-4113	HEX. SOCKET BOLT (M3*L8)	32
L3039	11019SW-9115	SPRING WASHER (3@)	32
L3040	08011SW-1111	SPRING WASHER (@3-S)	32

Ref. No	Part No.	Part Names	Q'ty
L3041	12017PU-T121	Timing Pulley "A"	4
L3042	12018BR-T121	Neddlle Bearing Hk1010(Ina)	8
L3043	12019BR-T121	FIBER WASHER R-TW1020	8
L3044	14060CW-UK01	TIMING PULLEY DRIVING PIN	4
L3045	15048SC-4119	PLUS SCREW (M5*L12)	4
L3046	08044SR-4013	E-RING (@8)	4
L3047	14063PU-UK01	Timing Pulley "B"	4
L3048	04014SC-4517	HEX.SOCKET SET SCREW(M5*L5)	8
L3049	14065AD-UK01	MOTOR FIXING SHAFT (A)	8
L3050	15053SC-4119	PLUS SCREW (M5*L30)	8
L3051	14067AD-UK01	MOTOR FIXING SHAFT (B)	4
L3052	15055SC-4119	PLUS SCREW (M5*L35)	4
L3053	14069AD-UK01	Motor Block	4
L3054	08076SC-4113	HEX. SOCKET BOLT (M5*L12)	8
L3055	16019SW-4115	SPRING WASHER (@5)	8
L3056	14071BR-UK01	Bearing Bc616Zz	4
L3057	15076AF-UK01	X-MOTOR	4
L3058	15061PR-UK01	MOTOR SPACE (@5*@11*2T)	16
L3059	14074PR-UK01	MOTOR BASE (L)	2
L3060	14075PR-UK01	MOTOR BASE (R)	2
L3061	08076SC-4113	HEX. SOCKET BOLT (M5*L12)	16
L3062	16019SW-4115	SPRING WASHER (@5)	16
L3063	16018SW-1111	WASHER (@5)	16
L3064	03201200UH00	X-MOVING SENSOR PLATE	2
L3065	02004SC-4113	HEX. SOCKET BOLT (M4*L8)	4
L3066	18014SW-3115	SPRING WASHER (@4-NO2)	4
L3067	18015SW-3111	WASHER (4@)	4
L3068	03201600UH00	X-POSITIONING SENSOR	4
L3069	06010AF-8118	PLUS SCREW(M3*L4)	8
L3070	15067PR-UK01	SENSOR PLATE	4
L3071	02004SC-4113	HEX. SOCKET BOLT (M4*L8)	8
L3072	18014SW-3115	Spring Washer (@4-No2)	8
L3073	18015SW-3111	Washer (4@)	8
L3074	15087PR-UK02	CABLE PLATE FOR BUSHING	2
L3075	02010SC-3123	TRUSS SCREW (M4*L8)	4
L3076	GP-004146-00	X-FRAME COVER	2
L3077	15042SC-3123	TRUSS SCREW (M4*L6)	32
L3078	18153SC-3123	PLUS SCREW (M4*L10)	4
L3079	GP-005106-00	X-FRAME SIDE COVER L	2
L3080	GP-005107-00	X-FRAME SIDE COVER R	2

L3


X Axis Drive System (UH1208D)



[illegible]

L4

X-Axis Drive System (UH1512D)




Ref.No	Part No.	PartNames	Q'ty
L4001	GP-005070-01	X-Lm Guide Frame	2
L4002	03200500UH00	X-Axis L/M Guide "A"	4
L4003	03200600UH00	X-Axis L/M "B"	1
L4004	22006SC-7113	Hex. Socket Bolt (M3*L8)	92
L4005	15062SF-T121	Felt	16
L4006	03200700UH00	Tubular Frame Rail Plate	2
L4007	15007PR-UK02	Connecting Plate(L)	2
L4008	02015SC-7113	Hex.Socket Bolt(M4*L10)	16
L4009	02028SW-9115	Spring Washer (@4)	16
L4010	02063SW-1111	Washer(@4)	16
L4011	15011PR-UK02	Connecting Plate(R)	2
L4012	15015PR-UK02	Connecting Plate	4
L4013	03200800UH00	L/M Block Connecting Plate (L)	1
L4014	02023SC-7113	Hex. Socket Bolt (M4*L8)	32
L4015	02028SW-9115	Spring Washer (@4)	32
L4016	05009SW-1111	Washer (@4-L)	32
L4017	03200900UH00	L/M Block Connecting Plate (R)	2
L4018	03201000UH00	L/M Block Connecting Plate	4
L4019	14020PR-UK01	Space	4
L4020	14045AD-UK01	Belt Bracket (B)	4
L4021	15034SC-4113	Hex. Socket Boit (M4*L45)	4
L4022	05009SW-1111	Washer (@4-L)	4
L4023	14049AD-UK01	Belt Bracket (C)	2
L4024	14048AD-UK01	Belt Bracket (A)	2
L4025	03201100UH00	X-Timming Belt (L=1260)	4
L4026	14051PR-UK01	Fixing Plate	8
L4027	14052PR-UK01	Fixing Plate Holder	8
L4028	03071SC-A001	Hex.Scoket Bolt (M3*L15)	32
L4029	11019SW-9115	Spring Washer (3@)	32
L4030	08011SW-1111	Spring Washer (@3-S)	32
L4031	12017PU-T121	Timing Pulley "A"	4
L4032	12018BR-T121	Neddle Bearing Hk1010(Ina)	8
L4033	12019BR-T121	Fiber Washer R-Tw1020	8
L4034	03106000U000	Timing Pulley Driving Pin	4
L4035	15048SC-4119	Plus Screw (M5*L12)	4
L4036	08044SR-4013	E-Ring (@8)	4
L4037	14063PU-UK01	Timing Pulley "B"	4
L4038	04014SC-4517	Hex.Socket Set Screw(M5*L5)	8
L4039	14065AD-UK01	Motor Fixing Shaft (A)	8
L4040	15053SC-4119	Plus Screw (M5*L30)	8

Ref. No	Part No.	Part Names	Q'ty
L4041	14067AD-UK01	Motor Fixing Shaft (B)	4
L4042	15055SC-4119	Plus Screw (M5*L35)	4
L4043	14069AD-UK01	Motor Block	4
L4044	08076SC-7113	Hex. Socket Bolt (M5*L12)	40
L4045	18048SW-3115	Spring Washer (@5)	40
L4046	14071BR-UK01	Bearing Bc616Zz	4
L4047	15076AF-UK01	X-Motor	4
L4048	15061PR-UK01	Motor Space (@5*@11*2T)	16
L4049	16018SW-1111	Washer (@5)	16
L4050	14074PR-UK01	Motor Base (L)	2
L4051	14075PR-UK01	Motor Base (R)	2
L4052	03201200UH00	X-Moving Sensor Plate	2
L4053	02023SC-7113	Hex. Socket Bolt (M4*L8)	12
L4054	02028SW-9115	Spring Washer (@4)	12
L4055	05009SW-1111	Washer (@4-L)	12
L4056	15067PR-UK01	Sensor Plate	4
L4057	15043EL-UK01	X-Positioning Sensor	4
L4058	06010AF-8118	Plus Screw(M3*L4)	8
L4059	15087PR-UK02	Cable Plate For Bushing	2
L4060	15082PR-W121	FIXING PLATE FOR BUSHING	2
L4061	02023SC-7113	HEX.SOCKET BOLT (M4*L8)	8
L4062	03201300UH00	X-Cover (L=2931)	24
L4063	15042SC-3123	Truss Screw (M4*L6)	4
L4064	18153SC-3123	Plus Screw (M4*L10)	2
L4065	GP-005104-00	X-Frame Side Cover Holder (L)	2
L4066	GP-005105-00	X-Frame Side Cover Holder (R)	16
L4067	02023SC-7113	Hex. Socket Bolt (M4*L8)	16
L4068	02028SW-9115	Spring Washer (@4)	16
L4069	05009SW-1111	Washer (@4-L)	16
L4070	GP-005106-00	X-Axis Frame Side Cover (L)	2
L4071	GP-005107-00	X-Axis Frame Side Cover (R)	2
L4072	15042SC-3123	Truss Screw (M4*L6)	8
L4073	25052EL-UK01	Last-Sensor (Black) 4Ht-52	2
L4074	25053EL-UK01	Last-Sensor (White) 4Ht-53	2
L4075	03101700UH00	Roller Fixed Plate	4
L4076	02023SC-7113	Hex.Socket Bolt (M4*L8)	8
L4077	18014SW-3115	Spring Washer (@4-No2)	8
L4078	18015SW-3111	Washer (4@)	8
L4079	15104CW-UK01	Roller Stud Bolt	4
L4080	15130AF-A001	Roller Guide	4


L4

X-Axis Drive System (UH1512D)



M1

Y-Axis Drive System (UH1504D)




Ref.No	Part No.	Part Names	Q'ty
M1001	GP-004930-00	Y-LM Guide Frame L620	4
M1002	GP-004147-00	Cam Roller Guide Rail (L590)	8
M1003	04016MC-4113	CAM ROLLER GUIDE FIXED SCREW	56
M1004	02033SC-4113	Hex. Socket Bolt	16
M1005	03003SC-4113	Hex. Socket Bolt "B"(M8*L35)	12
M1006	15095SW-3115	Spring Washer (@8)	28
M1007	04029SW-A001	Stud Bolt Washer(S) (@8)	28
M1008	GP-005021-00	Bracker For X-Y Connecting	4
M1009	07016SC-7113	Hex.Socket Bolt (M4*L12)	32
M1010	18014SW-3115	Spring Washer (@4-No2)	32
M1011	05009SW-1111	Washer (@4-L)	32
M1012	03010400UH00	Plate For Y-Sensing	2
M1013	22006SC-7113	Hex. Socket Bolt (M3*L8)	4
M1014	11019SW-9115	Spring Washer (3@)	4
M1015	08011SW-1111	Spring Washer (@3-S)	4
M1016	16104CL-H001	Belt Catcher Plate (Y)	8
M1017	15002CW-B001	Cam Roller Stud (A)	16
M1018	15029SN-3211	Hex. Nut (M4-No2)	16
M1019	02028SW-9115	Spring Washer (@4)	16
M1020	15003CW-B001	Cam Roller Stud (B)	16
M1021	12010SN-1211	Hex.Nut (M5)	16
M1022	15001BR-B001	Cam Roller Baearing	32
M1023	16074PR-UK06	Y-Lm Support Fixing Plate	2
M1024	14002SC-7113	Hex.Socket Bolt (M6*L15)	8
M1025	16014SW-4115	Spring Washer (@6)	8
M1026	08057SW-1111	Washer (@6)	8
M1027	03016SC-4113	Hex. Socket Bolt (M5*L15)	8
M1028	18048SW-3115	Spring Washer (@5)	8
M1029	16018SW-1111	Washer (@5)	8
M1030	03101300UH00	Sensor Bracket	1
M1031	03101300UH00	Sensor Bracket	1
M1032	02015SC-7113	Hex.Socket Bolt(M4*L10)	4
M1033	02028SW-9115	Spring Washer (@4)	4
M1034	05009SW-1111	Washer (@4-L)	4
M1035	02107300UH80	Cable (Sh-73)	2
M1036	06010SC-8118	Plus Screw (M3*L4)	4
M1037	03100600UH00	Tension Adjusting Plate	4
M1038	07016SC-7113	Hex.Socket Bolt (M4*L12)	8
M1039	18014SW-3115	Spring Washer (@4-No2)	8
M1040	18015SW-3111	Washer (4@)	16


Ref. No	Part No.	Part Names	Q'ty
M1041	03100700UH00	Fixed Block	4
M1042	11029SC-4113	Hex. Socket Bolt (M4*L20)	4
M1043	18014SW-3115	Spring Washer (@4-No2)	4
M1044	18015SW-3111	Washer (4@)	4
M1045	15030SC-7113	Hex. Socket Bolt (M5*L30)	4
M1046	18048SW-3115	Spring Washer (@5)	4
M1047	16018SW-1111	Washer (@5)	4
M1048	03100500UH00	Y-Tension Adjusting Bracket	4
M1049	08007SC-4517	Hex. Socket Set Screw (M3*L5)	8
M1050	04500100U000	Y-Drive Timing Pulley	4
M1051	12018BR-T121	Neddle Bearing Hk1010(Ina)	8
M1052	12019BR-T121	Fiber Washer R-Tw1020	8
M1053	16100CW-UK06	Timing Pulley Shaft (Y)	4
M1054	03100400UH01	Y-Driving Timing Belt	4
M1055	03101000UH00	Y-Bearing Bracket (R)	4
M1056	03100900UH00	Y-Bearing Bracket (L)	4
M1057	08091SC-7113	Hex. Socket Bolt (M6*L20)	16
M1058	13026BR-T121	Needle Bearing (6002Z)	4
M1059	03002700T000	Bearing Collar	8
M1060	03037AF-A001	Driver Screw	16
M1061	04001000U000	Y-Drive Timing Pulley	4
M1062	04014SC-4517	Hex.Socket Set Screw(M5*L5)	16
M1063	03101100UH00	Y-Bearing Bracket Cover	4
M1064	07035SC-7113	Bracket Screw (M3*L6)	16
M1065	11019SW-9115	Spring Washer (3@)	16
M1066	08011SW-1111	Spring Washer (@3-S)	16
M1067	03005100U000	Coupling "A"	4
M1068	03016SC-4113	Hex. Socket Bolt (M5*L15)	8
M1069	03100800UH60	Y-Driving Shaft "A"	4
M1070	03003800B000	Coupling	4
M1071	08091SC-7113	Hex. Socket Bolt (M6*L20)	16
M1072	16055MT-UK06	Y Motor	2
M1073	08062SC-7113	Hex.Socket Bolt (M5*L20)	8
M1074	18048SW-3115	Spring Washer (@5)	8
M1075	16018SW-1111	Washer (@5)	8
M1076	15057CS-UK01	Y-Driving Motor Bracket	2
M1077	14027SC-4113	Hex.Socket Bolt (M8*L30)	8
M1078	15095SW-3115	Spring Washer (@8)	8
M1079	04029SW-A001	Stud Bolt Washer(S) (@8)	8
M1080	15045EL-UK01	Bid (L)	2

M1

Y-Axis Drive System (UH1504D)




M2 Y-Axis Drive System (UH1506D,UH1508D)



Ref.No	Part No.	Part Names	Q'ty
M2001	03003000UH60	Y-LM Guide Frame L620	4
M2002	03100100UH01	Cam Roller Guide Rail (L590)	8
M2004	14027SC-4113	Hex. Socket Bolt	16
M2005	03003SC-4113	Hex. Socket Bolt "B" (M8*L35)	20
M2006	15095SW-3115	Spring Washer (@8)	36
M2007	04029SW-A001	Stud Bolt Washer(S) (@8)	36
M2008	GP-005021-00	Bracker For X-Y Connecting	4
M2009	07016SC-7113	Hex.Socket Bolt (M4*L12)	32
M2010	18014SW-3115	Spring Washer (@4-No2)	32
M2011	18015SW-3111	Washer (@4-L)	32
M2012	03101400UH00	Plate For Y-Sensing	2
M2013	22006SC-7113	Hex. Socket Bolt (M3*L8)	4
M2014	11019SW-9115	Spring Washer (3@)	4
M2015	08011SW-1111	Spring Washer (@3-S)	4
M2016	16104CL-H001	Belt Catcher Plate (Y)	8
M2017	02028SW-9115	Cam Roller Stud (A)	16
M2018	15029SN-3211	Hex. Nut (M4-No2)	16
M2019	02028SW-9115	Spring Washer (@4)	16
M2020	15003CW-B001	Cam Roller Stud (B)	16
M2021	12010SN-1211	Hex.Nut (M5)	16
M2022	15001BR-B001	Cam Roller Baearing	32
M2023	16074PR-UK06	Y-Lm Support Fixing Plate	2
M2024	14006SC-7113	Hex.Socket Bolt (M8*L15)	8
M2025	15095SW-3115	Spring Washer (@6)	8
M2026	08041SW-1111	Washer (@6)	8
M2027	08076SC-7113	Hex. Socket Bolt (M5*L15)	8
M2028	18048SW-3115	Spring Washer (@5)	8
M2029	16018SW-1111	Washer (@5)	8
M2030	03101300UH00	Bracket for Y-Sensor	2
M2031	03101300UH00	Bracket for Y-Sensor	2
M2032	02015SC-7113	Hex.Socket Bolt(M4*L10)	4
M2033	02028SW-9115	Spring Washer (@4)	4
M2034	05009SW-1111	Washer (@4-L)	4
M2035	09018EL-UK01	Sensor	2
M2036	08006SC-8118	Plus Screw (M3*L5)	4
M2037	03100600UH00	Tension Adjusting Plate	4
M2038	07016SC-7113	Hex.Socket Bolt (M4*L12)	8
M2039	18014SW-3115	Spring Washer (@4-No2)	8
M2040	18015SW-3111	Washer (4@)	16
M2041	03100700UH00	Fixed Block	4


Ref. No	Part No.	Part Names	Q'ty
M2042	11029SC-4113	Hex. Socket Bolt (M4*L20)	4
M2043	18014SW-3115	Spring Washer (@4-No2)	4
M2044	18015SW-3111	Washer (4@)	4
M2045	16028SC-7113	Hex. Socket Bolt (M5*L25)	4
M2046	18048SW-3115	Spring Washer (@5)	4
M2047	16018SW-1111	Washer (@5)	4
M2048	03100500UH00	Y-Tension Adjusting Bracket	4
M2049	08007SC-4517	Hex. Socket Set Screw (M3*L5)	8
M2050	03003400UH60	Y-Drive Timing Pulley	4
M2051	12018BR-T121	Neddle Bearing Hk1010(Ina)	8
M2052	12019BR-T121	Fiber Washer R-Tw1020	8
M2053	16100CW-UK06	Timing Pulley Shaft (Y)	4
M2054	03100400UH81	Y-Driving Timing Belt	4
M2055	GP-007144-00	Y-Bearing Bracket (R)	4
M2056	GP-007145-00	Y-Bearing Bracket (L)	4
M2057	16059SC-7113	Hex. Socket Bolt (M6*L20)	16
M2058	13026BR-T121	Needle Bearing (6002Z)	4
M2059	03002700T000	Bearing Collar	8
M2060	03037AF-A001	Driver Screw	16
M2061	04001000 E000	Y-Drive Timing Pulley	4
M2062	04014SC-4517	Hex.Socket Set Screw(M5*L5)	16
M2063	03101100UH00	Y-Bearing Bracket Cover	4
M2064	07035SC-7113	Bracket Screw (M3*L6)	16
M2065	11019SW-9115	Spring Washer (3@)	16
M2066	08011SW-1111	Spring Washer (@3-S)	16
M2067	GP-007148-00	Y-Driving Shaft "A"	UH1506D 2
	GP-007148-00	Y-Driving Shaft "A"	UH1208D 2
M2070	GP-007516-00	Y-Driving Shaft "B"	UH1506D 2
	GP-004159-01	Y-Driving Shaft	UH1208D 2
M2073	16059MT-E131	Y Motor (103H89222-5212)	2
M2074	14046SC-7113	Hex.Socket Bolt (M6*L30)	8
M2075	16014SW-4115	Spring Washer (@6)	8
M2076	08057SW-1111	Washer (@6)	8
M2082	GP-004150-00	Y-LM Support Fixing Plate(A)	1
M2083	GP-004150-00	Y-LM Support Fixing Plate(A)	1
M2084	08062SC-7113	Hex. Socket Bolt (M5*L20)	8
M2085	18048SW-3115	Spring Washer (@5)	8
M2086	16018SW-1111	Washer (@5)	8
M2087	03016SC-4113	Hex. Socket Bolt (M5*L15)	4
M2088	18014SW-3115	Spring Washer (@4-No2)	4

Y-Axis Drive System (UH1506D,UH1508D)



M3

Y-Axis Drive System (UH1512D)




Ref.No	Part No.	Part Names	Q'ty
M3001	GP-004148,00	Y-LM Guide Frame L620	4
M3002	GP-004147,00	Cam Roller Guide Rail (L590)	8
M3003	04016MC-4113	CAM ROLLER GUIDE FIXED SCREW	56
M3004	02033SC-4113	Hex. Socket Bolt	16
M3005	03003SC-4113	Hex. Socket Bolt "B"(M8*L35)	12
M3006	15095SW-3115	Spring Washer (@8)	28
M3007	04029SW-A001	Stud Bolt Washer(S) (@8)	28
M3008	GP-004149,00	Bracker For X-Y Connecting	4
M3009	07016SC-7113	Hex.Socket Bolt (M4*L12)	32
M3010	18014SW-3115	Spring Washer (@4-No2)	32
M3011	05009SW-1111	Washer (@4-L)	32
M3012	03003800UH60	Plate For Y-Sensing	2
M3013	22006SC-7113	Hex. Socket Bolt (M3*L8)	4
M3014	11019SW-9115	Spring Washer (3@)	4
M3015	08011SW-1111	Spring Washer (@3-S)	4
M3016	16104CL-H001	Belt Catcher Plate (Y)	8
M3017	15002CW-B001	Cam Roller Stud (A)	16
M3018	15029SN-3211	Hex. Nut (M4-No2)	16
M3019	02028SW-9115	Spring Washer (@4)	16
M3020	15003CW-B001	Cam Roller Stud (B)	16
M3021	12010SN-1211	Hex.Nut (M5)	16
M3022	15001BR-B001	Cam Roller Baearing	32
M3023	16074PR-UK06	Y-Lm Support Fixing Plate	2
M3024	14002SC-7113	Hex.Socket Bolt (M6*L15)	8
M3025	16014SW-4115	Spring Washer (@6)	8
M3026	08057SW-1111	Washer (@6)	8
M3027	03016SC-4113	Hex. Socket Bolt (M5*L15)	8
M3028	18048SW-3115	Spring Washer (@5)	8
M3029	16018SW-1111	Washer (@5)	8
M3030	03101300UH00	Sensor Bracket	1
M3031	03101300UH00	Sensor Bracket	1
M3032	02015SC-7113	Hex.Socket Bolt(M4*L10)	4
M3033	02028SW-9115	Spring Washer (@4)	4
M3034	05009SW-1111	Washer (@4-L)	4
M3035	02107300UH80	Cable (Sh-73)	2
M3036	06010SC-8118	Plus Screw (M3*L4)	4
M3037	03100600UH00	Tension Adjusting Plate	4
M3038	07016SC-7113	Hex.Socket Bolt (M4*L12)	8
M3039	18014SW-3115	Spring Washer (@4-No2)	8
M3040	18015SW-3111	Washer (4@)	16

Ref. No	Part No.	Part Names	Q'ty
M3041	03100700UH00	Fixed Block	4
M3042	11029SC-4113	Hex. Socket Bolt (M4*L20)	4
M3043	18014SW-3115	Spring Washer (@4-No2)	4
M3044	18015SW-3111	Washer (4@)	4
M3045	15030SC-7113	Hex. Socket Bolt (M5*L30)	4
M3046	18048SW-3115	Spring Washer (@5)	4
M3047	16018SW-1111	Washer (@5)	4
M3048	03100500UH00	Y-Tension Adjusting Bracket	4
M3049	08007SC-4517	Hex. Socket Set Screw (M3*L5)	8
M3050	04001000 E000	Y-Drive Timing Pulley	4
M3051	12018BR-T121	Neddle Bearing Hk1010(Ina)	8
M3052	12019BR-T121	Fiber Washer R-Tw1020	8
M3053	16100CW-UK06	Timing Pulley Shaft (Y)	4
M3054	-	Y-Driving Timing Belt	4
M3055	03101000UH00	Y-Bearing Bracket (R)	4
M3056	03100900UH00	Y-Bearing Bracket (L)	4
M3057	08091SC-7113	Hex. Socket Bolt (M6*L20)	16
M3058	13026BR-T121	Needle Bearing (6002Z)	4
M3059	03002700T000	Bearing Collar	8
M3060	03037AF-A001	Driver Screw	16
M3061	03003500UH60	Y-Drive Timing Pulley	4
M3062	04014SC-4517	Hex.Socket Set Screw(M5*L5)	16
M3063	03101100UH00	Y-Bearing Bracket Cover	4
M3064	07035SC-7113	Bracket Screw (M3*L6)	16
M3065	11019SW-9115	Spring Washer (3@)	16
M3066	08011SW-1111	Spring Washer (@3-S)	16
M3067	GP-007148-00	Y-Driving Shaft "A"	2
M3068	03005100U000	Coupling "A"	4
M3069	03016SC-4113	Hex. Socket Bolt (M5*L15)	8
M3070	GP-005078-01	Y-Driving Shaft UH1512D	4
M3071	03003800B000	Coupling	4
M3072	08091SC-7113	Hex. Socket Bolt (M6*L20)	16
M3073	16059MT-E131	Y Motor (103H89222-5212)	2
M3074	14046SC-7113	Hex.Socket Bolt (M6*L30)	8
M3075	16014SW-4115	Spring Washer (@6)	8
M3076	08057SW-1111	Washer (@6)	8
M3077	03100500UH80	Y-Driving Motor Bracket	2
M3078	14027SC-4113	Hex.Socket Bolt (M8*L30)	8
M3079	15095SW-3115	Spring Washer (@8)	8
M3080	04029SW-A001	Stud Bolt Washer(S) (@8)	8


M3

Y-Axis Drive System (UH1512D)




N1

Tubular Frame (UH1504D)




N2

Tubular Frame (UH1506D)




N3


Tubular Frame (UH1208D)





N4


Tubular Frame (UH1512D)













P


S/B Switch Unit





Q2

Sub Control Unit & Lamp (UH1506D)





Ref.No	Part No.	Part Names	Q'ty
Q2001	GP-008788-00	Cable Cover A	1
Q2002	GP-008789-01	Cable Cover B	1
Q2003	02031SC-7113	Hex. Socket Screw(M5*L10)	4
Q2004	18049SW-3111	Washer (@5)	4
Q2005	08076SC-7113	Hex. Socket Bolt (M5*L12)	8
Q2006	18048SW-3115	Spring Washer (@5)	8
Q2007	16018SW-1111	Washer (@5)	8
Q2008	11049SC-A001	Board Stud Bolt	24
Q2009	18048SW-3115	Spring Washer (@5)	24
Q2010	18154SC-9134	PLUS SCREW (M3*L8)	24
Q2011	02054RB-UK01	Clamp Rubber	2
Q2012	02053PR-UK01	Cable Clamp	2
Q2013	11000110UH00	LAMP BRACKET	4
Q2014	08091SC-7113	Hex. Socket Bolt (M6*L20)	8
Q2015	16014SW-4115	Spring Washer (@6)	8
Q2016	08057SW-1111	Washer (@6)	8
Q2018	14014SC-7113	Hex.Socket Set Screw(M5*L8)	8
Q2019	18048SW-3115	Spring Washer (@5)	8
Q2021	02105700U040	Cable (Sh-57-2)	2
Q2022	02105610U040	Sh-56-2	2
Q2023	02106000U040	Cable (Sh-60-2)	2
Q2024	03-0000-HB11	Thread Control Joint Board	2
Q2025	02105900U000	Sh-59	2
Q2026	11093EL-C001	SUB-CONTROL BOARD NC-THS2.3	6
Q2027	20038PR-T121	WASHER (@8)	4
Q2028	25022EL-UK01	To Adjusting Plate (4Ht-22)	6
Q2029	20007BM-A001	Lamp Ass-Y "A"	2
Q2030	20014SC-9124	Hex. Socket Screw(M4*L8)	6
Q2031	20014ET-A001	Lamp Socket	4
Q2032	02105000E040	Cable	2
Q2033	32016PR-UH36	REFLECTING COVER	2
Q2034	32004PR-UK01	Lamp Socket Fixed Plate	4
Q2035	32025PR-UK01	Lamp Structure B	2
Q2036	09000700U000	BALLAST	2
Q2037	20009EL-B001	LAMP (32W)	2
Q2038	18013AF-7113	Hex. Socket Bolt(M4*L10)	2
Q2039	18049SW-3111	Washer (@5)	2
Q2040	01002600UH60	X-MOTOR CABLE HOLDER	2
Q2041	08076SC-7113	Hex. Socket Bolt(M5*L12)	4
Q2042	16018SW-1111	Washer (@5)	4





[illegible]

Q3

Sub Control Unit & Lamp (UH1208D)











Main Board




Joint Board (A)



Joint Board (B)



Joint Board (A)




SMPS(A)



SMPS(A)



SMPS(B)



T

Operation Unit



Ref.No	Part No.	PartNames	Q'ty
T-001	SWF-OB-DUAL	Operation Box (Set)	1
T-002	01-007A-DU33	Baseplate	1
T-003	20-006A-SW70	10.4 inch LCD	2
T-004	20-001B-SW70	Protection Sponge for LCD	2
T-005	01-012A-DU33	LCD Fixing Bracket A	2
T-006	01-013A-DU33	LCD Fixing Bracket B	2
T-007	20-001C-SW70	Screw Ass'y For LCD (M2×L6)	8
T-008	10-072S-SW70	SCREW FOR FDD PROTECTOR (M3×L12)	8
T-009	01-011A-DU33	LCD Pressing Plate	2
T-010	20-002B-SW70	LCD Pressing Plate Sponge	2
T-011	10-028S-SC53	Screw Ass'y For LCD Pressing Plate (M3×L7)	4
T-012	22027EL-A001	LCD Inverter	2
T-013	10-072S-SW70	SCREW FOR FDD PROTECTOR (M3×L12)	4
T-014	01-001R-DU33	LCD Cable Sponge	2
T-015	02-0000-DU33	DDC Board	1
T-016	02-101A-DU33	DDC Board Radiator	1
T-017	10-073S-SW70	Screw Ass'y For DDC Board Radiator (M3×L12)	4
T-018	10-028S-SC53	Screw Ass'y For switching regulator (M3×L7)	4
T-019	04-005A-SW64	CPU Fan	1
T-020	10-072S-SW70	Screw Ass'y For CPU Fan (M3xL12)	4
T-021	10-042M-AU10	Screw Ass'y For DDC Board Radiator (M4×L16)	2
T-022	01-016A-DU33	Speaker	2
T-023	10-028S-SC53	Screw For Speaker (M3×L8)	4
T-024	08-0000-DU33	Connector Board	1
T-025	10-028S-SC53	Screw Ass'y For Connector Board (M3×L7)	2
T-026	10-004A-AT10	FDD	1
T-027	01-019A-DU33	FDD Bracket	1
T-028	10-004M-PT01	INSULATOR PLATE FOR FDD	2
T-029	01-101B-OT10	OP Box insulation Bushing (B)	4
T-030	10-020M-SW66	Screw Ass'y For FDD (M3xL12)	4
T-031	01-018A-DU33	FDD Support	1
T-032	10-002S-SW66	Screw Ass'y For FDD Support (M3×L8)	4
T-033	10-028S-SC53	Screw Ass'y For FDD Bracket (M3×L7)	4
T-034	01-009A-DU33	FDD Fixing Bracket	1
T-035	01-005A-BT01	Middle Fan	1
T-036	01-017C-DU33	Screw For Middle Fan (M4×L25)	2
T-037	01-004S-2070	COVER SCREW SET	4
T-038	01-010A-DU33	FDD Front Bracket	1
T-039	10-028S-SC53	Screw Ass'y For FDD Front Bracket (M3×L7)	3
T-040	09-0000-DU33	CPU Board	2

Ref. No	Part No.	Part Names	Q'ty
T-041	09-002A-DU33	CPU Board Bracket A	1
T-042	01-020A-DU33	CPU Board Insulated Plate A	1
T-043	10-020M-SW66	Screw Ass'y For CPU Board Bracket A (M3xL12)	4
T-044	09-003A-DU33	CPU Board Bracket B	1
T-045	01-021A-DU33	CPU Board Insulated Plate B	1
T-046	10-020M-SW66	Screw Ass'y For CPU Board Bracket B (M3xL12)	4
T-047	10-001C-AT10	BUSHING-C	20
T-048	01-102B-OT10	OP BOXINSULATOR BUSHING (B)	20
T-049	01-012B-DU33	STUD (A) 3-5-30	12
T-050	04-0000-DU33	I/O Board(R)	1
T-051	10-028S-SC53	Screw Ass'y For I/O Board(R) (M3×L7)	6
T-052	03-0000-DU33	I/O Board(L)	1
T-053	10-028S-SC53	Screw Ass'y For I/O Board(L) (M3×L7)	6
T-054	01-008A-DU33	Chassis	1
T-055	01-004S-2070	COVER SCREW SET	12
T-056	01-014A-DU33	OP Fixing Bracket A	1
T-057	07-004S-SM5S	Screw Ass'y For OP Fixing Bracket A (M4×L10)	9
T-058	01-001A-DU33	Front Cover	1
T-059	09-001A-DU33	Touch Panel	2
T-060	-	Fixing Tape For Touch Panel	-
T-061	01-005A-DU33	Function Button A	1
T-062	01-006A-DU33	Function Button B	1
T-063	06-0000-DU33	Keyboard A	1
T-064	10-024M-SW66	NAIL FOR (3*6)	4
T-065	07-0000-DU33	Keyboard B	1
T-066	10-024M-SW66	NAIL FOR (3*6)	4
T-067	01-004S-2070	COVER SCREW SET	12
T-068	01-002A-DU33	Rear Cover	1
T-069	01-004S-2070	COVER SCREW SET	5
T-070	01-003A-DU33	FDD Cover	1
T-071	01-004A-DU33	Connector Cover	1
T-073	01-013C-DU33	M/C 1 Sticker - A	1
T-074	01-015C-DU33	M/C 1 Sticker - B	4
T-075	01-014C-DU33	M/C 2 Sticker - A	1
T-076	01-016C-DU33	M/C 2 Sticker - B	4
T-077	01-003B-SW63	Push Latch	2
T-078	01-012C-DU33	Wire Saddle (DAWS-2NA)	10
T-079	09000500UH60	FIXING BRACKET B FOR OP	1
T-080	14002SC-7113	HEX.SOCKET BOLT (M6*L15)	4
T-081	03026SW-9115	Spring Washer For OP Fixing Bracket B (∅6)	4

T

Operation Unit






I/O Board (L)




I/O Board (R)




CPU Board




LCD Inverter




Key Board (A)



Key Board (B)




DDC Board



Connector Board



FDD




1

2

3

4




5

6

7

8




9

10

11

12




13

14

15

16




17

18

19

20



21

22

23

V

Bobbin Winder

SMF®